

## User Manual

X-2000  
X-1000

FC CE  REACH



**X-800**  
**Smartcard Handle**

Designed and manufactured by Austin Hughes

## Legal Information

First English printing, December 2022

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

## Safety Instructions

**Please read all of these instructions carefully before you use the device. Save this manual for future reference.**

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the equipment is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labelled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

## What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
  - Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - Repair or attempted repair by anyone not authorized by us.
  - Any damage of the product due to shipment.
  - Removal or installation of the product.
  - Causes external to the product, such as electric power fluctuation or failure.
  - Use of supplies or parts not meeting our specifications.
  - Normal wear and tear.
  - Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

## Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in business, industrial and commercial environments.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


**IMPORTANT NOTE:** To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

## Before Installation

- It is very important to locate the equipment in a suitable environment.
- The surface for placing and fixing the equipment should be stable and level or mounted into a suitable rack.
- Make sure the place has good ventilation, is out of direct sunlight, away from sources of excessive dust, dirt, heat, water, moisture and vibration.
- Position the equipment with respect to related facilities.

## InfraBox Installation

- Suggest the installation at the rear top mounting of rack
- M6 screws set not provided.




< 1.1 > <b>Tips for Hardware</b>	P.1
<b>Key Hardware</b>	
< 2.1 > Package Contents	P.2
< 2.2 > <b>InfraBox</b> X-1000 / X-2000	P.3
< 2.3 > <b>Handle</b> X-800P / X-800M	P.8
< 2.4 > <b>Door Sensor Installation</b> ( Inductive / IR / Mechanical )	P.19
<b>PDU &amp; Fan Unit</b>	
< 3.1 > PDU	P.26
< 3.2 > Fan Unit	P.27
<b>Environmental Sensor &amp; Peripherals</b>	
< 4.1 > Temp. & Humid Sensor	P.29
< 4.2 > Smoke Sensor	P.30
< 4.3 > Shock Sensor	P.31
< 4.4 > Water Sensor	P.32
< 4.5 > LED Light Bar	P.33
< 4.6 > LED Beacon	P.34
<b>Network Connection</b>	
< 5.1 > Daisy Chain	P.35
< 5.2 > Star	P.35
< 5.3 > Mixed	P.36
<b>Application</b>	
< 6.1 > Data Centre	P.37
< 6.2 > Intelligent Building	P.38
< 6.3 > Remote Site	P.39
< 6.4 > Branches	P.40



< 7.1 >	<b>Tips for System Setup</b>	P.41
< 8.1 >	<b>Key Word &amp; Cabinet Icon</b>	P.42
	<b>Software Installation &amp; Activation</b>	
< 9.1 >	Key features	P.45
< 9.2 >	CD Key Box	P.46
< 9.3 >	Management PC & Client PC Requirement	P.47
< 9.4 >	OS Platform & Web Browser	P.48
< 9.5 >	Prerequisite before Software Installation	P.48
< 9.6 >	Software Installation	P.49
< 9.7 >	Remote Access	P.50
< 9.8 >	Software Activation	P.51
	<b>Operation Setup</b>	
< 10.1 >	<b>Cabinet Alignment</b>	P.54
< 10.2 >	<b>MFP - Master Floor Plan</b>	P.57
< 10.3 >	<b>CA - Control Area</b>	P.59
< 10.4 >	<b>User Setup</b>	P.61
< 10.5 >	<b>Group Setup</b>	P.62
< 10.6 >	<b>Visitor</b>	P.64
	<b>System Setup</b>	
< 11.1 >	Backup & Restore	P.66
< 11.2 >	Alarm Setting / Mail Server Setting / Audio Visual Alarm	P.68
< 11.3 >	Temperature Unit	P.69
< 11.4 >	Door Opening Overdue Setting	P.69
< 11.5 >	Time Rule	P.70
	<b>Operation &amp; Usage</b>	
< 12.1 >	Individual Cabinet Devices Enable & Disable	P.71
< 12.2 >	Individual Cabinet Door open by Remote	P.73
< 12.3 >	Individual Cabinet PDU Configuration & Control	P.74
< 12.4 >	Individual Cabinet Fan Unit Configuration & Control	P.76
< 12.5 >	Console Message	P.77
< 12.6 >	PDU Outlet Grouping	P.78
< 12.7 >	Device & System Event Log	P.81
< 13.1 >	<b>SNMP</b>	P.82
< 14.1 >	<b>FAQ &amp; Troubleshooting</b>	P.83

## < 1.1 > Tips for hardware



# Key Hardware

## < 2.1 > Package Contents

### Unpacking

The equipment comes with the standard parts shown on the package contents. Check and make sure they are included and in good condition. If anything is missing, or damage, contact the supplier immediately.

- X-2000 **OR** X-1000 InfraBox, 1 pc
- 800 MiFARE **OR** Proximity smart card handle, pair
- Inductive **OR** Mechanical door sensor, pair
- Front door cable, 2-section with joint connector, 1 pc ( 3150mm )
- Rear door cable, 2-section with joint connector, 1 pc ( 2350mm )
- 6' Power cord, 1 pc
- Activated smartcard, 1 pc
- Key, 1 pc
- Cable clip, 8 pcs



**OR**




Patented and Worldwide  
Patents Pending

X-800P **OR** X-800M



#### Handle mounting screw set :


- Handle mounting bracket, 2 pcs
- M4 x 9mm screw, 4 pcs
- Square hole washer, 6 pcs
- Circle hole washer, 2 pcs
- M5 x 15mm screw, 2 pcs
- U bracket, 2 pcs
- M3 x 10mm screw, 4 pcs
- Extensions spigot, 2 pcs




Each package bundled with smartcard x 1. The card on the bottom right shows card number information :

## < 2.2 > InfraBox X-1000 / X-2000

### X-1000



### X-2000




- ① Power input
- ② Dual power input ( option )
- ③ Door cable DB-9 connector x 2  
Connect to the front and rear handle
- ④ “Act in Out” LED
- ⑤ Daisy chain RJ45 port x 2  
( Link & Out )
- ⑥ Temp. LED display x 2
- ⑦ Smoke / Shock sensor port x 2
- ⑧ LED Light Bar port x 2
- ⑨ Port for 3rd party alarm board x 1
- ⑩ LED beacon port x 1
- ⑪ Temp. & Humid. sensor port x 2
- ⑫ PDU port x 1 ( RJ-45, up to PDU daisy chain level x 4 )
- ⑬ Fan unit port x 1 ( RJ-45, up to fan unit daisy chain level x 2 )
- ⑭ Water sensor port x 2


### X-1000 / X-2000 Specification

<b>Product Dimension ( W x D x H )</b>	400 x 135 x 39.7 mm / 15.7 x 5.3 x 1.6 inch
<b>Packing Dimension ( W x D x H )</b>	557 x 367 x 98 mm / 21.9 x 14.4 x 3.9 inch
<b>Net / Gross Weight</b>	1.06 kgs ( 2.3 lbs ) / 2.2 kgs ( 4.8 lbs )
<b>Power Consumption</b>	Auto-sensing 100~240VAC, 50 / 60Hz 0.5A, Max. 48 Watt
<b>Operating Temperature</b>	0° to 55°C Degree
<b>Storage Temperature</b>	-5° to 60 °C Degree
<b>Relative Humidity</b>	5~90%, non-condensing
<b>Mounting</b>	1U Rackmount
<b>Safety Regulatory</b>	FCC & CE certified
<b>Environmental</b>	RoHS3 & REACH compliant by SGS


## Key hardware Installation Diagram - InfraBox / Handle / Door Sensor



## InfraBox Daisy Chain Connection



Installation Diagram - PDU / Fan / Sensor / Peripheral




Item	Qty.	Location
① LED Light Bar	2	front & rear top inside
② Smoke Sensor	1	rear inside top
③ Flashing LED Beacon	1	front rack roof
④ Temp. & Humid. Sensor	2	any inside position
⑤ Shock Sensor	1	upper inside
⑥ Fan Unit	2	door mount or rackmount
⑦ PDU	4	vertical or rackmount
⑧ Water Sensor	1	surrounding rack on floor

## IP Setup for InfraBox



Before place the InfraBox to the rack, user **MUST** configure the IP setting for the InfraBox. It takes around 1-2 minutes to complete :

1. Prepare a notebook computer to download the **IP setup utilities** from the link below :  
<http://www.austin-hughes.com/support/utilities/infrasolutionX/InfraBoxSetup.msi>
2. Double click the **InfraBoxSetup.msi** and follow the instruction to complete the utilities installation.
3. Power ON the InfraBox.
4. Go to each InfraBox with the notebook computer & a piece of CAT. 5 / 6 cable to configure the InfraBox as below.



## IP Setup for InfraBox



Write down the new IP address for < 10.2 > MFP - Master Floor Plan

5. Click “ **Scan** ” to search the connected InfraBox.

6. Change the IP address / Subnet mask / Gateway, then Click “ **Save** ” to confirm the setting of InfraBox.

The default IP address is as below :

IP address: 192.168.0.1  
Subnet mask: 255.255.255.0  
Gateway: 192.168.0.254



**Please take the procedure no. 3 to 6 for all InfraBoxes ONE BY ONE.**




## < 2.3 > Handle X-800P / X-800M

### Universal Mounting Cut-out

To achieve the highest level of interoperability offered in the rack industry, the X-800 handle applies the universal mounting cut-out. It avoids costly and complicated door customization for the smartcard handle integration.

Unit : mm




### Models of left / right side opening

X-800P / X-800M support left side open. If user requires right side open, please order X-800P-R / X-800M-R.

Model	Left side open	Right side open
X-800P	✓ Proximity	
X-800M	✓ MiFARE	
X-800P - R		✓ Proximity
X-800M - R		✓ MiFARE

Installation for **Single Point Lock**



While insert the screws to secure the handle with **electrical power screwdriver**, please set the torque **NOT** exceed 8 kgf/cm

1. Mount the smartcard handle to the universal mounting position.
2. Place the ① handle mounting bracket with ② M4 x 9mm screw x 2 to secure the handle.
3. Attach the **Cam** with ③ square hole washer(s) to adjust and to fit the cam locking position. The extension spigot ⑦ required or not for installation is subject to the rack door locking design.  
 Note : - If the cam cannot fit the locking position after adjustment, customization for the cam is required.  
 - Cam customization service upon your request, please contact your sales representative.
4. Insert the ④ M5 x 15mm screw x 1 with circle hole washer to secure the **Cam** to the handle.
5. Place the ⑤ U bracket with ⑥ M3 x 10mm screw x 2 to further secure the handle in place.

**Handle mounting screw set for single point lock**

		Qty.	Single Point Lock
①	Handle mounting bracket	2	✓
②	M4 x 9mm screw for ①	4	✓
③	Square hole washer	6	✓
④	Circle hole washer w/ M5 x 15mm screw	2	✓
⑤	U bracket	2	✓
⑥	M3 x 10mm screw for ⑤	4	✓
⑦	Extensions spigot	2	✓




Pay attention to the following points when install the lock system.  
Otherwise, it may cause handle distortion and malfunction.

1. Make sure
  - ① Cam lock can slide into the hole without stress.
  - ② The cut-out of the cam hole with enough space tolerance.




Cam lock hole  
✓ enough  
tolerance




Cam lock hole  
✗ limited  
tolerance

2. Make sure the rack door is rigid and no bending.




✓ Rigid  
door



✗ Bending  
door

3. Don't over tighten the fixing screws.

Installation for **2 - point Lock** ( light-duty rod-latch )



While insert the screws to secure the handle with **electrical power screwdriver**, please set the torque **NOT** exceed 8 kgf/cm

1. Mount the smartcard handle to the universal mounting position.
2. Place the ① handle mounting bracket with ② M4 x 9mm screw x 2 to secure the handle.
3. Attach the **Rod-latch** with ③ square hole washer(s) to adjust and to fit the door top & bottom locking position.
4. Insert the ④ M5 x 15mm screw x 1 with circle hole washer to secure the **Rod-latch** to the handle.
5. Place the ⑤ U bracket with ⑥ M3 x 10mm screw x 2 to further secure the handle in place.


**Handle mounting screw set for 2-point lock ( light-duty )**

		Qty.	2-Point Lock light-duty
①	Handle mounting bracket	2	✓
②	M4 x 9mm screw for ①	4	✓
③	Square hole washer	6	✓
④	Circle hole washer w/ M5 x 15mm screw	2	✓
⑤	U bracket	2	✓
⑥	M3 x 10mm screw for ⑤	4	✓
⑦	Extensions spigot	2	X




Pay attention to the following points when install the lock system.  
Otherwise, it may cause handle distortion and malfunction.

1. Make sure
  - ① Two ends of latch rod can entry into the top & bottom holes without stress.
  - ② The top & bottom holes with enough space tolerance.




2-point lock holes  
( top & bottom )  
✓ enough  
tolerance




2-point lock holes  
( top & bottom )  
✗ limited  
tolerance

2. Make sure the rack door is rigid and no bending.




✓ Rigid  
door



✗ Bending  
door

3. Don't over tighten the fixing screws.

Installation for **2 - point Lock** ( rod control system )



While insert the screws to secure the handle with **electrical power screwdriver**, please set the torque **NOT** exceed 8 kgf/cm

1. Mount the smartcard handle to the universal mounting position.
2. Attach the **Rod control system** to the handle and insert the **4** M5 x 15mm screw x 1 with circle hole washer to secure the position.
3. Insert **Original handle screws** x 2 through the **Rod control system** and door to the handle to fix it in place.
4. Place the **5** U bracket with **6** M3 x 10mm screw x 2 to further secure the handle in place.


**Handle mounting screw set for 2-Point Lock ( with rod control )**

		Qty.	2-Point Lock ( with rod control )
<b>1</b>	Handle mounting bracket	2	X
<b>2</b>	M4 x 9mm screw for <b>1</b>	4	X
<b>3</b>	Square hole washer	6	X
<b>4</b>	Circle hole washer w/ M5 x 15mm screw	2	✓
<b>5</b>	U bracket	2	✓
<b>6</b>	M3 x 10mm screw for <b>5</b>	4	✓
<b>7</b>	Extensions spigot	2	X




Pay attention to the following points when install the lock system.  
Otherwise, it may cause handle distortion and malfunction.


1. Make sure
  - ① Two ends of latch rod can entry into the top & bottom holes without stress.
  - ② The top & bottom holes with enough space tolerance.





2-point lock holes  
( top & bottom )



2-point lock holes  
( top & bottom )




2. Make sure the rack door is rigid and no bending.



3. Don't over tighten the fixing screws.

**Important Note for Key lock**

- ⚠ • Under Smartcard mode, always keep key cylinder to 12 o'clock direction.



✗		<b>Key lock mode</b> Key cylinder to <b>9 o'clock direction</b> Under key lock mode, even present the smartcard, the handle still keeps locked.
✗		<b>Key unlock mode</b> Key cylinder to <b>3 o'clock direction</b> Under key unlock mode, the handle keeps unlocked.
✓		<b>Smartcard mode</b> ⚠ For smartcard operation, keep key cylinder always to <b>12 o'clock direction</b> .


- ⚠
- Unless the smartcard handle is defective, lock / unlock the handle by key is NOT recommended
- Please insert & turn the key with push force



		<b>Key lock mode</b> Key cylinder to <b>9 o'clock direction</b> .
		<b>Key unlock mode</b> Key cylinder to <b>3 o'clock direction</b> .



## Maintenance Key ( MK-001 )



- Improper key usage may cause the cylinder stuck at abnormal direction 1 to 2 o' clock.
- Under this circumstance, the **maintenance key (MK-001)** is required to solve the problem.
- Please insert the **maintenance key** to the cylinder with push force for turning it to normal direction 9 or 12 or 3 o'clock.




## Important Note for Handle


For your own safety, please return the handle to park position properly in case reckless collision.




✓ How to unlock the handle & open the door properly




✗ Unlock the handle but NOT open the door



✗ Unauthorized door-open



✓ How to close the door properly



Intentionally  
Left  
Blank

## < 2.4 > Door Sensor Installation Inductive Sensor

### Inductive Door Sensor, pair ( S-DSI )



#### Features


- light weight
- mini size ( 32.5 x 12.2 x 9.2 mm )

#### Requirement

- cabinet frame made of iron
- sensing distance 3mm


#### Package content

- Inductive sensor w/ 2m cable x 2
- 2mm adhesive tape x 6
- Mounting bracket x 2





①	Sensor area
②	Red LED ( light up while door opening )
③	2m cable
④	Cable jack ( connect to handle )

### Mounting by adhesive tape ( no custom cutting required on door )



### Mounting by bundled bracket

- Ø6.5mm hole cutting required on door frame



## Installation steps


- connect to the handle
- guide & fix the cable with cable clips ( bundle with handle package )
- place the sensor at the top of the door, close to the opening side
- adjust the sensor with adhesive tape or mounting bracket to ensure the sensing distance between door to frame within 3mm while door in close status



## Sensor Operation


### DOOR CLOSE

- close door
- inductive sensor detects the cabinet frame
- DOOR CLOSE SIGNAL sends out



### DOOR OPEN

- open door
- inductive sensor lose detection with cabinet frame
- Red LED of sensor light up
- DOOR OPEN SIGNAL sends out



## < 2.4 > Door Sensor Installation **IR Sensor**

### IR Door Sensor, pair ( S-DIR )

#### Features

- Magnetic base for easy setup
- No custom cutting required on doors
- Light weight & mini size ( 33 x 19 x 7 mm )
- 2m cord





#### Requirement

- rack frame made of ferrous metal ( iron )
- sensing distance
- door close : < 40mm
- door open : > 50mm

#### Package content

- IR sensor w/ 2m cable x 2
- reflective label x 2 ( opposite to the IR door sensor for a better response, size: 30 x 40 mm )




①	Sensor area
②	2m cable
③	Cable jack ( connect to handle )

## Installation steps

- connect to the handle
  - guide & fix the cable with cable clips ( bundle with handle package )
  - place the sensor at the top of the door, close to the hinge side
  - adjust the sensor to ensure the sensing distance between door to frame within 5mm while door in close status
  - stick the reflective label on the rack frame just opposite to the sensor position
- door close : < 40mm  
 door open : > 50mm


Suggested sensor position



## Sensor Operation


### DOOR CLOSE


- close door
- IR sensor detects the rack frame
- DOOR CLOSE SIGNAL sends out



### DOOR OPEN

- open door
- IR sensor lose detection with rack frame
- DOOR OPEN SIGNAL sends out



-  sensing distance  
 door close : < 40mm  
 door open : > 50mm

## < 2.4 > Door Sensor Installation Mechanical Sensor


### Mechanical Door Sensor, pair ( S-DSW )

- Low cost / precise
- Size ( 36.3 x 15 x 30.75 mm )
- 2m cord


#### Package content

- Mechanical sensor w/ 2m cable x 2
- Mounting bracket x 2


Top View



Front View



Side View




unit : mm

①	Cable connector
②	Press button ( total travel distance : 9.25 mm ) ( min. actuation distance : 3.00 mm )


### Mounting by custom cutout on door frame

- Cutout size ( 23 x 12.5 mm )



### Mounting by bundled bracket

- Ø6.5mm hole cutting required on door frame




unit : mm



## Installation steps


- connect to the handle
- place the sensor at the top middle of the door
- secure it with mounting screws x 2



## Sensor Operation


### DOOR CLOSE

- close door
- Sensor button is pressed on
- DOOR CLOSE SIGNAL sends out



### DOOR OPEN

- open door
- Sensor button is released
- DOOR OPEN SIGNAL sends out



## < 2.4 > Door Sensor Installation



### Specification

		Inductive Door Sensor	Mechanical Door Sensor
<b>Part no.</b>		<b>S-DSI</b>	<b>S-DSW</b>
<b>Sensitivity</b>	Actuation	/	3.00 mm
	Travelling Distance	/	9.25 mm
	Operating Force	/	3.5±1 N
	Sensing distance	Max. 3mm	/
	Sensing object	Ferrous metal	/
<b>Power Requirement</b>	Voltage	12VDC, powered by sensor port	/
	Current Consumption	100mA	/
<b>Housing</b>	Material	Plastic	
	Color	Black	
<b>Connection</b>	Cable Length	sensor w/ 2m cable	
<b>Environmental</b>	Operating	-20 to 60°C Degree	
	Storage	-20 to 60°C Degree	-30 to 70°C Degree
	Relative Humidity	5~90%, non-condensing	
<b>Dimensions</b>	Product	32.5L x 12.2W x 9.2H mm	52W x 22.5L mm ( with metal plate )
	Packing	/	/
<b>Weight</b>	Net / Gross	6g	14g ( with metal plate )
<b>Supply includes</b>	1	Inductive door sensor with 2m cable	Mechanical door sensor
	2	2mm Adhesive tape	Metal plate
	3	/	2m cable
<b>Compatibility</b>	X-2000 series		
<b>Safety Regulatory</b>	FCC & CE certified		
<b>Environmental</b>	RoHS3 & REACH compliant by SGS		

## < 3.1 > PDU

Under an **InfraSolution X** network, each InfraBox supports **InfraPower** intelligent PDU x 4 in a daisy chain. Each PDU comes with Temp. & Humid. sensor port x 2

**W** series : monitored PDU

**WS** series : switched PDU



**WSi** series : outlet level measurement switched PDU



Please visit below link to select desired PDU & download the PDU drawing & specifications.

[http://www.austin-hughes.com/solutions/intelligent-kWh-pdu.html#Single\\_Phase](http://www.austin-hughes.com/solutions/intelligent-kWh-pdu.html#Single_Phase)

### InfraBox



Max. daisy chain distance from InfraBox to the 4th PDU up to 80M


### PDU level setting :

For details about PDU level setting ( meter with 1.8" LCD ), please refer to IPM-04 user manual < 1.2 > Meter Reading & Setting : [www.austin-hughes.com/UM-IPM-04-1P-WMeter](http://www.austin-hughes.com/UM-IPM-04-1P-WMeter)

For details about PDU level setting ( meter with 2.8" touch LCD ), please refer to IPM-04 user manual < 1.3 > Meter ( PDU ) Cascade : [www.austin-hughes.com/UM-IPM-04-1P-3Meter](http://www.austin-hughes.com/UM-IPM-04-1P-3Meter)

## < 3.2 > Fan Unit

Under an **InfraSolution X** network, each InfraBox supports **InfraCool** remote fan unit x 2 in a daisy chain. Each fan unit comes with TEMP. sensor port x 1




### Fan unit level setting :

Please follow the steps below to set the daisy chain level for expansion fan units

Step 1. Press and hold the “**1**” button for 5 seconds.

Step 2. Press **◀** or **▶** arrow button to set the daisy chain level




### Audio alarm setting :

Please follow the steps below to setup each FAN unit audio alarm

Step 1. Press and hold the “**2**” button for 5 seconds.

Step 2. Press **◀** or **▶** arrow button to enable / disable the audio alarm



**Warning:** If enable the audio alarm, the buzzer will sound when the outside temperature is over the preset alarm temperature.

## Fan Specification :

<b>Expansion Serial Fan</b>	Model	<b>RF-1.6 / 1.9</b>	<b>RF-33.9</b>
	No. of Fan	6 / 9	9
	Mounting	1U	Door mount
	CFM Level	Normal / High / Max.	
	Individual Fan ON / OFF	Yes	
	Individual Fan CFM	108 CFM	
	Unit CFM ( Approximately )	324 / 648 / 972 CFM	972 CFM
	IP Remote Access	Not available, must be via Master IP fan on the 1st level	
	Daisy Chain Level	For Level 2 - 16	
	MTBF	50,000 hrs	
	Individual Fan Noise Level	41 dB	

<b>Temperature Sensor</b>	Temperature Port	1 x temperature sensor port ( sensor bundled )
	Measurement Range	0 to 99.9°C
	Measurement Accuracy	+/- 1.5%
	Temperature Alarm	Yes

<b>Power</b>	Input	Auto sensing, 100V or 240V AC at 50 or 60Hz via IEC cord	
	Consumption	20W / 40W / 60W	60W

<b>Environmental Conditions</b>	Operating	0 to 50°C
	Storage	-5 to 60°C
	Relative Humidity	90%, non-condensing
	Shock	50G peak acceleration ( 11ms, half-sine wave )
	Vibration	58~100Hz / 0.98G ( 11ms / cycle )

<b>Dimensions</b>	Model	Product Dimension	Packing Dimension
	<b>RF-1.6</b>	480 x 458.3 x 43.5 mm 18.9 x 18 x 1.71 inch	550 x 550 x 120 mm 21.7 x 21.7 x 4.7 inch
	<b>RF-1.9</b>	480 x 623.3 x 43.5 mm 18.9 x 24.5 x 1.71 inch	550 x 730 x 120 mm 21.7 x 28.7 x 4.7 inch
	<b>RF-33.9</b>	195 x 42.9 x 1466 mm 7.7 x 1.7 x 57.7 inch	263 x 106 x 1650 mm 10.4 x 4.2 x 65.0 inch

<b>Weight</b>	Model	Net Weight	Gross Weight
	<b>RF-1.6</b>	6.8 kgs / 15 lbs	8 kgs / 17.6 lbs
	<b>RF-1.9</b>	9 kgs / 19.8 lbs	11 kgs / 24.2 lbs
	<b>RF-33.9</b>	5 kgs / 11 lbs	7.4 kgs / 16.3 lbs

<b>Casing Color</b>	Black
---------------------	-------

<b>Regulatory</b>	FCC & CE
-------------------	----------

<b>Environmental</b>	RoHS3 & REACH compliant by SGS
----------------------	--------------------------------

## < 4.1 > Temp. & Humidity Sensor

Each InfraBox provides Temp. & Humid. Sensor port x 2. If more TH sensors required, two temp. & humid. sensor ports on each integrated PDU can be applied.



		Temp. & Humid. Sensor	Temp. Sensor
<b>Part no.</b>		IG-TH01-2M	IG-T01-2M
<b>Temperature Sensitivity</b>	Range	0 to 80°C ( 32 to 176°F )	
	Accuracy	±0.5°C typical ( ±1°F )	±1°C ( ±2°F )
	Resolution	0.1°C ( 0.2°F )	
	Response Time	5 to 30 sec	
<b>Relative Humidity Sensitivity</b>	Range	0 to 100% R.H	/
	Accuracy	0 to 100, ±8.0% R.H 20 to 80, ±4.5% R.H.	/
	Resolution	1% R.H.	/
	Response Time	8 sec	/
<b>Power Requirement</b>	Voltage	12VDC, powered by sensor port	
	Current Consumption	20mA	
	Power consumption	0.24 Watt	
	Power on indicator	Red	Green
<b>Housing</b>	Chassis & Cover	Plastic	
	Color	Dark gray	
	Installation	Magnetic base for unrestricted installation	
<b>Connection</b>	Cable Length	TH sensor w/ 2m cable ( standard ) TH sensor w/ 4m cable ( option )	T sensor w/ 2m cable ( standard ) T sensor w/ 4m cable ( option )
	Cable Specification	4-wired 3.5mm to RJ11	
	Cable Color	Black	Beige
<b>Environmental</b>	Operating	0 to 80°C Degree	
	Storage	-5 to 80°C Degree	
	Humidity	0~100%, non-condensing	
<b>Dimensions</b>	Product	30L x 25W x 18H mm	
<b>Weight</b>	Net	66g	
<b>Supply includes</b>	1	TH Sensor	Temperature Sensor
	2	4-wired 3.5mm to RJ11 cable ( 2m, black color )	
<b>Compatibility</b>	InfraPower	W / WS / Wi / WSi series PDU	
	InfraSolution	X-2000 series	
	InfraGuard	EC-300M & EC-300	
<b>Safety Regulatory</b>	FCC & CE certified		
<b>Environmental</b>	RoHS3 & REACH compliant by SGS		

## < 4.2 > Smoke Sensor


Smoke sensor comes with a RED LED. When smoke alarm triggers, the RED LED lights on with beep sound continuously.



		<b>Smoke Sensor</b>
<b>Part no.</b>		<b>IG-S01-1M</b>
<b>Sensitivity</b>	Smoke sensitivity	0.15 ~ 0.3 dB/m
<b>Alarm Output</b>	Solid State Relay	24VDC@1A
	Alarm LED	Red
	Audio Alarm	80 dB
	Audio Alarm Pattern	Continuous beeps
<b>Power Requirement</b>	Voltage	12VDC, powered by sensor port
	Current Consumption	200uA
	Power ON LED	Red LED flashes every 6 seconds
<b>Housing</b>	Chassis & Cover	ABS plastic
	Color	Ivory White
<b>Connection</b>	Cable Length	1m / 3m ( option )
<b>Environmental</b>	Operating	-5 to 50°C Degree
	Storage	-10 to 60°C Degree
	Humidity	5~90%, non-condensing
<b>Dimensions</b>	Product	103L x 103W x 55H mm
<b>Weight</b>	Net	165g
<b>Supply includes</b>	1	Smoke Sensor with 1m cable
<b>Compatibility:</b>	InfraSolution	X-2000 series
	InfraGuard	EC-300M & EC-300
<b>Safety Regulatory</b>	FCC & CE certified	
<b>Environmental</b>	RoHS3 & REACH compliant by SGS	

## < 4.3 > Shock Sensor

Shock sensor comes with a RED LED. When shock alarm triggers, the RED LED lights on continuously.



REACH


		<b>Shock Sensor</b>
<b>Part no.</b>		<b>IG-V01-1M</b>
<b>Sensitivity</b>	Detection radius	3.5 m
	Adjustable sensitivity	Internal micro knob with screwdriver cross slot
<b>Alarm Output</b>	Solid State Relay	12VDC@100mA
	Alarm hold time	Approx. 2.0 sec.
	Alarm LED	Red
<b>Power Requirement</b>	Voltage	12VDC, powered by sensor port
	Current Consumption	15mA
	Power consumption	0.18 Watt
<b>Housing</b>	Chassis & Cover	ABS plastic
	Color	White
<b>Connection</b>	Cable Length	1m / 3m ( option )
<b>Environmental</b>	Operating	-5 to 55°C Degree
	Storage	-10 to 60°C Degree
	Humidity	5~90%, non-condensing
<b>Dimensions</b>	Product	26 x 85 x 24 mm
<b>Weight</b>	Net	40g
<b>Supply includes</b>	1	Shock Sensor with 1m cable
<b>Compatibility</b>	InfraSolution	X-2000 series
	InfraGuard	EC-300M & EC-300
<b>Safety Regulatory</b>		FCC & CE certified
<b>Environmental</b>		RoHS3 & REACH compliant by SGS



## < 4.4 > Water Sensor




**REACH**




		<b>Water Sensor</b>
<b>Part no.</b>		<b>IG-W01-3M</b>
<b>Measurement Range</b>	Measurement Range	Wet or Dry (-20°C to 60°C)
	Rope Sensor Length	5m
<b>Power Requirement</b>	Voltage	5VDC, powered by sensor port
	Power consumption	125 mWatt
<b>Connection</b>	Extension cable length	3m ( non-detection )
<b>Environmental</b>	Operating	-20 to 60°C Degree
	Storage	-20 to 80°C Degree
<b>Weight</b>	Net	450g ( Sensor & extension cable )
<b>Supply includes</b>	1	Rope water sensor
	2	Extension cable
<b>Compatibility</b>	InfraSolution	X-2000 series
	InfraGuard	EC-300M & EC-300
<b>Safety Regulatory</b>	FCC & CE certified	
<b>Environmental</b>	RoHS3 & REACH compliant by SGS	

## < 4.5 > LED Light Bar

Under InfraSolution X software, the LED light bar can be enabled / disabled / always ON.

When the LED light bar is enabled & connected, it will be ON within 10 seconds after the handle lock is released.



		<b>LED Light Bar</b>
<b>Part no.</b>		<b>CLB-IX-002-2M</b>
<b>Light</b>	Color	Cool White
	Output	250 Lumens
	Color Temperature	5600-7000K
	Number of LED	18 High Output CREE SMD LED
	Life Expectancy	30,000 hrs
<b>Power Requirement</b>	Voltage	12VDC, powered by sensor port
	Current Consumption	0.375A
	Power consumption	4.5 Watt
<b>Housing</b>	Chassis	Extruded aluminum with silver powder coat
	Diffuser	Acrylic with milky white
	Installation	Magnetic base for unrestricted installation
<b>Connection</b>	Cable Length	2m / 3m ( option )
<b>Environmental</b>	Operating	-20 to 50°C Degree
	Storage	-20 to 60°C Degree
	Relative Humidity	5~90%, non-condensing
<b>Dimensions</b>	Product	300L x 20W x 12H mm
<b>Weight</b>	Net	84g
<b>Compatibility</b>	InfraSolution	X-2000 series
	InfraGuard	EC-300M & EC-300
<b>Safety Regulatory</b>		FCC & CE certified
<b>Environmental</b>		RoHS3 & REACH compliant by SGS

## < 4.6 > LED Beacon

The LED Beacon can be stuck firmly by the bundled adhesive tape.



REACH

		<b>LED Beacon</b>
<b>Part no.</b>		<b>IG-FB03-1M</b>
<b>Notification</b>	Len Color	Blue
	Light Source	White
	Flash Rate	120 flashes per minute
<b>Power Requirement</b>	Voltage	12VDC, powered by sensor port
	Current Consumption	0.175A
<b>Housing</b>	Cover Len	Polycarbonate
	Color	Blue
<b>Connection</b>	Cable Length	1m / 3m
<b>Environmental</b>	Operating	-20 to 50°C Degree
	Storage	-20 to 60°C Degree
	Relative Humidity	5~90%, non-condensing
<b>Dimensions</b>	Product	72L x 72W x 45H mm
<b>Weight</b>	Net	50g
<b>Supply includes</b>	1	LED Beacon with 1m cable
<b>Compatibility</b>	InfraSolution	X-2000 series
	InfraGuard	EC-300M & EC-300
<b>Safety Regulatory</b>		FCC & CE certified
<b>Environmental</b>		RoHS3 & REACH compliant by SGS

## Network Connection


InfraSolution X provides 3 connection ways - **Daisy Chain**, **Star**, **Mixed**.

Which connection applied is subject to the site scale, environment and users' requirements.

### < 5.1 > Daisy Chain Connect all InfraBoxes by Cat5/6 cable, and no any network switch required

#### Key Benefits


- Simple connection
- No network switch required
- Appropriate for small networks



### < 5.2 > Star Connect to network switch by a point-to-point connection

#### Key Benefits

- Appropriate for large networks
- Increased fault tolerance
- Easy for troubleshooting




# Network Connection

## < 5.3 > Mixed Combining daisy chain with star connection

### Key Benefits

- Most effective and practical for large scale of networks
- Take all advantages of Daisy Chain and Star connection
- Flexible to meet a variety of network environments and needs




# Application

## < 6.1 > Data Center

By mixed connection, InfraSolution X can be scalable up to 3000 racks. X-2000 and X-1000 InfraBoxes can be coexisted in the same network. Users are enabled to manage and remotely access all racks under a centralized and user friendly GUI.

- Connect the 1st InfraBox in each daisy chain to the network switch
- Connect the management PC and client PCs via the network switch
- Up to 3000 Infraboxes / Racks




## < 6.2 > Intelligent Building

It is essential for a Multi-Storey Intelligent Building to be applied with a centralized management system for the building's mechanical and electrical equipment such as security, power, ventilation, and lighting systems, etc.

InfraSolution X system allows equipment to be distributed throughout a building simply by deploying an Ethernet network. To keep capital costs down, InfraSolution X can also be cascaded between boxes up to 100m over a Cat5/6 cable. Signal weakness problem for long distance between InfraBoxes can be solved by applying network hubs with repeater function.

- Connect the InfraSolution X network in each floor via the network ethernet / fiber switch
- Up to 3000 Infraboxes / Racks






## < 6.3 > Remote Site

InfraSolution X can be also applied to the remote site for access and monitoring over IP anytime and anywhere.




InfraSolution X Software License is required for each remote site / management PC






## < 6.4 > Branches

For a global or scalable company, it is vital to remote access and monitor the network of their nationwide and worldwide branches. InfraSolution X provides an ideal solution to keep an eye on rack access security and environmental condition.



## < 7.1 > Tips for System Setup



## < 8.1 > Key Word

### MFP - Master Floor Plan

- An actual cabinet floor plan.
- Only in MFP, you can create cabinet & configure the IP setting for the cabinet.
- If you want to monitor & control cabinets & their devices, you need to build the control area.
- MFP can be more than one. No. of MFP is subject to the site scale & plan by floor, zone, building, branches or remote sites.

### CA Loading

- There is a button in MFP - CA Loading. It is to provide a quick and efficient path for the user to move cabinet to build the control area.

### CA - Control Area

- You can build a Control Area for some specific cabinets which you want to monitor, configure & control.
- All cabinets in the CA should be loaded from the MFP by CA Loading button.
- CA can be more than one. How many CA is subject to your plan.
- CA has 2 modes : Edit mode & View mode.
- Under Edit mode, you can configure not only cabinets but also devices such as PDU, fan unit & sensors.
- View mode is designed for users with limited authority so they can ONLY monitor the status of cabinet & device.

### User Setup

- To build a user list. Afterward, you can use the list to build the user group.
- Each user has his own login name & password for remote system login.
- Each user also has his own smartcard for cabinet access.
- However, before users join a user group in next step, they can do nothing.

### User Group

- You can form a user group from the user list.
- You can define the user group with authority and which control area / areas to monitor & access.
- Each user subordinated to ONLY ONE user group.
- If the user wants to join another user group, a new login name, password & smartcard MUST BE assigned.
- Each user group must select ONE time rule. All group users can access the cabinet and remote system login according to the time period of the selected time rule.
- Without time rule assignment, all group users can do nothing.

### Time Rule


- Time rule is designed for security. It tries to restrict the users with a time period to access the system and cabinet.
- In system setup section < 11.5 >, you can set time rules up to 32.
- Afterward, all time rules will be shown in user group for their selection.
- Only one time rule can be assigned to one user group.

## < 8.1 > Cabinet Icon

### Cabinet Icon layer


Cabinet icon has two layers, the layer one by default shows on all control area under view mode for status monitoring. User can click cabinet icon to switch to layer two.

#### Layer one





- show PDU status ( **P1, P2, P3, P4** )
- if PDU is enabled & connected, **P** icon in WHITE color
- if PDU is enabled BUT disconnected, **P** icon in RED color
- if PDU is on alarm status, **P** icon also in RED color
- if PDU is disabled, **P** icon in GREY color
- show Fan unit status ( **F1, F2** )
- if Fan unit is enabled & connected, **F** icon in WHITE color
- if Fan unit is enabled BUT disconnected, **F** icon in RED color
- if Fan unit is on alarm status, **F** icon also in RED color
- if Fan unit is disabled, **F** icon in GREY color

#### Layer two





- show TH sensor status ( **S1, S2** )
- if TH sensor is enabled & connected, **S1, S2** icon in WHITE color
- if TH sensor is enabled BUT disconnected, **S1, S2** icon in RED color
- if TH sensor is on alarm status, **S1, S2** icon also in RED color
- if TH sensor is disabled, **S1, S2** icon in GREY color
- show smoke & shock sensor status ( **S3, S4** )
- if smoke & shock sensor is enabled & connected, **S3, S4** icon in WHITE color
- if smoke & shock sensor is on alarm status, **S3, S4** icon also in RED color
- if smoke & shock sensor is disabled, **S3, S4** icon in GREY color
- show water sensor status ( **S5, S6** )
- if water sensor is enabled & connected, **S5, S6** icon in WHITE color
- if water sensor is on alarm status, **S5, S6** icon also in RED color
- if water sensor is disabled, **S5, S6** icon in GREY color



### Door direction




### Door status



### Connection status



### Non-configure cabinet



In CA control area, the grey cabinet icon shows that the cabinet has been deleted in master floor plan. The user should remove this non-function cabinet from control area.

## Software Installation & Activation

### < 9.1 > Key Features

InfraSolution X Manager X-ISM is a LICENSED cabinet management software to monitor up to 3000 cabinets remotely.

Each InfraBox connects a pair of smartcard handles to secure the cabinet access control.

Each InfraBox can also connect a variety of sensors to provide an environmental monitoring solution.

To enhance the functionality, up to 12000 x kWh PDU / 6000 x Fan Unit can be monitored through InfraSolution X Manager as well.

Up to 100 concurrent users can access the management software remotely to achieve the demand of multi-user / multi-tasking in nowadays' time sharing data center operation.

### InfraSolution X Manager X-ISM

Features		
<b>Capacity</b>	InfraBox	3000
	Concurrent user	100
<b>System Setup</b>	Backup / Restore Setting	✓
	Time Rule Setting	✓
	Alarm Mail Server Setting	✓
	Audio and Visual Alarm Output Setting	✓
<b>Cabinet Overview</b>	Status of Door, PDU, Sensor & Fan unit	✓
	Door	
	Door open by remote	✓
<b>Sensor</b>	Last door open & close record	✓
	Status Monitoring	✓
<b>Peripherals</b>	Temp-Humid Alarm Threshold Setting	✓
<b>PDU</b>	Energy Consumption kWh / Amp. Monitoring	✓
	Outlet Level Measurement	✓
	PDU Outlet Grouping / Schedule	✓
	Outlet Switch ON / OFF	✓
	Amp. Alarm Threshold Setting	✓
	Amp. Rising / Low Alert Threshold Setting	✓
	Temp-Humid Monitoring	✓
<b>Fan Unit</b>	CFM & Temp. Monitoring	✓
	Unit CFM ( fan speed ) Setting	✓
	Auto CFM Control Setting	✓
	Individual Fan Kit ON / OFF	✓
	Fan Unit ON / OFF	✓
<b>Chart / Event / Reporting</b>	System & Device Event Reporting	✓
	Temp-Humid Line Chart of InfraBox	✓

## < 9.2 > CD Key Box

A licensed software, InfraSolution X Manager X – ISM, is bundled with a CD Key.  
The CD Key Box consists of a software CD and a software license certificate



### SOFTWARE LICENSE CERTIFICATE

ISSUE DATE: <today>

S/N: 2-130812-000000-XMS01

Dear customer:

Thank you for purchasing SOFTWARE from Austin Hughes Electronics Ltd. Please take good care of SOFTWARE CD Key. This LICENSE CERTIFICATE will serve as the main document to prove your legal right to use legitimate software.

Please do not disclose the SOFTWARE CD Key to the unauthorized person.

You may install and use one copy of the SOFTWARE, or in its place, any prior version for the same operating system (O.S.), on a single computer (Management PC).

Please read End User License Agreement (EULA) for more details or visit the link below:

<http://www.austin-hughes.com/index/eula.html>

RESELLER : ABC COMPANY

CONTACT PERSON : Peter Chan

License Information	
Software Model	InfraSolution X Manager X-ISM
CD KEY	XXXXXX-XXXXXX-XXXXXX-XXXXXX-XXXXXX-XXXXXX
NO. OF CLIENTS	10
NO. OF NODES	50

Software download : <http://www.austin-hughes.com/downloads/IPDL/software.html>

Software activation : <http://www.austin-hughes.com/activations>

Technical support : [support@austin-hughes.com](mailto:support@austin-hughes.com)

## < 9.3 > Management PC & Client PC Requirement

### Management PC requirement

Management PC requirement is highly related to the no. of cabinet. Please refer to the table below :

No. of Cabinet	Processor	Memory	Hard Disk	LCD Resolution	No. of days log file kept in database
2 - 200	Quad Core Xeon x 1	4GB	1TB x 2	1660 x 1200, 1600 x 900, 1920 x 1080	31
201 - 500	Quad Core Xeon x 1	8GB	1TB x 2	1660 x 1200, 1600 x 900, 1920 x 1080	31
501 - 1000	Quad Core Xeon x 1	16GB	2TB x 4	1660 x 1200, 1600 x 900, 1920 x 1080	15
Over 1000	Quad Core Xeon x 2	32GB	4TB x 4	1660 x 1200, 1600 x 900, 1920 x 1080	7



- The default service port of web server is 80.
- A dedicated PC to run InfraSolution X Manager X- ISM is recommended.
- If the PC is a notebook computer, the power adapter MUST be plugged in & power ON.
- Make sure the management PC is POWER ON & X-ISM is under operation.  
Otherwise, daily data backup will NOT be proceeded.



To legally access Microsoft server software, a Client Access License ( CAL ) may be required.

For more information, please visit the link below :

<http://www.microsoft.com/licensing/about-licensing/client-access-license.aspx>

### Client PC requirement

Processor	Memory	Hard Disk	LCD Resolution
Dual Core x 1	2GB	500GB	1660 x 1200, 1600 x 900, 1920 x 1080

For better view of cabinet status, an appropriate LCD size is necessary.  
Please refer to the table below :

No. of Cabinet in CA	Preferred LCD Size
2 - 100	21" ( 1920 x 1080 )
101 to 300	46" ( 1920 x 1080 )



## < 9.4 > OS Platform & Web Browser

### OS platform

- MS Windows Server 2008 R2 ( English Edition )
- MS Windows Server 2012 ( Standard Edition )
- MS Windows Server 2016 ( Standard Edition )

### Web browser

- I.E. Version 11.0



Make sure users login the management PC as a member of “ Administrator “ Group before X-ISM installation & execution.

## < 9.5 > Prerequisite before software installation

Components	Windows 2008 server standard, 64bit	Windows 2008 server R2 / 2012	Windows 2012 / 2016 server
Java SE 6 / 7 ( i586 )			
Java SE 6 / 7 ( x64 )	✓	✓	✓
Microsoft Visual C++ 2008 SP1 Redistributable Package ( X86 )		✓	✓
Microsoft Visual C++ 2008 SP1 Redistributable Package ( X64 )	✓	✓	✓



The firewall setting of the management PC MUST be OFF


## < 9.6 > Software Installation

After the InfraBox installation, please follow the steps below to install the

InfraSolution X Manager - Matrix Server



1. Double click the **X-ISM.exe** in software CD come with the CD Key Box and follow the instruction to complete the installation.



click " **Next** "



click " **Install** "



click " **Finish** " ..... **Complete**



The management PC must reboot before proceed to Software Activation

## < 9.7 > Remote Access

After software installation, administrator can turn on firewall of the management PC and set the inbound & outbound rules of firewall.

### **Inbound rules :**

1. Open “ **Control Panel** “
2. Select “ **Windows Firewall** “
3. Select “ **Advanced settings** “
4. Right Click “ **Inbound Rules** “ & select “ **New Rules...** “
5. Select “ **Port** “ & Click “ **Next>** “
6. Select “ **TCP** “ then input “ **80, 4000, 5432, 18081** “ in “ **Specific local ports:** “
7. Select “ **Allow the connection** “ & Click “ **Next>** “
8. Tick all three options & Click “ **Next>** “
9. Input the “ **Name** “ & “ **Description** “ of the port & Click “ **Finish** “

### **Outbound rules :**

1. Open “ **Control Panel** “
2. Select “ **Windows Firewall** “
3. Select “ **Advanced settings** “
4. Right Click “ **Outbound Rules** “ & select “ **New Rules...** “
5. Select “ **Port** “ & Click “ **Next>** “
6. Select “ **TCP** “ then input “ **4001, 4003, 4006, outgoing SMTP port** “ in “ **Specific remote ports:** “
7. Select “ **Allow the connection** “ & Click “ **Next>** “
8. Tick all three options & Click “ **Next>** “
9. Input the “ **Name** “ & “ **Description** “ of the port & Click “ **Finish** “



The port no. of outgoing SMTP port depends on the mail server setting in < 11.2 >


## < 9.8 > Software Activation

After software installation is completed, please follow the steps below to do the software activation

1. Click “ **Start** “ & Select “ **Software Activation or Upgrade** “




2. The “ **Software Activation / Upgrade** “ web page pops up



3. Input “ **CD Key** “ & Click “ **Submit** “. The “ **Installation Key** “ will be generated automatically.



4. Click “ **Activate Online** “ & go to “ **Software Online Activation Centre** “ directly



5. Fill in all necessary information & Click “ **Submit** “. Then Click “ **OK** “ from the pop up window to get the “ **Activation Code** “

**Software Online Activation Center**

Welcome to the Austin Hughes SOFTWARE Online Activation Center!  
In order to begin, you need to fill in the following information and get the Official Valid Activation Code.

For technical support: [support@austin-hughes.com](mailto:support@austin-hughes.com)

\* CD Key : 2B0C03 - 000C44 - 5263A2 - 070113 - E46755 - 3FF2A1  
\* Installation Key : C059D2 - D970EF - 749970 - 029978 - 44C5D7  
\* End User Company Name : ABC Company  
\* End User First Name : Peter  
\* End User Last Name : Chan  
\* End User Email Address : peter.chan@abc.com  
End User Phone Number : 3520 1120  
Date of Purchase : 2013 - 8 - 1  
Reseller : XYZ Company

Please complete all of the required fields ( \* ) above before hitting the Submit button.



6. Input the “ **Activation Code** “ & Click “ **Submit** “ in the “ **Software Activation / Upgrade** “ web page to complete the software activation

If the activation is successful, please input the activation code in the box below and click "Submit".

Activation Code : 3E2048 - 682BF7 - 12343F - 73AADF



7. Once the software activation is completed, the following web page will be displayed.

**Software Activation / Upgrade**

Active CD Key : 2B0C03-000C44-5263A2-070113-E46755-3FF2A1  
Active Installation Key : C059D2-D970EF-749970-029978-44C5D7  
Active Activation Code : 3E2048-682BF7-12343F-73AADF  
Number of User : 12  
Number of Node : 94




..... **Complete**

## < 9.8 > Software Activation

### Operation Setup

After the software is activated, user can follow below steps to access the management PC and InfraSolution X Manager – Matrix Server

1. Open the web browser of remote client PC
2. Enter “ *http:// ManagementPC IP address/RMS\_2013/RMS\_2013.html* “
3. Enter the login name & password



The image shows a web browser login dialog box. The title bar reads "Login". There are two input fields: "User Name:" and "Password:". Below the fields is an "OK" button.

Default login name : admin



Default login password : admin

## < 10.1 > Cabinet Alignment

In MFP & CA, the system provides alignment function for user to arrange the cabinet in a neat way



### Alignment - Left

1. Press < Shift > to select the 3 highlighted cabinets
2. Release < Shift >
3. Press < Align Left >



### Alignment - Center



1. Press < Shift > to select the 2 highlighted cabinets
2. Release < Shift >
3. Press < Align Center >



## < 10.1 > Cabinet Alignment


### Alignment - Right

1. Press < Shift > to select the 2 highlighted cabinets
2. Release < Shift >
3. Press < Align Right >



### Alignment - Top



1. Press < Shift > to select the 5 highlighted cabinets
2. Release < Shift >
3. Press < Align Top >






### Alignment - Middle

1. Press < Shift > to select the 5 highlighted cabinets
2. Release < Shift >
3. Press < Align Middle >



### Alignment - Bottom

1. Press < Shift > to select the 5 highlighted cabinets
2. Release < Shift >
3. Press < Align Bottom >



## < 10.2 > MFP - Master Floor Plan


- An actual cabinet floor plan.
- Only in MFP, you can create cabinet & configure the IP setting for the cabinet.
- If you want to monitor & control cabinets & their devices, you need to build the control area.
- MFP can be more than one. No. of MFP is subject to the site scale & plan by floor, zone, building, branches or remote sites.



Ensure ONLY one user configures the cabinet IP in the same MFP at the same time

### Add MFP

1. Click “ **MFP** ” tab
2. Click “ **Add** ”
3. Input the MFP title & Description  
( min. 1 char / max. 32 char )
4. Click “ **OK** ” to finish



**Add New Master Floor Plan**

MFP Title: Zone A 37/F

MFP Description: Data Centre 01

OK Cancel

### Edit MFP

1. Select the MFP you want to edit
2. Click “ **Edit** ”
3. Edit the MFP title / Description
4. Click “ **OK** ” to finish



**Edit Master Floor Plan**

MFP Title: Zone A 37/F

MFP Description: Data Center 01

OK Cancel

## Add Cabinet

1. Select the MFP you want to add cabinet (s)
2. Click  to add cabinet. ( 1 / 5 / 10 cabinets at one time )
3. Click  & Click “ **Yes** ” to confirm cabinet addition

## Cabinet IP configuration


1. Select a cabinet
2. Input : “ **Cabinet No.** ” ( min 4 char / max. 16 char. ),  
“ **Title 1** ” ( min. 2 char / max. 8 char ),  
“ **Title 2** ” ( min. 2 char / max. 8 char ),  
“ **IP address** ”, Enable / Disable the email & audio alarm  
  
( If email alarm is “ **Disable** ” , NO alarm email will be sent to user. )
3. Click “ **Save** ” to finish the cabinet IP configuration



Repeat step 1 to 3 for all cabinets ONE BY ONE.

Once the cabinet is configured, the IP address CANNOT BE edited.

Users need to delete cabinet in the MFP & create a new one.



Cabinet Configuration

Cabinet Details:

Cabinet No: Cabinet 001

Title 1: Zone A

Title 2: 30/F

IP Address: 138.168.1.1


Alarm: Enable

Email: Enable


Audio: Enable

Save

## Delete Cabinet

1. Select the cabinet you want to delete in the MFP
2. Click  & Click “ **Yes** ” to confirm the cabinet deletion


## Delete MFP




1. Select the MFP you want to delete
2. Select all cabinets in the MFP to clear first
3. Click  & Click “ **Yes** ” to confirm to clear all cabinet
4. Then select the MFP & Click “ **Delete** ”
5. Click “ **Yes** ” in the confirmation window to confirm MFP deletion

## < 10.3 > CA - Control Area

- You can build a Control Area for some specific cabinets which you want to monitor, configure & control.
- All cabinets in the CA should be loaded from the MFP by CA Loading button.
- CA can be more than one. How many CA is subject to your plan.
- CA has 2 modes : Edit mode & View mode.
- Under Edit mode, you can configure not only cabinets but also devices such as PDU, fan unit & sensors.
- View mode is designed for users with limited authority so they can ONLY monitor the status of cabinet & device.


### Add CA

1. Click “ **Control Area** ” tab
2. Click “  ” & input the login password in validation window to enter “ **Edit Mode** ”
3. Click “ **Add** ”
4. Input the CA title & Description ( min. 1 char / max. 32 char )
5. Click “ **OK** ” to finish CA addition




### Load Cabinet

1. Go back to “ **MFP** ” tab
2. Select the MFP where the cabinet( s ) you want to load to CA
3. Click “ **CA loading** ”
4. You can load whole MFP cabinets or part of them by tick
5. In “ **Cabinet Orientation** ”, you can select Normal if the rear door at bottom side, or select Inverted if the rear door at top side
6. Click “ **Load** ” button to finish CA loading.



## Edit CA

1. In < **CA – Edit Mode** >, select the CA you want to edit
2. Click “ **Edit** “
3. Edit the CA title / Description
4. Click “ **OK** “ to finish




Edit Control Area	
CA Title:	Zone A ABC Company
CA Description:	37/F Data Centre 01
OK Cancel	

## Delete CA

1. In < **CA – Edit Mode** >, select the CA you want to delete & Click “ **Delete** “
2. Click “ **Yes** “ in the confirmation window
3. Input login password in validation window to confirm CA deletion

## Remove Cabinet from CA

### Cabinet removal from CA

1. In < **CA – Edit Mode** >, select the CA you want the cabinet(s) to be removed
2. Select the cabinet(s)
3. Click “  “
4. Click “ **Yes** “ in the confirmation window to confirm the cabinet removal

## < 10.4 > User Setup

- To build a user list. Afterward, you can use the list to build the user group.
- Each user has his own login name & password for remote system login.
- Each user also has his own smartcard for cabinet access.
- However, before users join a user group in next step, they can do nothing.

### Add User

1. Click “ **User Setup** ” tab
2. Click “ **Add** ”
3. In the user window, please input all the fields.
4. If you want to receive device alarm email, tick “ **Email Alert** ” ( Default : untick )
5. If you want to suspend the user authority and access temporarily, tick “ **User Suspended** ” ( Default : untick )
6. Then click “ **Save** ” to finish

The screenshot shows a 'User' setup window with the following fields and options:

- First Name: Peter
- Last Name: Chan
- Title: IT Manager
- Staff ID: 12345678
- Dept: MIS
- Phone: ( 852 ) 3310 0700
- Mobile: ( 852 ) 6789 5600
- Email: Peter.Chan@abc.com
- Company: ABC Company
- Smart Card No.: 10809901
- Issue Date: 2013-08-15
- Expiry Date: 2015-08-14
- Login Name: Peter
- New Password: ••••••••
- Confirm Password: (empty)
- Enforce to change password in next login
- Email Alert (circled in red with a circled '4')
- User Suspended (circled in red with a circled '5')

Buttons: Save, Cancel

### Edit User

1. Select the user you want to edit
2. Click “ **Edit** ” in “ **User Details** ” window
3. Edit the field ( s ) you want
4. Click “ **Save** ” & Click “ **Yes** ” in the confirmation window to confirm user edition.

### Delete User


1. Select the user you want to delete
2. Click “ **Delete** ” in “ **User Details** ” window & Click “ **Yes** ” in the warning window to confirm user deletion

## < 10.5 > Group Setup

- You can form a user group from the user list.
- You can define the user group with authority and which control area / areas to monitor & access.
- Each user subordinated to ONLY ONE user group.
- If the user wants to join another user group, a new login name, password & smartcard MUST BE assigned.
- Each user group must select ONE time rule. All group users can access the cabinet and remote system login according to the time period of the selected time rule.
- Without time rule assignment, all group users can do nothing.

### Add group

1. Select the Group Profile where a group you want to add
2. Click “ Add “
3. Input the Group Title & Description ( min. 1 char / max. 32 char )
4. Click “ OK “ to finish




**Add User Group**

Title: Zone A 37/F Admin


Description: 37/F Data Center 01

OK Cancel



### Edit group

1. Select the group title you want to edit
2. Click “ Edit “
3. Edit the Title / Description
4. Click “ OK “ to finish



**Edit User Group**

Title: Zone A 37/F Admin



Description: 37/F Data Center 01


OK Cancel

## < 10.5 > Group Setup

### Assign group authority

To assign authority to User group, please take the steps below :

1. Select the group
2. Click “ **Edit** ”
3. Tick the user( s ) you want to assign to the group
4. Tick the Control Area( s ) you want the group to control & monitor
5. Assign appropriate “ **Setup** ” , “ **Device Configuration** ” , “ **System & Device Log** ” authority to the group
6. Select one of the time rule in “ **Time Access Setting for User Group:** ”
7.  Tick “ **SmartCard Access** ”, otherwise the group user CANNOT access the cabinets by smartcard ( Default : untick )
8.  If you want the group user can NOT access the software out of the time rule, please tick “ **Remote System Login** ” ( Default : untick )
9. Click “ **Save** ” & “ **Yes** ” in the warning window to finish Group authority assignment



The screenshot displays the 'Group Setup' interface. On the left, a tree view shows the 'AAA' group selected under the 'Administrator Profile' category. The main area is divided into several sections:

- User(s)** (3): A list of users with checkboxes. 'Operator' and 'richard1' are checked.
- Control Area(s)** (4): A list of control areas with checkboxes. 'XYZ Company Zone A3' and 'XYZ Zone B1' are checked.
- Authority Category** (5): Three sub-sections: 'Setup' (checked: Master Floor Plan, Control Area (View mode only), Control Area (Edit & View mode), User Setup, Group Setup, Visitor), 'Device Configuration' (checked: Door Remote Open, PDU, Sensors, Fan, MF T/H Sensors), and 'System & Device Log' (checked: User Activity, System Setup, MFP, Control Area, User, User Group).
- Time Access Setting for User Group:** (6) A dropdown menu set to 'Working hours'.
- Applied to:** (7) 'Smart Card Access' is checked. (8) 'Remote System Login' is unchecked.

Buttons for 'Save' and 'Cancel' are located at the bottom right.

### Delete group

1. Select the group you want to delete
2. Click “ **Delete** ” & Click “ **Yes** ” to finish.



The deleted group's users will be moved to the unassigned user list simultaneously.



## < 10.6 > Visitor

### Add Visitor

1. Go to “ **Visitor** ” tab
2. Click “ **Add** ”
3. Input all the fields in the following window
4. Tick the cabinet( s ) to allow visitor to access by smartcard
5. Tick “ **Visitor Card Activate** ” to activate the smartcard to access the cabinets under a specific time period
6. Click “ **Save** ” to finish Visitor addition

The screenshot shows a 'Visitor' form with the following fields and values:

- First Name: Peter
- Last Name: Chan
- Phone: (852) 2901 3322
- Mobile: (852) 6754 3112
- Email: peter.chan@abc.com
- Company: ABC Company
- Address 1: Rm 2011, 20/F
- Address 2: Tai Yau Building, Wan Chai, HK
- Visitor Card No.: 10809344
- Effective Date: 2013-08-16
- Time: 14:00
- Expiry Date: 2013-08-16
- Time: 18:00

The 'Add cabinet' section shows a tree view with the following items:

- walker
- XYZ Zone B1
- XYZ Company Zone A3
- ABC Company Zone A1
- ABC Company Zone A2 (selected)
- 13816811 (checked)
- Rack024 (checked)
- Rack025 (checked)

The 'Visitor Card Activate' checkbox is checked. The 'Save' and 'Cancel' buttons are at the bottom.

### Edit Visitor

1. Select the visitor you want to edit
2. Click “ **Edit** ” in “ **Visitor Details** ” window
3. Edit the field( s ) you want
4. Click “ **Save** ” & Click “ **Yes** ” to finish

### Delete Visitor

1. Select the visitor you want to delete
2. Click “ **Delete** ” in “ **Visitor Details** ” window & Click “ **Yes** ” to finish

## System Setup

In System Setup tab, it provides the following settings which apply to the whole system.

- ( 1 ) Backup & Restore
- ( 2 ) Alarm Setting, Mail Server Setting, Audio Visual Alarm
- ( 3 ) Temperature unit
- ( 4 ) Door opening overdue setting
- ( 5 ) Time Rule

The screenshot displays the 'System Setup' web interface, organized into three main columns:

- Backup:** Includes fields for 'Backup File Path' (C:\RackMgt\_v2\data\_backup\), 'Keep the log for this number of days' (14), a threshold for stopping the backup process (90), and a 'Restore File' section with an 'Upload' button.
- Alarm Setting:** Features checkboxes for 'Email alert' (checked) and 'Audio alert' (unchecked).
- Temperature unit:** Offers radio buttons for 'Celsius(°C)' (selected) and 'Fahrenheit(°F)'.
- Handle Setting:** Includes a 'Door Overdue' field set to 30 minutes.
- Time Rule:** Contains a 'Setup' button.
- Mail Server Setting:** Configures SMTP details: host (smtp.gmail.com), port (587), authentication (checked), username (infrasolutionx@gmail.com), password (masked), and security (tls). It also sets default email addresses and the user name (X-ISM Email ALARM).
- Audio Visual Alarm:** A table defining alarm events and their corresponding actions.

Sensor Event	Buzzer	Beacon	Alarm out
S1 (T / TH 1) temp. / humid. alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S2 (T / TH 2) temp. / humid. alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S3 Smoke alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S4 Shock alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S5 (Water1) alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S6 (Water2) alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>


A 'Save' button is located at the bottom center of the interface.

## < 11.1 > Backup & Restore

### Backup

You can set

- the backup path of device configuration & system setting
- the time period the system & event log kept in the system
- the drive space used in term of percentage before the backup process STOP



**Backup**

Backup File Path:

Keep the log for this number of days:

All backup process will be stopped if the backup drive reach this threshold:



Those event log over the defined time period will be saved as CSV format which located at “ **Backup File Path** ” \logbackdist folder


The system setup backup file will be saved in the “ **Backup File Path** ” \sysbackdist folder

### Restore



Restore MUST BE done at the management PC side NOT client side


1. Click “ **Upload** ” button



Restore File:



2. Click “ **Browse** ” to select the file you want to restore



**Backup & Restore**

This will reset your System Setup Setting back to setting of restore file.


**NOTE:**  
This will take a few moments. Please **DO NOT** close the browser until the process had been completed.

Restore File:




## < 11.1 > Backup & Restore

3. Select the file & Click “ Open “



4. Click “ Submit “ to start to restore. When restore is completed, “ Restore succeeded “ will be displayed in the web page



..... Complete



After system restore, users need to activate the software again if the backup file is from a different management PC

## < 11.2 > Alarm Setting / Mail Server Setting / Audio visual Alarm

### Alarm Setting

System will send out device alarm email to user if enable " Email Alert "

#### Alarm Setting

Email alert

Audio alert

Default : Untick

### Mail Server Setting

It is used to setup the sender account to send out the device alarm email to the user

#### Mail Server Setting

smtp host:

smtp port:

smtp auth

smtp username:

smtp password:

smtp secure:

Default mail from address:

Default mail from user name:

### Audio Visual Alarm

Enable or disable " Buzzer " , " Beacon " & " Alarm out " .

By this setting, all sensors under alarm status WILL or WILL NOT trigger audio visual alarm accordingly.

Sensor Event	Buzzer	Beacon	Alarm out
S1 (T / TH 1) temp. / humid. alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S2 (T / TH 2) temp. / humid. alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S3 Smoke alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S4 Shock alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S5 (Water1) alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
S6 (Water2) alarm	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

## < 11.3 > Temperature unit

Select the temperature unit °C / °F displaying in the system

**Temperature unit**

Celsius(°C)

Fahrenheit(°F)

Default : Celsius

## < 11.4 > Door Opening Overdue Setting

Set the door opening overdue time after the cabinet door is open.  
When time overdue, user can view overdue timing with mins in cabinet icon.

**Handle Setting**

Door Overdue:  min(s).

Default : 2 mins  
( Min. 1 min / max. 9999 mins ).

## < 11.5 > Time Rule

- Time rule is designed for security. It tries to restrict the users with a time period to access the system and cabinet.
- In this section, you can set time rules up to 32.
- Afterward, all time rules will be shown in user group for their selection.
- Only one time rule can be assigned to one user group.

1. Click “ **Setup** “ under time rule section
2. Select time rule no. ( 1 - 32 )
3. Edit the “ **Time Rule Name** “
4. Tick the time slot to set date-time period & weekday for the time rule
5. Click “ **Save** “ to finish
6. Repeat step 2 to 5 for other time rules


Time Slot	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
	Sunday	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday
00:00 - 01:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
00:00 - 00:15	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
00:15 - 00:30	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
00:30 - 00:45	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
00:45 - 01:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
01:00 - 02:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
02:00 - 03:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
03:00 - 04:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
04:00 - 05:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
05:00 - 06:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
06:00 - 07:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
07:00 - 08:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
08:00 - 09:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
09:00 - 10:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10:00 - 11:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
11:00 - 12:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
12:00 - 13:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
13:00 - 14:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
14:00 - 15:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
15:00 - 16:00	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

# Operation & Usage

## < 12.1 > Individual Cabinet Devices Enable & Disable

Enter **CA – Edit Mode** to enable / disable individual cabinet sensor & device :  
- TH Sensors / Sensors / PDU / Fan


1. Double click the cabinet icon & show the window below



2. Click “ **Edit** ” in T / H pane

3. Disable if no TH sensors connection ( default : disable )  
OR  
Enable if TH sensor connected and set alarm level


4. Click “ **Apply** ” to finish






## < 12.1 > Individual Cabinet Devices Enable & Disable

5. Click “ **Edit** ” in Sensors pane
6. Disable if no sensors connection ( default : disable )  
OR  
Enable if sensor connected
7. Click “ **Apply** ” to finish




The screenshot shows the 'Sensors' configuration window. It contains several dropdown menus for different sensor types: Water 1, Water 2, Smoke, Shock, LED1, LED2, Beacon, and Alarm out. The 'Water 2' dropdown is currently open, showing three options: 'Disable', 'Enable', and 'Disable'. The 'Apply' button at the bottom right is circled in red.


8. In PDU pane, disable if no PDU connection ( default : disable )  
OR  
Enable if PDU connected



The screenshot shows the 'PDU' configuration window. It contains several fields: Name, Model, Location, Status, Amp, KWh, TH1, and TH2. At the bottom, there is a dropdown menu for 'PDU 1-' which is open, showing three options: 'Disable', 'PDU Disable', and 'Enable'. The 'Apply' button at the bottom right is circled in red.

9. In Fan pane, disable if no Fan connection ( default : disable )  
OR  
Enable if Fan connected
10. Click “ **Save** ” to finish the PDU & Fan section

 When enable or disable PDU & fan,  
the InfraBox will reboot to make the changes effective



The screenshot shows the 'Fan' configuration window. It contains several fields: Name, Model, Position, Status, CFM, and Temp/Alarm. At the bottom, there is a dropdown menu for 'Fan 1-' which is open, showing three options: 'Disable', 'Fan Disable', and 'Enable'. The 'Apply' button at the bottom right is circled in red.

## < 12.2 > Individual Cabinet Door Open by Remote

In Door pane, you can proceed

- door open by remote
- view the record of last door open & close record

**Door**

Front:

Status: Handle locked remotely, door close.

Last user: kenny

Opened: 2013-08-19 14:45:31

Closed: 2013-08-19 14:46:13

Duration: 00day 00h 00m 42s.

Rear:

Status: **Unauthorized open**

Last user: Anonymous User

Opened: 2013-08-19 14:47:07

Closed: 2013-08-19 14:47:34

Duration: 00day 00h 00m 27s.

## < 12.3 > Individual Cabinet PDU Configuration & Control

In PDU pane, Click “ **PDU Details** ” to go to PDU Details page

**PDU**

PDU 1-

Name: Rack 018 WSi01

Model: V8UK/4C13/2C19-32A-WSi

Location: Rack 018 WSi

Status: Connected

Amp: 0.6

KWh: 10.33

TH1: --- °C / 35.0 °C , --- % / 65 %

TH2: --- °C / 35.0 °C , --- % / 65 %

Buttons: Enable, **PDU Details**, TH Status

In “ **PDU Details** ”, you can

- Change “ **Name** ” & “ **Location** ” of PDU
- Change “ **Alarm amp.** ”, “ **R. alert amp.** ” & “ **Low alert amp.** ” of PDU’s circuits
- Click “ **Save** ” to finish
- Click “ **Reset** ” to reset peak amp. & kWh of PDU’s circuits
- Click “ **On / Off** ” to switch on / off PDU’s outlet ( Switched PDU models only )

**XYZ Zone B1 - Rack 018 - PDU Details**

PDU Level: 03 V24C13-32A-WSi      PDU kWh: 0.00

Status: Connected      PDU load amp: 0.0

Name: Rack 18 23C13WSI      Power Factor: 0.4

Location: Rack 18 23C13WSI      App Power (KVA): 0.03

---

**Circuit A**      **Circuit B**

Max. amp: 16.0      Load amp: 0.0      Max. amp: 16.0      Load amp: 0.0

Alarm amp: 13.0      R.alert amp: 0.0      Low alert amp: 0.0      Alarm amp: 13.0      R.alert amp: 0.0      Low alert amp: 0.0

Peak amp: 0.0 2013-08-15 11:12:24      Reset      Peak amp: 0.1 2013-08-12 18:22:50      Reset

kWh: 0.0 2013-08-07 14:03:55      Reset      kWh: 0.0 2013-08-07 14:04:01      Reset

---

**Circuit A Outlets**      **Circuit B Outlets**

Outlet	Name	Amp/Load/Alarm/R.alert/Low al...	kWh	Status	Switch
01	outlet_name_01	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
02	outlet_name__#02	0.0 / 10.0 / 0.0 / 0.0	0.0	Off	On
03	outlet_name__#03	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
04	outlet_name__#04	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
05	outlet_name__#05	0.0 / 10.0 / 0.0 / 0.0	0.0	Off	On
06	outlet_name__#06	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
07	outlet_name__#07	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
08	outlet_name__#08	0.0 / 10.0 / 0.0 / 0.0	0.0	Off	On
09	outlet_name__#09	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
10	outlet_name__#10	0.0 / 10.0 / 0.0 / 0.0	0.0	On	Off
13	outlet_name__#13	0.0 / 5.0 / 0.0 / 0.0	0.0	On	Off
14	outlet_name__#14	0.0 / 5.0 / 0.0 / 0.0	0.0	On	Off
15	outlet_name__#15	0.0 / 5.0 / 0.0 / 0.0	0.0	On	Off
16	outlet_name__#16	0.0 / 5.0 / 0.0 / 0.0	0.0	On	Off
17	outlet_name__#17	0.1 / 5.0 / 0.0 / 0.0	0.02	On	Off
18	outlet_name__#18	0.1 / 5.0 / 0.0 / 0.0	0.02	On	Off
19	outlet_name__#19	0.1 / 5.0 / 0.0 / 0.0	0.0	On	Off
20	outlet_name__#20	0.1 / 5.0 / 0.0 / 0.0	0.04	On	Off
21	outlet_name__#21	0.0 / 5.0 / 0.0 / 0.0	0.0	On	Off
22	outlet_name__#22	0.0 / 5.0 / 0.0 / 0.0	0.0	On	Off

Buttons: Save

## < 12.3 > Individual Cabinet PDU Configuration & Control

In “ **PDU Details** “ , you can Click outlet icon to go to Outlet Setting page

In “ **Outlet Setting** “ , you can

- Change the “ **Name** “ of PDU outlet
- Change “ **Power up sequence delay** “ of PDU outlet ( Switched PDU models only )
- Change “ **Alarm amp.** “ , “ **R. alert amp.** “ & “ **Low alert amp.** “ of PDU outlet ( Outlet level measurement PDU models only )
- Click “ **Save** “ to finish
- Click “ **Reset** “ to reset peak amp. & kWh of PDU outlet ( Outlet kWh Switched PDU only )

**Demo - Cabinet 014 - PDU Details - Outlet Setting**

PDU level: 01 V16C13/4C19-32A-WSi  
 Status: Connected  
 Name: WSi Switched  
 Location: Cabinet 014

Outlet: 01

Outlet Name: outletname01  
 Outlet Status: On  
 Power up sequence delay: 1 (Min. 1, Max. 10 Seconds)

Load amp: 0.0  
 Alarm amp: 5.0  
 R.alert amp: 0.0  
 Low alert amp: 0.0

Peak amp: 8.5 2013-08-13 17:52:40 (Reset)  
 kWh: 0.59 2013-08-07 16:45:58 (Reset)

**Save**

To configure the TH sensors of PDU, you can Click “ **View** “ button in “ **TH Status** “ to go the TH Setting page

**XYZ Zone B1 - Rack 018 - PDU Details - TH Status**

PDU		TH1		TH2			
Level	Name	Location	Temp / Alarm (°C)	Humd / Alarm (%)	Location	Temp / Alarm (°C)	Humd / Alarm (%)
01	Rack 018 WSi01	THSen_#1	--- / 35.0	--- / 65	THSen_#_2	--- / 35.0	--- / 65
02	Rack 018 WSi_02	THSensor_#1_loc	--- / 35.0	--- / 65	THSensor_#2_loc	--- / 35.0	--- / 65
03	Rack 18 23C13WSi	Rack 18 PDU 3	24.6 / 99.9	54 / 99	THSensor_#2_loc	--- / 35.0	--- / 65
04	Rack 18#_C13WSi	Rack 18 PDU 4	--- / 35.0	--- / 65	THSensor_#2_loc	--- / 35.0	--- / 65

In “ **TH Setting** “ , you can

- Activate / Deactivate TH sensors of PDU
- Change “ **Location** “ , “ **Alarm Setting** “ of TH sensors
- Click “ **Save** “ to finish

**XYZ Zone B1 - Rack 018 - PDU Details - TH Status - TH Setting**

PDU Level: 01 V8UK/4C13/2C19-32A-WSi  
 Status: Connected  
 Name: Rack 018 WSi01  
 Location: Rack 018 WSi

**TH 1**  
 Status:  Activate  Deactivate  
 Location: THSen\_#1

Alarm Setting: Temp. (°C): 35.0, Humid. (%): 65  
 Reading: ---

**TH 2**  
 Status:  Activate  Deactivate  
 Location: THSen\_#\_2


Alarm Setting: Temp. (°C): 35.0, Humid. (%): 65  
 Reading: ---

**Save**

- DO NOT activate T or TH sensor if no sensor installed.  
 - When install T or TH sensor, please tick activate. Otherwise, no readings display.

## < 12.4 > Individual Cabinet Fan Unit Configuration & Control

In Fan pane, Double Click “ **Fan Details** ” to go to Fan Details page



**Fan**

Fan 1-

Name: Rack 22

Model: RF-1.3 1U Fan Tray

Position: Top

Status: Connected


CFM: LOW

Temp/Alarm: DISABLED

Enable  **Fan Details** Temp Settings

In “ **Fan Details** ” , you can

- Change “ **Name** ” & “ **Position** ” of Fan unit
- Change “ **Unit CFM** ”
- Click “ **Save** ” to finish
- Switch ON / OFF Fan unit



**XYZ Zone B1 - Rack 018 - Fan Details**

Fan unit level: 02 RF-1.3 1U Fan Tray

Status: Connected Unit switch:

Name:  Unit CFM:

Position:

Fan	Status	Switch
01	OFF	<input type="button" value="ON"/>
02	OFF	<input type="button" value="ON"/>
03	OFF	<input type="button" value="ON"/>

## < 12.4 > Individual Cabinet Fan Unit Configuration & Control

In Fan pane, Double Click “ **Temp Settings** ” to go to Temp Settings page.

You can

- Activate / Deactivate Temp. sensor
- Change “ Position ” of Temp. sensor
- Enable / Disable Auto CFM Control
- Change the “ **Alarm** ” of Temp. sensor
- Click “ **Save** ” to finish

XYZ Zone B1 - Rack 018 - Temp Settings

Fan unit level: 02 RF-1.3 1U Fan Tray  
Status: Connected  
Name: Rack 22  
Position: Front\_top

**Temp. sensor**

Status:  Active  Deactivate  
Position: Front\_top  
Auto CFM Control:  Enable  Disable  
Temp. (°C): 22.5  
Alarm (°C): 99.9

- DO NOT activate temp. sensor if no sensor installed. Otherwise, temp. sensor disconnection event will be triggered.

- When install temp. sensor, please tick activate. Otherwise, no readings display.

- When temp. alarm triggers:

1. All individual fans will change to Max. speed if auto CFM is enabled.
2. If the temp. drops under the alarm temp. MINUS 2C with 10 mins, the buzzer will not sound.

Save

## < 12.5 > Console Message

In the bottom side of the web page, you can view the console message pane.

All action related to the cabinet doors will be shown in this area.

Event	IP address	Description
2013-08-21 15:53:04 +08:00	138.168.1.18	In Cabinet 018(138.168.1.18), Front Handle was unlocked remotely by richard

To collapse and hide the console message pane, Click 


To expand and display the console message pane , Click 

## < 12.6 > PDU Outlet Grouping

PDU Outlet Grouping is a feature which you can assign different PDUs for scheduled outlet ON / OFF / Reboot. Each PDU CAN ONLY BE ASSIGNED to one PDU Outlet Grouping. In each PDU Outlet Grouping, there are 6 outlet ON / OFF / Reboot schedules on Once, Daily & Weekly basis

To add a PDU outlet grouping, please follow the steps below:


1. Click “ **PDU Outlet Grouping** ” Tab
2. Click “ **Add** ”



The screenshot shows the 'PDU Outlet Grouping' configuration page. The 'Add' button in the 'Outlet Grouping' sidebar is circled in red. The main area contains the following fields and sections:

- Outlet Grouping Title**
- Group Name: [Text Field]
- Description: [Text Field]
- Schedule: [Dropdown Menu]
- Status:  Enable  Disable
- Action:  ON  OFF  Reboot
- Time:  Once  Daily  Weekly
- Issue Date: [Date Picker]
- Issue Time: [Time Picker]
- MFP**: [Text Field]
- Circuit A Outlets**: [Table with 'Outlet' column]
- Circuit B Outlets**: [Table with 'Outlet' column]
- Edit** button

3. Input “ **Outlet Group Title** ” & “ **Outlet Group Description** ”
4. Click “ **OK** ” in “ **Add New Outlet Group** ” window to finish



The screenshot shows the 'Add New Outlet Group' dialog box with the following fields:

- Outlet Group Title: Zone A 37/F
- Outlet Group Description: Data Centre 01
- OK** button (circled in red)
- Cancel button

To enable an outlet schedule, please follow the steps below :

1. Select one of the outlet group
2. Click “ **Edit** ”



## < 12.6 > PDU Outlet Grouping

**Outlet Grouping**

Summary Add Edit Delete

Zone A 37/F

**Zone A 37/F**

Group Name: Zone A 37/F  
 Description: Data Centre 01  
 Schedule: 1 Status:  Enable  Disable  
 Action:  ON  OFF  Reboot  
 Time:  Once  Daily  Weekly  
 Issue Date: 2013-01-03  
 Issue Time: 00:00

**MFP**

Assigned List

**Circuit A Outlets**

Outlet

**Circuit B Outlets**

Outlet

Edit

Console Message

3. Select schedule 1
4. Select “ Enable “
5. Select “ Action “ ( ON / OFF / Reboot )
6. Select “ Time “ ( Once / Daily / Weekly )
7. Select “ Issue Date “ & “ Issue Time “

Group Name:  
 Description:  
 Schedule: 1 Status:  Enable  Disable  
 Action:  ON  OFF  Reboot  
 Time:  Once  Daily  Weekly  
 Issue Date:  
 Issue Time:

once

Group Name:  
 Description:  
 Schedule: 1 Status:  Enable  Disable  
 Action:  ON  OFF  Reboot  
 Time:  Once  Daily  Weekly  
 Issue Time:


Daily

Group Name:  
 Description:  
 Schedule: 1 Status:  Enable  Disable  
 Action:  ON  OFF  Reboot  
 Time:  Once  Daily  Weekly  
 Issue Weekday:  
 Issue Time:

Weekly




8. Select the PDU you want to add to this schedule by Clicking “ **Unassigned List** ” > “ **MFP** ” > “ **Cabinet** ” > “ **PDU** ” in MFP pane




If the PDU already assigned to another outlet schedule in the same outlet grouping, you can select the PDU in the “ **Assigned List** ”

9. Tick the outlet of the selected PDU for the schedule
10. Repeat step 9 for outlet ( s ) of other PDU ( s ) you want to add to the same schedule
11. Click “ **Save** ” to finish



12. Repeat Step 2 to 11 for other schedules if necessary

 If the outlet schedule is “ **Once** ”, the schedule will be disabled automatically once the action is completed. To cancel the outlet schedule, select “ **Disable** ” of the selected schedule & Click “ **Save** ” to finish

## < 12.7 > Device & System Event Log

In “ **Log** “ tab, it provides device & system events for you to view, print or export in CSV format.

Device event log includes:

- Cabinet
- Door Access
- Fan
- PDU
- Sensors
- T / H Sensor

System event log includes:

- Console
- Control Area
- MFP
- Outlet Grouping
- System Setup
- User
- User Activity
- User Group
- Visitor

You can view all the log records or the log records in a specific time period.

You can print the event log records by Clicking “ **Print** “.

You can export the event log records in CSV format by Clicking “ **CSV** “.

The screenshot displays the 'Log' application interface. On the left is a sidebar with a tree view containing categories like 'Device Event Log' (Cabinet, Door Access, Fan, PDU, Sensors, T / H Sensor) and 'System Event Log' (Console, Control Area, MFP, Outlet Grouping, System Setup, User, User Activity, User Group, Visitor). The main area is titled 'Door Access Log' and features a 'Filter-Option' section with radio buttons for 'All' and 'Specific Date', and input fields for 'Start Date & Time' and 'End Date & Time'. Below the filter section are 'Print' and 'CSV' buttons, both circled in red. The main content is a table with columns 'Event' and 'Description'. The table contains 20 rows of log entries, each with a timestamp and a description of a door access event. At the bottom, there is a pagination bar showing 'Page 1 of 10' and a status bar indicating 'Displaying 1 - 20 of 189'.

Event	Description
2013-09-27 06:27:49 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was locked by Auth card User 'kenny'-10803532
2013-09-27 06:27:49 +08:00	In Cabinet 014(138.168.1.14), Front Handle was locked by Auth card User 'kenny'-10803532
2013-09-27 06:27:43 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was closed by Auth card by User 'kenny'-10803532
2013-09-27 06:27:39 +08:00	In Cabinet 014(138.168.1.14), Front Handle was closed by Auth card by User 'kenny'-10803532
2013-09-27 06:27:37 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:27:37 +08:00	In Cabinet 014(138.168.1.14), Front Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:27:31 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:27:31 +08:00	In Cabinet 014(138.168.1.14), Front Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:25:07 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:25:00 +08:00	In Cabinet 014(138.168.1.14), Front Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:21:48 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:21:48 +08:00	In Cabinet 014(138.168.1.14), Front Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:21:22 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:21:22 +08:00	In Cabinet 014(138.168.1.14), Front Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:20:13 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:20:13 +08:00	In Cabinet 014(138.168.1.14), Front Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:19:48 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:19:48 +08:00	In Cabinet 014(138.168.1.14), Front Handle was opened by Auth card by User 'kenny'-10803532
2013-09-27 06:19:09 +08:00	In Cabinet 014(138.168.1.14), Rear Handle was unlocked by Auth card by User 'kenny'-10803532
2013-09-27 06:19:09 +08:00	In Cabinet 014(138.168.1.14), Front Handle was unlocked by Auth card by User 'kenny'-10803532

## < 13.1 > SNMP

### ( I ). Accessing MIB Files

Use the World Wide Web (WWW) to download the SNMP MIB file at this URL:


[https://www.austin-hughes.com/resource\\_cat/product-resources/rack-access-resources/](https://www.austin-hughes.com/resource_cat/product-resources/rack-access-resources/)

### ( II ). Enabling SNMP Support

The following procedure summarizes how to enable the InfraBox for SNMP support.

1. Connect the InfraBox to a computer.
2. Open the Internet Explorer ( I.E. ) version 8.0 or above
3. Enter the configured IP address of InfraBox into the I.E. address bar. ( refer to P.7 )  
Default IP address is “ **192.168.0.1** ”


4. Enter “ **Login name** ” & “ **Password** ”.  
Default login name & password are “ **00000000** ”  
To change login name and password of XMS-02-S,  
please refer to P.43 < Login >



Login name

Password

5. Select **SNMP** from the left navigation pane
6. The **SNMP** Settings window appears as below:



**SNMP**

**SNMP agent**  Enable  Disable

**SNMP polling**

Read community

Write community

**SNMP traps**  ▼


**Management station**

Station IP

Trap port

Trap community

7. Click “ **Enable** ” in “ **SNMP Agent** ” to start the SNMP agent service
8. Input “ **Read Community** “. Default is “ **public** ”
9. Input “ **Write Community** “. Default is “ **private** ”
10. Select “ **disabled** ” or “ **V2Trap** ” in “ **SNMP Traps** ”

 If select “ **V2Trap** ” , please input IP address of the SNMP management station in “ **Station IP:** ”

11. Click “ **Apply** ” to finish the SNMP settings

## < 14.1 > FAQ & Troubleshooting

### InfraSolution X Manager – X-ISM

#### 1. What is InfraSolution X Manager – X-ISM?

InfraSolution X Manager X-ISM is a LICENSED rack management software to monitor up to 3000 racks remotely.

Each InfraBox connects a pair of smartcard handles to secure the rack access control.

Each InfraBox can also connect a variety of sensors to provide an environmental monitoring solution.

To enhance the functionality, up to 1920 x kWh PDU / 960 x Fan Unit can be monitored through InfraSolution X Manager as well.

Up to 100 concurrent users can access the management software remotely to achieve the demand of multi-user / multi-tasking in nowadays' time sharing data center operation.

#### 2. What OS platform does X-ISM support?

MS Windows 2008 Server R2 Standard edition with SP1 ( English edition only )  
MS Windows 2012 / 2016 Server ( Standard edition )

#### 3. What are the default ports used in X-ISM ?

UDP port: 8890 for searching InfraBox

TCP port: 4000, 4001, 4003, 4006 & 18081 for InfraBox communication

TCP port: 80 for HTTP

TCP Port: 25 for email alarm service ( can be edited by user )

#### 4. What is the login name & password of default administrative account?

Default login name “ admin “ & password “ admin “

#### 5. How many racks & remote clients does X-ISM support?

3,000 racks and 100 remote clients ( max. )

#### 6. How can I receive the alarm email?

- Enable email alert in System Setup
- Configure mail server setting in System Setup
- Enable email alert in User Setup
- Enable email alarm in Rack IP configuration

#### 7. After close the web browser, I cannot login the software UI again using the same user account immediately?

Ensure clicking the “ logout “ button to exit. If clicking the “ close “ button, you need to wait around 1 min before you can login again.

### InfraBox

#### 1. Does the InfraBox has dual power input?

( MUST order before delivery )

**2. How many PDUs does InfraBox support?**

4 PDUs max. ( for InfraBox X-2000 only )

**3. How many fan units does InfraBox support?**

2 fan units max. ( for InfraBox X-2000 only )

**4. Does the InfraBox have a built-in UI ?**

Yes, a built-in UI provides a general remote rack access monitoring & control. You can also monitor & control up to 4 PDUs and a variety of sensors ( X-2000 model ONLY ).

However, this built-in UI can ONLY manage ONE InfraBox , no any event log. If need a complete monitoring control AND event log reporting for some hundred racks , the licensed X-ISM rack management software is absolutely required.

**5. Can I use the built-in UI and InfraSolution Manager software simultaneously ?**

No, only either one

**6. What is the default IP setting of InfraBox ?**

The default IP setting is as below :

IP address: 192.168.0.1

Subnet mask: 255.255.255.0

Gateway: 192.168.0.254

**7. What is the IP Setup utilities ?**

This is a windows application used to assign the IP address of the InfraBox.

Please find the link below:

<http://www.austin-hughes.com/support/utilites/InfrasolutionX/InfraBoxSetup.msi>

**8. What is the default ports used in IP setup utilities ?**

- UTP port : 8880, 8881, 8882, 8883, 8884, 8888, 8889, 8890 & 8891

**9. How can I replace the failed InfraBox ?**

Power off the faulty InfraBox. Unplug the cables, unscrew the InfraBox and take it out.

Before install the new InfraBox to rack, please follow the InfraBox IP setup procedure in user manual P.6. After install the new InfraBox to rack, plug all the connection cables required and power on.

**10. Does the InfraBox have firmware built-in ?**

Yes

**11. How can I get the updated InfraBox firmware ?**

Please find the link below :

<http://www.austin-hughes.com/resources/software/infrasolutionX>

Please select " **Management Software** " at the right side selection column, and you will find the firmware files.

**12. Can I remotely update the InfraBox firmware ?**

Yes

## < 14.1 > FAQ & Troubleshooting

### Sensors

**1. How accurate is the Temp. & Humid sensor?**

It is accurate to +/- 0.5 C ( typical ) and +/- 4.5% RH ( typical )

**2. How accurate is the Temp. sensor?**

It is accurate to +/- 1.0 C ( typical )

**3. What is sensitivity of smoke sensor?**

0.15 ~ 0.3 dB/m

**4. What is the detection radius of shock sensor?**

3.5m

**5. What is the lumen of the LED light bar?**

250

**6. How long is the LED light bar ON after the handle lock is released?**

within 10 seconds

### Others

**1. Can I use a notebook computer as a management PC?**

Yes, but ensure the power adapter is plugged in & power ON.

**2. Where can I find the Catalogue / User manual / Model list of InfraBox?**

Please visit [www.austin-hughes.com](http://www.austin-hughes.com)

**3. How can I get a further support?**

Please send an email to [support@austin-hughes.com](mailto:support@austin-hughes.com) or [sales@austin-hughes.com](mailto:sales@austin-hughes.com)

## InfraBox Disconnection

### 1. GUI shows **a certain InfraBox in a DAISY CHAIN / MIXED network** disconnected

#### Step 1 - InfraBox power off?

Check the InfraBox is power ON or not

#### Step 2 - Can ping the IP address?

- i. Make sure the IP address can be found and configured using the “ **IP setup utilities for InfraBox** “
- ii. Make sure the IP address of the InfraBox is the same as the IP address of the rack configuration in the InfraSolution X Manager GUI

### 2. GUI shows **the whole daisy chain group of InfraBoxes in a DAISY CHAIN / MIXED network** disconnected

#### Step 1 - Cat. 5 / 6 cable disconnected, loose or defective?

Check the Cat. 5 / 6 cable connection between the first InfraBox and network device. Make sure the connectors are firmly attached. And check if any defects on your cable or not. If yes, replace a new one.

#### Step 2 - First InfraBox failed?

Disconnect the InfraBox from the network and try to direct connect the Cat. 5 / 6 cable from the < **LAN** > port to a computer network port and use IP Setup Utilities to check if the InfraBox can be found or not. If it cannot be found, the InfraBox may be failed

### 3. GUI shows **a certain InfraBox in a STAR network** disconnected

#### Step 1 - InfraBox power off?

Check the InfraBox is power ON or not

#### Step 2 - Can ping the IP address?

- i. Make sure the IP address can be found and configured using the “ **IP setup utilities for InfraBox** “
- ii. Make sure the IP address of the InfraBox is the same as the IP address of the rack configuration in the InfraSolution X Manager GUI

#### Step 3 - Cat. 5 / 6 cable disconnected, loosed or defective?

Check the Cat. 5 / 6 cable connection between the InfraBox and network device.

Make sure the connectors are firmly attached. And check if any defects on your cable or not. If yes, replace a new one.

## < 14.1 > FAQ & Troubleshooting

### Replacement of InfraBox

#### 1. How to replace a failed InfraBox in a DAISY CHAIN network with a new one?

**Step 1** - Configure the IP address of the new InfraBox as the failed one

( Please refer to user manual < 2.2 > InfraBox X-1000 / X-2000 for details )

**Step 2** - Prepare an appropriate length Cat. 5 / 6 cable

**Step 3** - Use a Cat. 5 / 6 cable to bridge over the failed InfraBox which will be replaced to minimize data loss

**Step 4** - Remove all connected handles, sensors, PDUs and fan units from the failed InfraBox

**Step 5** - Power off and remove the failed InfraBox from connection

**Step 6** - Install the new InfraBox, cancel the cable-bridging and reconnect the InfraBox to the previous and next one

**Step 7** - Power on the new InfraBox

**Step 8** - Reconnect the removed handles, sensors, PDUs and fan units to the new InfraBox

**Step 9** - Configure the new InfraBox in < **CA – Edit Mode** >



Ignore step 2 and 3 if the InfraBox is in the last position of the daisy chain

#### 2. How to replace a failed InfraBox in a STAR network with a new one?

**Step 1** - Configure the IP address of the new InfraBox as the failed one

( Please refer to user manual < 2.2 > InfraBox X-1000 / X-2000 for details )

**Step 2** - Remove all connected handles, sensors, PDUs and fan units from the failed InfraBox

**Step 3** - Power off and remove the failed InfraBox from connection

**Step 4** - Install the new InfraBox to the connection and power it on

**Step 5** - Reconnect the removed handles, sensors, PDUs and fan units to the new InfraBox

**Step 6** - Configure the new InfraBox in < **CA – Edit Mode** >

The company reserves the right to modify product specifications without prior notice and assumes no responsibility for any error which may appear in this publication.

All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2022 Austin Hughes Electronics Ltd. All rights reserved.