

## User Manual

PPS-03-S, IP dongle GUI & SNMP

InfraPower Intelligent PDU



Designed and manufactured by Austin Hughes



## Legal Information

First English printing, August 2023

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

## Safety Instructions

**Please read all of these instructions carefully before you use the device. Save this manual for future reference.**

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the equipment is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labelled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equipment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

## What the warranty does not cover

- Any product, on which the serial number has been defaced, modified or removed.
- Damage, deterioration or malfunction resulting from:
  - ☐ Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product.
  - ☐ Repair or attempted repair by anyone not authorized by us.
  - ☐ Any damage of the product due to shipment.
  - ☐ Removal or installation of the product.
  - ☐ Causes external to the product, such as electric power fluctuation or failure.
  - ☐ Use of supplies or parts not meeting our specifications.
  - ☐ Normal wear and tear.
  - ☐ Any other causes which does not relate to a product defect.
- Removal, installation, and set-up service charges.

## Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in business, industrial and commercial environments.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-position or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

# Contents

< 1.1 >	IP Dongle Specification	P.1
< 1.2 >	IP Dongle Installation & Meter ( PDU ) Cascade	P.3
< 1.3 >	Meter ( PDU ) Level Setting	P.4
< 1.4 >	IP Dongle Configuration	P.5
< 1.5 >	Remote PDU Level & ID Setting	P.6
< 1.6 >	PPS-03-S IP Dongle GUI	P.10
< 1.7 >	System	P.15
< 1.8 >	Network	P.16
< 1.9 >	Wifi Network Configuration	P.17
< 1.10 >	Login	P.24
< 1.11 >	SNMP Setup	P.28
< 1.12 >	Notification	P.33
< 1.13 >	Syslog	P.34
< 1.14 >	IP Dongle Firmware Upgrade	P.35
< 1.15 >	Bulk Firmware Upgrade	P.37
< 1.16 >	DHCP Setting	P.49
< 1.17 >	802.1X authentication	P.52
< 1.18 >	Command Line Interface Access	P.58
< 1.19 >	Optional Accessories - Wifi Kit	P.59

## < 1.1 > IP Dongle Specification

### IP Dongle Access to 32 PDU Levels


Patented IP Dongle provides IP remote access to the PDUs by a true network IP address chain. Only 1 x IP dongle allows access to max. 32 PDUs in daisy chain - which is a highly efficient application for saving not only the IP remote accessories cost, but also the true IP addresses required on the PDU management.

Hot-Pluggable design facilitates the IP dongle installation. Simply integrate the IP Dongle to the 1st PDU, then the entire daisy chain group can be remote over IP. Hence, administrator can remotely access all PDUs in the daisy chain group by one single IP via the IP Dongle.

- Press the reset button and release instantly to reboot IP dongle.
- Press and hold the reset button until Green LED off to reset IP dongle to factory default

Part no.  
**IPD-03-S**

Reset.....  
button



### InfraPower PPS-03-S

Features		
Capacity	IP Dongle Group ( Just 1 for 32 PDU levels )	1
	Max PDU number per IP dongle ( IPD-03-S )**	32
	Concurrent Users	1
Enhanced Features	Outlet Level kWh & Amp Measurement	✓
	Energy Consumption ( kWh ) Monitoring	✓
	Apparent Power ( kVA ) Monitoring	✓
	Power Factor Measurement	✓
	Circuit Breaker ( MCB ) Monitoring	✓
	Remote level & ID setting for cascaded iPDU	✓
Basic Features	Aggregate Current ( Amp ) Monitoring	✓
	Individual Outlet Switch ON/OFF	✓
	Temp-Humid Monitoring	✓
	Alarm Threshold Setting	✓
	Rising Alert Threshold Setting	✓
	Door & Smoke Sensor Monitoring	✓
	Remote Access via Web	✓
	Graphic User Interface	✓
PDU Series Support	All Single & Three Phase iPDU	✓
	All Single & Three Phase Dual Feed iPDU	✓
	All Single & Three Phase inline meter	✓
	All Single & Three Phase Dual Feed inline meter	✓

\*\* Data refresh speed subject to number of cascaded PDU.

## < 1.1 > IP Dongle Specification



### Dual LAN Network Failover

- > Auto failover to a 2nd Ethernet-connection in the event of network interruption
- > Ensuring 100% iPDU uptime reporting



### Connectivity

- > Access your iPDU on two independent networks or VLANs
- > Auto-negotiable 10/100 BaseT Ethernet & 1000 BaseT Gigabit Ethernet ports
- > Redundant network access to the connected iPDUs via IP



### Enterprise Level IP Authentication

- > Active Directory (AD), Lightweight Directory Access Protocol (LDAPv3 / LDAPS), Remote Access Dial-In User Service (RADIUS) protocol, or local credential database.
- > Strong passwords and granular user/user group permissions.



### Remote Management

- > Significantly reduce the number of Ethernet ports used in deployment by cascading a single network connection across multiple iPDUs (up to 32)
- > Simultaneous access via free management software IPM-04, web GUI & SNMP V2 / V3
- > Remote level & ID setting for cascaded iPDU's



### Alerts / Alarms

- > Receive alerts via SNMP, email (SMTP), and syslog when predefined thresholds are exceeded for both iPDU and environmental sensor events.
- > Common SNMP MIBs (Management Information Base) across all iPDU families



### USB Wifi Port

- > Optionally connect via a Wifi kit (IPD-WIFI) complying with 802.11 g/n/ac





### Remote Management Protocols

- > HTTP(S); SSH Command Line Interface; Telnet; SMTP; IPv6/IPv4

## < 1.2 > IP Dongle Installation & Meter ( PDU ) Cascade

IP dongle installation steps :


- slide the IP dongle on the plate above the meter
- plug the RJ-45 connector of IP dongle into the LINK port of the 1st level PDU meter
- use the CAT. 5e / 6 cable to connect IP dongle to network device



## < 1.3 > Meter ( PDU ) Level Setting

### ( I ) For 1.8" LCD Meter ( No touchscreen function )


Display 9



**Step 1** - Press the & button to display no.9 and press to confirm

**Step 2** - Press the & button to PDU ID and press to confirm


Display 9.1



**Step 3** - In display 9.1, Press the & button to select PDU level no. & press to confirm

**Step 4** - Press to exit

### ( II ) For 2.8" LCD Meter ( With touchscreen function )



### ( III ) For 2.8" LCD Meter ( With touchscreen function )



For PDU with firmware version V37 or above





## < 1.4 > IP Dongle Configuration

 The following steps show the static IP setting only. For DHCP setting, please refer to < 1.14 > DHCP Setting

After the completion of IP dongle connection, please take the following steps to configure the IP dongle :

- Step 1.** Prepare a notebook computer to download the IP setup utilities from the link :  
<http://www.austin-hughes.com/support/utilities/infrapower/IPdongleSetup.msi>
- Step 2.** Double Click the IPDongleSetup.msi and follow the instruction to complete the installation
- Step 3.** Go to each first level PDU with the notebook computer & a piece of CAT. 5e / 6 cable to configure the **LAN 1 Port** of the IP dongle by IP setup utilities as below. Please take the procedure for all IP dongles **ONE BY ONE**



1. If the IP dongle is in factory default setting or the password is " 00000000 ", you **MUST** change the password for security purpose .
2. The password **MUST** contain at least three of the following four character groups :
  - English uppercase characters ( A through Z )
  - English lowercase characters ( a through z )
  - Numerals ( 0 through 9 )
  - Non-alphabetic characters ( such as !, @, #, % ). [ ` ], [ \$ ], [ " ], [ \ ] are NOT supported.
3. Device name **NOT EQUAL** to the Login name of IP Dongle WEBUI ( PPS-03-S ). To change Login name, please refer to < 1.10 > Login for details.

**Step 4.** Click " **Scan** " to search the connected IP dongle

**Step 5.** Enter device name in " **Device name** " ( min. 4 char. / max. 16 char. ). Default is " **default\_ipd\_name** "

**Step 6.** Enter device location in " **Device location** " ( min. 4 char. / max. 16 char. ). Default is " **default\_ipd\_loc.** "

**Step 7.** Enter password in " **Password** " for authentication ( min. 8 char. / max. 16 char. ) Default is " **00000000** "

**Step 8.** Enter new password in " **New password** " ( min. 8 char. / max. 16 char. )

**Step 9.** Re-enter new password in " **Confirm new password** "

**Step 10.** Change the desired " **IP address** " / " **Subnet mask** " / " **Gateway** ", then Click " **Save** " to confirm the changes

**Lan 1.** The default IP setting is as below:

IP address : 192.168.11.1  
Subnet mask : 255.255.255.0  
Gateway : 192.168.11.254

**Lan 2.** The default IP setting is as below:


IP address : 192.168.0.1  
Subnet mask : 255.255.255.0  
Gateway : 192.168.0.254


**Step 11.** Repeat **Step 4 & Step 10** for **Lan 2** Port of IP dongle if you will use LAN 2 as well. Otherwise, ignore this step.



## < 1.5 > Remote PDU Level & ID Setting

InfraPower Manager PPS-03-S provides a convenient way to set the PDU level. You can set the PDU level remotely via the IP Dongle WEBUI. Please follow the steps below to complete the Remote PDU level setting.

 ONLY PDU with 2.8" LCD meter ( firmware version V37 or above ) supports this functions

 You MUST have the PDU serial number onhand and know which rack the PDU is installed.

**Step 1.** Open MS Edge

**Step 2.** Enter the configured IP Dongle address into the address bar.

Default IP address of LAN 1 is “ **192.168.11.1** ”

Default IP address of LAN 2 is “ **192.168.0.1** ”




Device: IP Dongle PPS-03s

Login name:

Password:

Login Cancel



Device: IP Dongle PPS-03s

You are required to change the default password.

Login name:

Default Password:

New Password:


Confirm Password:

Apply Cancel



- If the IP dongle is in factory default setting or the password is “ 00000000 “. This window will be shown and you MUST change the “ Password “ before you can login the IP dongle WEBUI.

**Step 3.** Enter the “ Login name “ and “ Password “ & Click “ Login “



Device: IP Dongle PPS-03s

Login name: 00000000


Password: .....

Login Cancel



- Default login name: 00000000
- Password: the one you set in Step 7 of < 1.4 > IP Dongle Configuration.
- The login account will be LOCKED for 5 minutes if three unsuccessful login attempts to the IP dongle WEBUI.

**Step 4.** In < Status >, Click “ Search “ to start the PDU searching



Status

IP Dongle name : default\_name

LAN 1 IPv4 address : 192.168.1.62 LAN 2 IPv4 address : 192.168.0.2

LAN 1 IPv6 address : 2001:0:1:a2::ec11/64 LAN 2 IPv6 address : 2001:0:1:a2::ec01/64

Level	Name	Location	Amp	kWh	kVA	Total
			Max. / Load / Alarm/ R. alert / L. alert			Amp kWh kVA

☒ Auto data refresh : ☐ Untick during data input

Search Search new installed devices Time Sync Synchronize all connected devices' time with computer

## < 1.5 > Remote PDU Level & ID Setting

**Step 5.** After the searching is completed, the following screen will display

**Status**

IP Dongle name : default\_name

LAN 1 IPv4 address : 192.168.1.62

LAN 1 IPv6 address : 2001:0:1:a2::ec11/64

LAN 2 IPv4 address : 192.168.0.2

LAN 2 IPv6 address : 2001:0:1:a2::ec01/64

#	Model	Serial No.	Name	Location	Level	Register
1.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P001	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
2.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P002	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
3.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P003	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
4.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P004	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
5.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P005	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
6.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P006	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
7.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P007	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
8.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P008	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
9.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P009	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
10.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P010	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
11.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P011	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
12.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P012	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
13.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P013	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
14.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P014	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
15.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P015	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
16.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P016	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
17.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P017	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
18.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P018	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
19.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P019	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
20.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P020	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
21.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P021	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
22.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P022	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
23.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P023	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
24.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P024	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
25.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P025	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
26.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P026	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
27.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P027	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
28.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P028	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
29.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P029	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
30.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P030	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
31.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P031	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>
32.	V48C13/24C19-32A-WSI/CR_EN/3T-1	208201020001111-3300-P032	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▾	<input checked="" type="checkbox"/>

Save new data input

Return to previous page

Discard new data input

## < 1.5 > Remote PDU Level & ID Setting

**Step 6.** Assign a unique “ **Level** “ , “ **Name** “ and “ **Location** “ to each PDU and ensure to check the register box.  
Then Click “ **Apply** “.

**Status**

IP Dongle name : default\_name

LAN 1 IPv4 address : 192.168.1.62

LAN 1 IPv6 address : 2001:0:1:a2::ec11/64

LAN 2 IPv4 address : 192.168.0.2

LAN 2 IPv6 address : 2001:0:1:a2::ec01/64

#	Model	Serial No.	Name	Location	Level	Register
1.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P001	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	01 ▼	<input checked="" type="checkbox"/>
2.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P002	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	02 ▼	<input checked="" type="checkbox"/>
3.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P003	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	03 ▼	<input checked="" type="checkbox"/>
4.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P004	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	04 ▼	<input checked="" type="checkbox"/>
5.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P005	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	05 ▼	<input checked="" type="checkbox"/>
6.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P006	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	06 ▼	<input checked="" type="checkbox"/>
7.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P007	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	07 ▼	<input checked="" type="checkbox"/>
8.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P008	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	08 ▼	<input checked="" type="checkbox"/>
9.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P009	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	09 ▼	<input checked="" type="checkbox"/>
10.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P010	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	10 ▼	<input checked="" type="checkbox"/>
11.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P011	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	11 ▼	<input checked="" type="checkbox"/>
12.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P012	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	12 ▼	<input checked="" type="checkbox"/>
13.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P013	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	13 ▼	<input checked="" type="checkbox"/>
14.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P014	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	14 ▼	<input checked="" type="checkbox"/>
15.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P015	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	15 ▼	<input checked="" type="checkbox"/>
16.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P016	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	16 ▼	<input checked="" type="checkbox"/>
17.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P017	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	17 ▼	<input checked="" type="checkbox"/>
18.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P018	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	18 ▼	<input checked="" type="checkbox"/>
19.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P019	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	19 ▼	<input checked="" type="checkbox"/>
20.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P020	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	20 ▼	<input checked="" type="checkbox"/>
21.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P021	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	21 ▼	<input checked="" type="checkbox"/>
22.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P022	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	22 ▼	<input checked="" type="checkbox"/>
23.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P023	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	23 ▼	<input checked="" type="checkbox"/>
24.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P024	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	24 ▼	<input checked="" type="checkbox"/>
25.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P025	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	25 ▼	<input checked="" type="checkbox"/>
26.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P026	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	26 ▼	<input checked="" type="checkbox"/>
27.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P027	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	27 ▼	<input checked="" type="checkbox"/>
28.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P028	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	28 ▼	<input checked="" type="checkbox"/>
29.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P029	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	29 ▼	<input checked="" type="checkbox"/>
30.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P030	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	30 ▼	<input checked="" type="checkbox"/>
31.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P031	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	31 ▼	<input checked="" type="checkbox"/>
32.	V48C13/24C19-32A-WSi/CR_EN/3T-1	208201020001111-3300-P032	<input type="text" value="default_pdu_name"/>	<input type="text" value="default_pdu_loc."/>	32 ▼	<input checked="" type="checkbox"/>

Apply

Cancel

Save new data input

Discard new data input

Exit

Return to previous page

< 1.5 > Remote PDU Level & ID Setting

Step 7. After the PDU level setting is complete, “ Status “ page will display the PDU with proper level.

Status

IP Dongle name : default\_name

LAN 1 IPv4 address : 192.168.1.62

LAN 1 IPv6 address : 2001:0:1:a2::ec11/64

LAN 2 IPv4 address : 192.168.0.2

LAN 2 IPv6 address : 2001:0:1:a2::ec01/64

Level	Name	Location		Amp			kWh	kVA		Amp			kWh	kVA		Total															
				Max. / Load / Alarm/ R. alert / L. alert						Max. / Load / Alarm/ R. alert / L. alert						Load															
01	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
02	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.06		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.06
03	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
04	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
05	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
06	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
07	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
08	default_pdu_name	default_pdu_loc.	A	16.0	/	0.3	/	12.8	/	0.0	/	0.0	0.31	0.07		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.3	0.31	0.07
09	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
10	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
11	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
12	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
13	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
14	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
15	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
16	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
17	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
18	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
19	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
20	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
21	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
22	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
23	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
24	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
25	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
26	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
27	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
28	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
29	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
30	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
31	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00
32	default_pdu_name	default_pdu_loc.	A	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		B	16.0	/	0.0	/	12.8	/	0.0	/	0.0	0.00	0.00		0.0	0.00	0.00

☒ Auto data refresh : ☐ Untick during data input

Search

 Search new installed devices

Time Sync

 Synchronize all connected devices' time with computer



## < 1.6 > PPS-03-S IP Dongle GUI

Each IP dongle ( IPD-03-S ) provides a **FREE** built-in GUI , PPS-03-S, which allows user, via a web browser, to see PDU's data and remotely manage the PDU over a TCP / IP Ethernet network.



Each web browser window supports only one IP dongle ( IPD-03-S ). If user installs more IP dongles, multi windows will be required



PPS-03-S is a management software with very limited features. User can use more advanced software, InfraPower Manager IPM-04


### Step 1. Open MS Edge

**Step 2.** Enter the configured IP dongle address into the address bar ( Please refer to < 1.4 > IP dongle configuration )

Default IP address of LAN 1 is “ **192.168.11.1** ”

Default IP address of LAN 2 is “ **192.168.0.1** ”

**Step 3. Enter “ Login name ” , “ Password ” & Click “ Login ”**



A screenshot of a login form. It has two input fields: "Login name" and "Password". Below these fields are two buttons: "Login" and "Cancel". The "Login" button is circled in red.

- Default login name: 000000000
- Password: the one you set in Step 7 of < 1.4 > IP Dongle Configuration.

In **< Status >**,

- Click “ **Search** ” to search all new installed PDUs
- View all installed PDUs’ status
- View latest loading on each PDU's circuits
- View aggregate current & energy consumption on each PDU
- View status & latest reading of Temp. & Humid sensors connected to each PDU
- View status of Door / Smoke sensors connected to each PDU
- Click “ **Time Sync** ” update all connected PDU’s real time clock from the computer logged in the IP Dongle

Status

IP Dongle name :

default\_name

LAN 1 IPv4 address :

192.168.1.62

LAN 1 IPv6 address :

2001:0:1::2::ec11/64

LAN 2 IPv4 address :

192.168.0.2

LAN 2 IPv6 address :

2001:0:1::2::ec01/64

Level	Name	Location		Amp			kWh	kVA		Amp			kWh	kVA		Total								
				Max. / Load / Alarm/ R. alert / L. alert						Max. / Load / Alarm/ R. alert / L. alert														
				Load						Load														
01	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
02	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.06		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.06							
03	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
04	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
05	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
06	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
07	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
08	default_pdu_name	default_pdu_loc.	A	16.0 / 0.3 / 12.8 / 0.0 / 0.0			0.31	0.07		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.3	0.31	0.07							
09	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
10	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
11	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
12	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
13	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
14	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
15	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
16	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
17	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
18	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
19	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
20	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
21	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
22	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
23	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
24	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
25	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
26	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
27	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
28	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
29	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
30	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
31	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							
32	default_pdu_name	default_pdu_loc.	A	16.0 / 0.0 / 12.8 / 0.0 / 0.0			0.00	0.00		B	16.0 / 0.0 / 12.8 / 0.0 / 0.0	0.00	0.00		0.0	0.00	0.00							

☒ Auto data refresh :

Untick during data input

Search

Search new installed devices

Time Sync

Synchronize all connected devices' time with computer

## < 1.6 > PPS-03-S IP Dongle GUI

In < **Details** > ,

- Change “ **Name** ” and “ **Location** ” of PDU & Click “ **Apply** ”
- Change “ **Alarm amp.** ” & “ **Low alert amp.** ” of PDU's circuits & Click “ **Apply** ”
- Click “ **Reset** ” to reset peak amp. or kWh of PDU's circuits
- Click “ **ON / OFF** ” to switch ON / OFF outlet ( Switched PDU only )
- View On / Off status of each PDU's outlet
- View aggregated current on the PDU
- View latest loading & energy consumption of each PDU's outlet ( Outlet Measurement PDU only )
- Click “ **Time Sync** ” update PDU's real time clock from the computer logged in the IP Dongle

**PDU Details**

Level : 01 V48C13/24C19-32A-WSi

Name : default\_pdu\_name

Status : Connected

Location : default\_pdu\_loc.

kWh : 6.90

Power factor : 0.68

Frequency : 50.1

Load amp : 0.3

kVA : 0.07

**A**

Voltage : 218.0

Max. amp : 16.0

Load amp : 0.3

Peak amp : 0.4

kWh : 6.90

Alarm amp : 12.8

Rising alert amp : 0.0

Low alert amp : 0.0

2015/01/01 07:53:28

2015/01/01 00:00:00

Reset

Reset

**B**

Voltage : 218.0

Max. amp : 16.0

Load amp : 0.0

Peak amp : 0.0

kWh : 0.00

Alarm amp : 12.8

Rising alert amp : 0.0

Low alert amp : 0.0

2015/01/01 00:00:00

2015/01/01 00:00:00

Reset

Reset

Outlet	Name	Amp	kWh	kVA	Status	Switch	Outlet	Name	Amp	kWh	kVA	Status	Switch
01	outlet_name_01	0.0	0.00	0.00	ON	OFF	25	outlet_name_37	0.0	0.00	0.00	ON	OFF
02	outlet_name_02	0.0	0.00	0.00	ON	OFF	26	outlet_name_38	0.0	0.00	0.00	ON	OFF
03	outlet_name_03	0.0	0.00	0.00	ON	OFF	27	outlet_name_39	0.0	0.00	0.00	ON	OFF
04	outlet_name_04	0.0	0.00	0.00	ON	OFF	28	outlet_name_40	0.0	0.00	0.00	ON	OFF
05	outlet_name_05	0.0	0.00	0.00	ON	OFF	29	outlet_name_41	0.0	0.00	0.00	ON	OFF
06	outlet_name_06	0.0	0.00	0.00	ON	OFF	30	outlet_name_42	0.0	0.00	0.00	ON	OFF
07	outlet_name_07	0.0	0.00	0.00	ON	OFF	31	outlet_name_43	0.0	0.00	0.00	ON	OFF
08	outlet_name_08	0.0	0.00	0.00	ON	OFF	32	outlet_name_44	0.0	0.00	0.00	ON	OFF
09	outlet_name_09	0.0	0.00	0.00	ON	OFF	33	outlet_name_45	0.0	0.00	0.00	ON	OFF
10	outlet_name_10	0.0	0.00	0.00	ON	OFF	34	outlet_name_46	0.0	0.00	0.00	ON	OFF
11	outlet_name_11	0.0	0.00	0.00	ON	OFF	35	outlet_name_47	0.0	0.00	0.00	ON	OFF
12	outlet_name_12	0.0	0.00	0.00	ON	OFF	36	outlet_name_48	0.0	0.00	0.00	ON	OFF
13	outlet_name_13	0.0	0.00	0.00	ON	OFF	37	outlet_name_49	0.0	0.00	0.00	ON	OFF
14	outlet_name_14	0.0	0.00	0.00	ON	OFF	38	outlet_name_50	0.0	0.00	0.00	ON	OFF
15	outlet_name_15	0.0	0.00	0.00	ON	OFF	39	outlet_name_51	0.0	0.00	0.00	ON	OFF
16	outlet_name_16	0.0	0.00	0.00	ON	OFF	40	outlet_name_52	0.0	0.00	0.00	ON	OFF
17	outlet_name_17	0.0	0.00	0.00	ON	OFF	41	outlet_name_53	0.0	0.00	0.00	ON	OFF
18	outlet_name_18	0.0	0.00	0.00	ON	OFF	42	outlet_name_54	0.0	0.00	0.00	ON	OFF
19	outlet_name_19	0.0	0.00	0.00	ON	OFF	43	outlet_name_55	0.0	0.00	0.00	ON	OFF
20	outlet_name_20	0.0	0.00	0.00	ON	OFF	44	outlet_name_56	0.0	0.00	0.00	ON	OFF
21	outlet_name_21	0.0	0.00	0.00	ON	OFF	45	outlet_name_57	0.0	0.00	0.00	ON	OFF
22	outlet_name_22	0.0	0.00	0.00	ON	OFF	46	outlet_name_58	0.0	0.00	0.00	ON	OFF
23	outlet_name_23	0.0	0.00	0.00	ON	OFF	47	outlet_name_59	0.0	0.00	0.00	ON	OFF
24	outlet_name_24	0.0	0.00	0.00	ON	OFF	48	outlet_name_60	0.0	0.00	0.00	ON	OFF
C01	outlet_name_25	0.0	0.00	0.00	ON	OFF	C13	outlet_name_61	0.0	0.00	0.00	ON	OFF
C02	outlet_name_26	0.0	0.00	0.00	ON	OFF	C14	outlet_name_62	0.0	0.00	0.00	ON	OFF
C03	outlet_name_27	0.0	0.00	0.00	ON	OFF	C15	outlet_name_63	0.0	0.00	0.00	ON	OFF
C04	outlet_name_28	0.0	0.00	0.00	ON	OFF	C16	outlet_name_64	0.0	0.00	0.00	ON	OFF
C05	outlet_name_29	0.0	0.00	0.00	ON	OFF	C17	outlet_name_65	0.0	0.00	0.00	ON	OFF
C06	outlet_name_30	0.0	0.00	0.00	ON	OFF	C18	outlet_name_66	0.0	0.00	0.00	ON	OFF
C07	outlet_name_31	0.0	0.00	0.00	ON	OFF	C19	outlet_name_67	0.0	0.00	0.00	ON	OFF
C08	outlet_name_32	0.0	0.00	0.00	ON	OFF	C20	outlet_name_68	0.0	0.00	0.00	ON	OFF
C09	outlet_name_33	0.0	0.00	0.00	ON	OFF	C21	outlet_name_69	0.0	0.00	0.00	ON	OFF
C10	outlet_name_34	0.0	0.00	0.00	ON	OFF	C22	outlet_name_70	0.0	0.00	0.00	ON	OFF
C11	outlet_name_35	0.0	0.00	0.00	ON	OFF	C23	outlet_name_71	0.0	0.00	0.00	ON	OFF
C12	outlet_name_36	0.0	0.00	0.00	ON	OFF	C24	outlet_name_72	0.0	0.00	0.00	ON	OFF

Click outlet icon for setting

Click outlet icon for setting

\* Press F11 to enlarge or diminish the screen

☒ Auto data refresh :  Untick during data input

Apply

 Save new data input

Cancel

 Discard new data input

Time Sync

 Synchronize this device time with computer

## < 1.6 > PPS-03-S IP Dongle GUI

In < **Outlet setting** > ,

- Change PDU's outlet name
- Change “ **Power up sequence delay** ” of PDU's outlet ( Switched PDU only )
- Change “ **Alarm amp.** ”, “ **Rising Alert amp.** ” & “ **Low alert amp.** ” of PDU's outlet ( Outlet Measurement PDU only )

⚠ Click “ **Apply** ” to finish the above settings

- Click “ **Reset** ” to reset peak amp. or kWh of PDU's outlet ( Outlet Measurement PDU only )

**Outlet details**

Level :  V48C13/24C19-32A-WSi

Status : Connected

Name : default\_pdu\_name

Location : default\_pdu\_loc.

**A**

Outlet :

Name :

Status : ON

Power up sequence delay :

Load amp :

Alarm amp :

R. alert amp :

L. alert amp :

Peak amp :  2015/01/01 00:00:00

kWh :  2015/01/01 00:00:00

Save new data input

Discard new data input



## < 1.6 > PPS-03-S IP Dongle GUI

In < **Sensor Status** > ,

- View status, location, latest reading & alarm setting of Temp. & Humid sensors.
- View status & location of Door sensor & Smoke sensor



The GUI will not show the status / reading if sensors are NOT installed & activated.

**Sensor Status**

IP Dongle name : default\_name  
LAN 1 IPv4 address : 192.168.1.62 LAN 2 IPv4 address : 192.168.0.2  
LAN 1 IPv6 address : 2001:0:1:a2::ec11/64 LAN 2 IPv6 address : 2001:0:1:a2::ec01/64

Level	Name	Setting	Sensor 1				Sensor 2			
			Location	Type	Status	Alarm	R.alert	Location	Type	Status
01	default_pdu_name		sensor_location	Temp. (°C)	33.0	35.0	0.0	sensor_location	Door	Close
02	default_pdu_name		sensor_location	Smoke	Normal	-	-	sensor_location	Temp. (°C)	34.7
03	default_pdu_name		-	-	-	-	-	-	-	-
04	default_pdu_name		-	-	-	-	-	-	-	-
05	default_pdu_name		-	-	-	-	-	-	-	-
06	default_pdu_name		-	-	-	-	-	-	-	-
07	default_pdu_name		-	-	-	-	-	-	-	-
08	default_pdu_name		-	-	-	-	-	-	-	-
09	default_pdu_name		-	-	-	-	-	-	-	-
10	default_pdu_name		-	-	-	-	-	-	-	-
11	default_pdu_name		-	-	-	-	-	-	-	-
12	default_pdu_name		-	-	-	-	-	-	-	-
13	default_pdu_name		-	-	-	-	-	-	-	-
14	default_pdu_name		-	-	-	-	-	-	-	-
15	default_pdu_name		-	-	-	-	-	-	-	-
16	default_pdu_name		-	-	-	-	-	-	-	-
17	default_pdu_name		-	-	-	-	-	-	-	-
18	default_pdu_name		-	-	-	-	-	-	-	-
19	default_pdu_name		-	-	-	-	-	-	-	-
20	default_pdu_name		-	-	-	-	-	-	-	-
21	default_pdu_name		-	-	-	-	-	-	-	-
22	default_pdu_name		-	-	-	-	-	-	-	-
23	default_pdu_name		-	-	-	-	-	-	-	-
24	default_pdu_name		-	-	-	-	-	-	-	-
25	default_pdu_name		-	-	-	-	-	-	-	-
26	default_pdu_name		-	-	-	-	-	-	-	-
27	default_pdu_name		-	-	-	-	-	-	-	-
28	default_pdu_name		-	-	-	-	-	-	-	-
29	default_pdu_name		-	-	-	-	-	-	-	-
30	default_pdu_name		-	-	-	-	-	-	-	-
31	default_pdu_name		-	-	-	-	-	-	-	-
32	default_pdu_name		-	-	-	-	-	-	-	-

☒ Auto data refresh : Untick during data input

## < 1.6 > PPS-03-S IP Dongle GUI

In < **Sensor Setting** > ,

- Default Sensor setting :
- “ **Activate** ” sensors ONLY when they are connected
- Change “ **Location** ” , “ **Rising alert Setting** ” & “ **Alarm Setting** ” of Temp. & Humid sensors
- Change “ **Location** ” of Door sensor & Smoke sensor



If no any sensor connected, NEVER activate.

**Sensor Setting**

Level :  V48C13/24C19-32A-WSi

Status : Connected

Name : default\_pdu\_name

Location : default\_pdu\_loc.

**Sensor 1**

☒ Activate ☐ Deactivate

Type  
Temp. sensor

Location :

Alarm

Rising alert

Setting

Reading

Temp.(°C) :  
  33.0

**Sensor 2**

☒ Activate ☐ Deactivate

Type  
Door sensor

Location :

State:  
Close

**DO NOT** activate T or TH sensor if no sensor installed.  
When install T or TH sensor, please tick activate.  
Otherwise, no readings display.

Save new data input

Return to previous page

Discard new data input

## < 1.7 > System

In < **System** > ,

- Change IP dongle name & location
- Change temperature unit displayed in UI
- Set the “ **Date & Time** ” of the IP dongle ( by “ **Manually** ” or “ **NTP server** ” ). Default is “ **Manually** ”
- Tick “ **Force HTTPS** ” to provide data transmission security. Default Web Access is “ **HTTP** ”
- Click “ **Apply** ” to finish the above settings

IP Dongle	IP Dongle
Name : <input type="text" value="default_name"/>	Name : <input type="text" value="default_name"/>
Location : <input type="text" value="default_ipd_loc"/>	Location : <input type="text" value="default_ipd_loc"/>
Temperature unit : <input checked="" type="checkbox"/> °C <input type="checkbox"/> °F	Temperature unit : <input checked="" type="checkbox"/> °C <input type="checkbox"/> °F
Date & Time : 2020-09-07 11:08:21	Date & Time : 2020-09-07 11:08:21
Time zone : <input type="text" value="GMT+08:00"/>	Time zone : <input type="text" value="GMT+08:00"/>
Time setting : <input type="text" value="Manually"/>	Time setting : <input type="text" value="Synchronize with NTP server"/>
Date : <input type="text" value="2020-09-07"/>	NTP server : <input type="text" value="time.google.com"/> <input type="button" value="Sync Now"/>
Time : <input type="text" value="11"/> : <input type="text" value="08"/> : <input type="text" value="21"/>	
Web Access	Web Access
Protocol : <input type="text" value="HTTPS"/>	Protocol : <input type="text" value="HTTPS"/>
Port : <input type="text" value="443"/> ( Default: 443 )	Port : <input type="text" value="443"/> ( Default: 443 )
SSL Certificate : <input checked="" type="radio"/> Use default certificate <input type="radio"/> Use custom certificate	SSL Certificate : <input checked="" type="radio"/> Use default certificate <input type="radio"/> Use custom certificate
<input type="button" value="Apply"/> <input type="button" value="Cancel"/> <input type="button" value="Reset to Factory Default"/>	<input type="button" value="Apply"/> <input type="button" value="Cancel"/> <input type="button" value="Reset to Factory Default"/>

## < 1.8 > Network

In < **Network** >, IP dongle can be configured to operate as Dual Lan or failover mode. Default is “ **Dual Lan mode** ”

Dual Lan mode :

- Enter LAN 1 “ **IPv4 address** ”, “ **IPv6 address** ”, “ **Subnet mask** ”, “ **Gateway** ”. ( For static IP setting only)
- Enter LAN 2 “ **IPv4 address** ”, “ **IPv6 address** ”, “ **Subnet mask** ”, “ **Gateway** ”. ( For static IP setting only)
- Enter the IP address of “ **Primary DNS** ”. Default is “ **8.8.8.8** ”
- Enter the IP address of “ **Secondary DNS** ”. Default is “ “**0.0.0.0** ”
- Click “ **Apply** ” to finish the above settings

The screenshot shows the 'Network' configuration window. It has two columns: 'LAN 1 settings' and 'LAN 2 settings'. Each column has fields for DHCP (set to OFF), IPv4 address, IPv6 address, Subnet mask, and Gateway. Below these columns is a checkbox for 'Enable automatic failover' which is unchecked. At the bottom, there is a 'DNS' section with a checked checkbox for 'Manually configure DNS server', and fields for 'Primary DNS' (8.8.8.8) and 'Secondary DNS' (0.0.0.0). At the very bottom, there are 'Apply' and 'Cancel' buttons. The 'Apply' button is circled in red.

LAN 1 settings	LAN 2 settings
DHCP : OFF	DHCP : OFF
IPv4 address : 192.168.1.62	IPv4 address : 192.168.0.2
IPv6 address : 2001:0:1:a2::ec11/64	IPv6 address : 2001:0:1:a2::ec01/64
Subnet mask : 255.255.255.0	Subnet mask : 255.255.255.0
Gateway : 192.168.1.1	Gateway : 192.168.0.254

Enable automatic failover : ☐

**DNS**

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

Apply Cancel

Failover mode :

- Tick “ **Enable automatic failover** ” to operate the failover mode
- Enter “ **IPv4 address** ”, “ **IPv6 address** ”, “ **Subnet mask** ”, “ **Gateway** ”. ( For static IP setting only)
- Enter the IP address of “ **Primary DNS** ”. Default is “ **8.8.8.8** ”
- Enter the IP address of “ **Secondary DNS** ”. Default is “ “**0.0.0.0** ”
- Click “ **Apply** ” to finish the above settings

The screenshot shows the 'Network' configuration window for failover mode. It has a single 'LAN settings' column with fields for DHCP (set to OFF), IPv4 address, IPv6 address, Subnet mask, and Gateway. Below this is a checked checkbox for 'Enable automatic failover'. At the bottom, there is a 'DNS' section with a checked checkbox for 'Manually configure DNS server', and fields for 'Primary DNS' (8.8.8.8) and 'Secondary DNS' (0.0.0.0). At the very bottom, there are 'Apply' and 'Cancel' buttons. The 'Apply' button is circled in red.

LAN settings
DHCP : OFF
IPv4 address : 192.168.0.1
IPv6 address : 2001:0:1:a2::ec31/64
Subnet mask : 255.255.255.0
Gateway : 192.168.0.254

Enable automatic failover : ☒

**DNS**

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

Apply Cancel

## < 1.9 > Wifi Network Configuration

### < Preparation >

- Make sure the network meet the security WPA2 - Personal or WPA2 - Enterprise.
- PDU dongle IPD-03-S is well connected to the iPDU and powered on.
- Login IPD-03-S web UI via LAN 1/ LAN 2 to configure the WIFI network.



3rd party WIFI kit is not compatible to InfraPower.

Make sure IPD-WIFI has been used for the WIFI network connection.

### ( I ) Wifi Static IP setting

**Step 1.** Take out the membrane from the IP dongle and the Wifi USB port will be found.  
Then, connect the USB wireless adapter to the IP dongle.  
( Details please refer to < 1.17 > Optional Accessories - Wifi Kit )



**Step 2.** Click “ Scan Wifi “ to search the available WiFi network

**Network**

**LAN 1 settings**  
DHCP :    
IPv4 address :   
IPv6 address :   
Subnet mask :   
Gateway :

**LAN 2 settings**  
DHCP :    
IPv4 address :   
IPv6 address :   
Subnet mask :   
Gateway :


☐ Enable automatic failover :

**WiFi settings**  
ESSID :     
Security :    
DHCP :    
IPv4 address :   
IPv6 address :   
Subnet mask :   
Gateway :

**DNS**  
☒ Manually configure DNS server :  
Primary DNS :   
Secondary DNS :

## < 1.9 > Wifi Network Configuration

**Step 3.** Select the appropriate network from the pull down menu of “ ESSID “



**Network**

**LAN 1 settings**

DHCP : OFF ▾

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:b01/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

**LAN 2 settings**

DHCP : OFF ▾

IPv4 address : 192.168.0.2

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**

ESSID : NONE ▾ Scan Wifi

Security : 37F

DHCP : Austin-Hughes ADServer

IPv4 address : Austin-Hughes User

IPv6 address : Austin-hughes Guest

Subnet mask : JTF3G6RHT7

Gateway : Oracle

DNS


Manually configure DNS server : ☐

Primary DNS : Oracle\_5G

Secondary DNS : RnDTest\_2.4G

Apply Cancel

**Step 4.** Select the security type ( NONE / WPA2-Personal / WPA2-Enterprise )



**Network**

**LAN 1 settings**

DHCP : OFF ▾

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:b01/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

**LAN 2 settings**

DHCP : OFF ▾

IPv4 address : 192.168.0.2

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**

ESSID : Austin-Hughes ADServer ▾ Scan Wifi

Security : None ▾

DHCP : None

IPv4 address : WPA2-Personal

IPv6 address : WPA2-Enterprise

Subnet mask : not available

Gateway : not available

DNS

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

Apply Cancel

## < 1.9 > Wifi Network Configuration

**Step 5.** Enter “ Username “ ( For security type : WPA2-Enterprise ONLY )

**Network**

**LAN 1 settings**  
DHCP : OFF  
IPv4 address : 192.168.11.1  
IPv6 address : ::ffff:c0a8:b01/120  
Subnet mask : 255.255.255.0  
Gateway : 192.168.11.254

**LAN 2 settings**  
DHCP : OFF  
IPv4 address : 192.168.0.2  
IPv6 address : ::ffff:c0a8:1/120  
Subnet mask : 255.255.255.0  
Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**  
ESSID : Austin-Hughes ADServer   
Security : WPA2-Enterprise  
Username : NONE  
Password :  
DHCP : OFF  
IPv4 address : 192.168.111.1  
IPv6 address : ::ffff:c0a8:6f01/120  
Subnet mask : 255.255.255.0  
Gateway : 192.168.111.254

**DNS**  
Manually configure DNS server : ☒  
Primary DNS : 8.8.8.8  
Secondary DNS : 0.0.0.0

**Step 6.** Enter “ Password “

**Step 7.** Select “ DHCP “ to “ OFF “. Default is “ ON “


**Step 8.** Enter “ IPv4 address “ , “ IPv6 address “ , “ Subnet mask “ , “ Gateway “ & Click “ Apply “ to finish the above settings.



## < 1.9 > Wifi Network Configuration

### ( II ) Wifi DHCP setting

**Step 1.** Take out the membrane from the IP dongle and the Wifi USB port will be found.  
Then, connect the USB wireless adapter to the IP dongle.  
( Details please refer to < 1.17 > Optional Accessories - Wifi Kit )



**Step 2.** Click “ Scan Wifi “ to search the available WiFi network

**Network**

**LAN 1 settings**  
DHCP : OFF  
IPv4 address : 192.168.11.1  
IPv6 address : ::ffff:c0a8:b01/120  
Subnet mask : 255.255.255.0  
Gateway : 192.168.11.254

**LAN 2 settings**  
DHCP : OFF  
IPv4 address : 192.168.0.2  
IPv6 address : ::ffff:c0a8:1/120  
Subnet mask : 255.255.255.0  
Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**  
ESSID : NONE  
Security : None  
DHCP : ON  
IPv4 address : not available  
IPv6 address : not available  
Subnet mask : not available  
Gateway : not available

**DNS**  
Manually configure DNS server : ☒  
Primary DNS : 8.8.8.8  
Secondary DNS : 0.0.0.0

Scan Wifi

ApplyCancel

## < 1.9 > Wifi Network Configuration

**Step 3.** Select the appropriate network from the pull down menu of “ ESSID “

**Network**

**LAN 1 settings**

DHCP : OFF ▾

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:b01/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

**LAN 2 settings**

DHCP : OFF ▾

IPv4 address : 192.168.0.2

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**

ESSID : NONE ▾ Scan Wifi

Security : Austin-Hughes ADServer

DHCP : Austin-Hughes User

IPv4 address : Austin-hughes Guest

IPv6 address : JTF3G6RHT7

Subnet mask : Oracle

Gateway : Oracle\_5G

DNS : RnDTest\_2.4G

Manually configure DNS server : RnDTest\_5G

Primary DNS : TP-LINK\_FA204E

Secondary DNS : TP-LINK\_POCKET\_3020\_4D504A

Apply Cancel

**Step 4.** Select the security type ( NONE / WPA2-Personal / WPA2-Enterprise )

**Network**

**LAN 1 settings**

DHCP : OFF ▾

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:b01/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

**LAN 2 settings**

DHCP : OFF ▾

IPv4 address : 192.168.0.2

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**

ESSID : Austin-Hughes ADServer ▾ Scan Wifi

Security : None ▾

DHCP : None

IPv4 address : WPA2-Personal

IPv6 address : WPA2-Enterprise

Subnet mask : not available

Gateway : not available

DNS : not available

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

Apply Cancel

## < 1.9 > Wifi Network Configuration

**Step 5.** Enter “ Username “ ( For security type : WPA2-Enterprise ONLY )

**Network**

**LAN 1 settings**

DHCP : OFF

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:101/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

**LAN 2 settings**

DHCP : OFF

IPv4 address : 192.168.0.2

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Enable automatic failover : ☐

**WiFi settings**

ESSID : Austin-Hughes ADServer Scan Wifi

Security : WPA2-Enterprise

Username : NONE

Password :

DHCP : ON

IPv4 address : not available

IPv6 address : not available

Subnet mask : not available

Gateway : not available

**DNS**

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0


Apply Cancel

**Step 6.** Enter “ Password “

**Step 7.** Select “ DHCP “ to “ ON “. Default is “ ON “

**Step 8.** Click “ Apply “ to finish the above settings.

**Step 9.** Select “ Firmware “ from the left navigation pane



## < 1.9 > Wifi Network Configuration

**Step 10.** Record the “ MAC address “ of the Wifi kit

**Firmware**

**Device information**

Device :

IP Dongle PPS-03s

Firmware version:

IPD-03-FW-v2.0

Hardware revision:

2.0

---

**LAN 1 information**

IPv4 address

: 192.168.1.67

IPv6 address

: ::ffff:c0a8:b01/120

MAC address

: 20:0A:0D:60:01:9F

---

**LAN 2 information**

IPv4 address

: 192.168.0.1

IPv6 address

: ::ffff:c0a8:1/120

MAC address

: 20:0A:0D:60:01:9E

---

**Wifi information**

IPv4 address

: 192.168.1.210

IPv6 address

: ::ffff:c0a8:2/120

MAC address

: 20:0A:0D:60:01:F0

---

**Upgrade firmware**

File path :

Browse

**Warning :** Upgrading firmware may take a few minutes,  
please don't turn off the power or press the reset button.

Upgrade

Cancel


**Step 11.** Assign an IP address of the Wifi kit from your DHCP server.

## < 1.10 > Login

In < **Login** >, you can login the IP dongle WEBUI by “ **Local User** ” or “ **Domain/LDAP** ” login.  
( Default login : “ **Local User** ” )


Local User :

- Change “ **Login name** ” OR “ **Password** ”
- Re-enter password in “ **Confirm password** ”
- Click “ **Apply** ” and “ **OK** ” on the pop up window to make changes effective



Domain/LDAP :

- Default Join Domain is “ **Disable** ”
- Enable “ **Join Domain** ” only when you want to login the IP dongle WEBUI by AD server
- Enter “ **AD Server** ”, “ **Account Login** ” & “ **Password** ”
- Click “ **Apply** ” and “ **OK** ” on the pop up window to make changes effective
- You can now go to “ **Domain Users** ” to assign access right to the “ **Domain Users** ” or the “ **Domain Group** ”



## < 1.10 > Login

In “ **Domain Users Setting** ”,

- Click “ **Update domain data** ” to update domain user list.
- Assign access right ( No access / Allow / Deny ) to “ **Domain Users** ” and click “ **Apply** ” .
- The Domain User assigned “ **Allow** ” access right can login the IP dongle WEBUI.

**Domain Users Setting**

Account Login : administrator@austin-hughes.dc

Password : .....

Update user list

Domain User ▾

No.	Domain User	No access	Allow	Deny
1.	Administrator	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
2.	DefaultAccount	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
3.	Guest	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
4.	databaseadmin	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>

Apply Cancel

In “ **Domain Users Setting** ”,

- Click “ **Update domain data** ” to update domain group list.
- Assign access right ( No access / Allow ) to “ **Domain Group** ” and click “ **Apply** ” .
- The Users of the Domain Group assigned “ **Allow** ” access right can login the IP dongle WEBUI.

**Domain Users Setting**

Account Login : administrator@austin-hughes.dc

Password : .....

Update user list

Domain Group ▾

No.	Domain Group	No access	Allow
1.	Access Control Assistance Operators	<input checked="" type="radio"/>	<input type="radio"/>
2.	Account Operators	<input type="radio"/>	<input checked="" type="radio"/>
3.	Administrators	<input checked="" type="radio"/>	<input type="radio"/>
4.	Allowed RODC Password Replication Group	<input checked="" type="radio"/>	<input type="radio"/>
5.	Backup Operators	<input checked="" type="radio"/>	<input type="radio"/>

Apply Cancel

## < 1.10 > Login

Domain/LDAP :

- Default LDAP Authentication is “ **Disable** ”
- Enable “ **LDAP Authentication** ” only when you want to login the IP dongle WEBUI by LDAP server
- Enter “ **LDAP Server** ”,
- Select “ **Protocol** ”( LDAP / LDAPS ). Default is “ **LDAP** ”
- Enter “ **Port** “. Default is “ **389** ”
- Select “ **Encryption** ”( None / SSL ). Default is “ **None** ”
- Enter “ **Base DN** ”.
- Enter “ **Account Login** ” & “ **Password** ”.
- Click “ **Apply** ” and “ **OK** ” on the pop up window to make changes effective
- You can now go to “ **LDAP Users** ” to assign access right to the “ **LDAP User** ” or the “ **LDAP Group** ”

**Domain / LDAP**

LDAP ▾

LDAP Authentication : ☒ Enable ☐ Disable

LDAP Server :

Protocol : 

LDAP ▾

Port :

Encryption : 

None ▾

Base DN :

Account Login :

Password : 

••••••••

👁

Apply

Cancel



## < 1.10 > Login

In “LDAP Access Setting”,

- Click “**Update domain data**” to update domain user list.
- Assign access right ( No access / Allow / Deny ) to “**LDAP User**” and click “**Apply**”.
- The LDAP User assigned “**Allow**” access right can login the IP dongle WEBUI.

**LDAP Access Setting**

Account Login :

Password :

LDAP User ▼

No.	LDAP User	No access	Allow	Deny
1.	Administrator	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
2.	DefaultAccount	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
3.	Guest	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>
4.	databaseadmin	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>

In “LDAP Access Setting”,

- Click “**Update domain data**” to update domain user list.
- Assign access right ( No access / Allow / Deny ) to “**LDAP Group**” and click “**Apply**”.
- The LDAP Group assigned “**Allow**” access right can login the IP dongle WEBUI.

**LDAP Access Setting**

Account Login :

Password :

LDAP Group ▼

No.	LDAP Group	No access	Allow
1.	Access Control Assistance Operators	<input checked="" type="radio"/>	<input type="radio"/>
2.	Account Operators	<input type="radio"/>	<input checked="" type="radio"/>
3.	Administrators	<input checked="" type="radio"/>	<input type="radio"/>
4.	Allowed RODC Password Replication Group	<input checked="" type="radio"/>	<input type="radio"/>
5.	Backup Operators	<input checked="" type="radio"/>	<input type="radio"/>

## < 1.11 > SNMP Setup

The IP dongle can manage the connected single & three phase intelligent PDUs in a single daisy-chain up to 32 levels via SNMP v1/v2 or v3 ( Simple Network Management Protocol )

### ( I ). Accessing MIB Files

**Step 1.** Click the following link to go to the mangement software download page :

<http://www.austin-hughes.com/resources/infrapower/software>

**Step 2.** Select the appropriate MIB file of the PDU series

### ( II ). Enabling SNMP Support

i. The following steps summarize how to enable the IP Dongle for SNMP v1 / v2 support.

**Step 1.** Connect the IP Dongle to a computer. ( Please refer to < 1.4 > IP dongle configuration )


**Step 2.** Open the MS Edge

**Step 3.** Enter the configured IP Dongle address into the address bar.

Default IP address of LAN 1 is “ **192.168.11.1** “

Default IP address of LAN 2 is “ **192.168.0.1** “

**Step 4.** Enter “ **Login name** “ & “ **Password** “.




A screenshot of a login dialog box. It contains two text input fields: the first is labeled 'Login name' and the second is labeled 'Password'. Below these fields are two buttons: 'Login' and 'Cancel'.

- Default login name: 00000000
- Password: the one you set in Step 7 of < 1.4 > IP Dongle Configuration.

## < 1.11 > SNMP Setup

**Step 5.** Select the **SNMP** from the left navigation pane



**Step 6.** The **SNMP** Settings window appears as below:

The image is a screenshot of the 'SNMP' configuration window. It has a title bar 'SNMP'. Under 'SNMP agent', there are radio buttons for 'Enable' and 'Disable', with 'Disable' selected. Below are input fields for 'SNMP version' (set to 'v1/v2'), 'SNMP port' (set to '161'), 'sysContact' (set to 'human.being<nobody@but.you>'), 'sysLocation' (set to 'Earth'), and 'sysName' (set to 'PPS-03-S'). The 'SNMP configuration' section has input fields for 'Read community' (set to 'public') and 'Write community' (set to 'private'). At the bottom, there are three identical sections for 'Station 1', 'Station 2', and 'Station 3'. Each station has radio buttons for 'Deactivate' (selected) and 'Activate'. Below each station are input fields for 'Trap Station IP' (set to '192.168.0.254'), 'Trap port' (set to '162'), and 'Trap community' (set to 'private'). At the very bottom are 'Apply' and 'Cancel' buttons.

**Step 7.** Click “ **Enable** ” in “ **SNMP agent** ” to start the SNMP agent service

**Step 8.** Select “ **v1/v2** ” in “ **SNMP version** ”

**Step 9.** Input “ **SNMP port** “. Default is 161

**Step 10.** Input “ **sysContact** “. Default is human.being<nobody@but.you>

**Step 11.** Input “ **sysLocation** “. Default is Earth

**Step 12.** Input “ **sysName** “. Default is A320D

**Step 13.** Input “ **Read Community** “. Default is public

**Step 14.** Input “ **Write Community** “. Default is private

**Step 15.** Click “ **Activate** ” in Station 1 to enable the trap service

**Step 16.** Input “ **Trap Station IP** “ , “ **Trap Port** “ & “ **Trap Community** “ of Station 1

**Step 17.** Repeat Step 14 & 15 for Station 2 & 3

**Step 18.** Click “ **Apply** ” to finish the SNMP v1 / v2 settings

## < 1.11 > SNMP Setup

ii. The following steps summarize how to enable the IP Dongle for SNMP v3 support.

**Step 1.** Connect the IP dongle to a computer. ( Please refer to < 1.4 > IP dongle configuration )


**Step 2.** Open MS Edge

**Step 3.** Enter the configured IP Dongle address into the address bar.

Default IP address of LAN 1 is “ 192.168.11.1 ”


Default IP address of LAN 2 is “ 192.168.0.1 ”

**Step 4.** Enter “ **Login name** ” & “ **Password** ”.




- Default login name: 00000000
- Password: the one you set in Step 7 of < 1.4 > IP Dongle Configuration.

**Step 5.** Select SNMP from the left navigation pane



**Step 6.** The **SNMP** Settings window appears as below:



**SNMP**

**SNMP agent :** ☒ Enable ☐ Disable

SNMP version : v1/v2 ▼

SNMP port : 161

sysContact : human.being<nobody@but.you>

sysLocation : Earth

sysName : PPS-03-S

**SNMP configuration**

Read community : public

Write community : private

**Station 1 :** ☐ Deactivate ☒ Activate

Trap Station IP : 192.168.1.113

Trap port : 162

Trap community : private

**Station 2 :** ☒ Deactivate ☐ Activate

Trap Station IP : 192.168.0.254

Trap port : 162

Trap community : private

**Station 3 :** ☒ Deactivate ☐ Activate

Trap Station IP : 192.168.0.254

Trap port : 162

Trap community : private

Apply Cancel

## < 1.11 > SNMP Setup

**Step 7.** Click “ **Enable** ” in “ **SNMP agent** ” to start the SNMP agent service

**Step 8.** Select “ **v3** ” in “ **SNMP version** ” & the SNMP v3 settings window appears as below :

**SNMP**

**SNMP agent :** ☒ Enable ☐ Disable

SNMP version : **v3**

SNMP port : 161

sysContact : human.being<nobody@but.you>

sysLocation : Earth

sysName : PPS-03-S

**SNMP configuration**

User 1 :	User 2 :	User 3 :
<input type="radio"/> Deactivate <input checked="" type="radio"/> Activate	<input checked="" type="radio"/> Deactivate <input type="radio"/> Activate	<input checked="" type="radio"/> Deactivate <input type="radio"/> Activate
User role : read only	User role : read only	User role : read only
USM user : usm_user1	USM user : usm_user2	USM user : usm_user3
Auth algorithm : None	Auth algorithm : None	Auth algorithm : None
Auth password : *****	Auth password : *****	Auth password : *****
Privacy algorithm : None	Privacy algorithm : None	Privacy algorithm : None
Privacy password : *****	Privacy password : *****	Privacy password : *****
SNMP trap : Disabled	SNMP trap : Disabled	SNMP trap : Disabled
Trap Station IP : 192.168.1.113	Trap Station IP : 192.168.0.254	Trap Station IP : 192.168.0.254
Trap port : 162	Trap port : 162	Trap port : 162

Apply Cancel

**Step 9.** Input “ **SNMP port** “. Default is 161

**Step 10.** Input “ **sysContact** “. Default is human.being<nobody@but.you>

**Step 11.** Input “ **sysLocation** “. Default is Earth

**Step 12.** Input “ **sysName** “. Default is A320D

**Step 13.** Click “ **Activate** ” in User 1

**Step 14.** Select “ **Read Only** ” or “ **Read & Write** ” in User role :

**Step 15.** Input the name of “ **USM user** ” . Default is usm\_user1

**Step 16.** Select “ **None / MD5 / SHA** ” in “ **Auth algorithm** ”.  
If you select “ **Read & Write** ” in “ **User role:** ” ,  
you **MUST** select “ **MD5 / SHA** ” in “ **Auth algorithm** ”

**Step 17.** Input the “ **Auth password:** ” Default is “ 00000000 ”

**Step 18.** Select “ **None / DES / AES / AES192 / AES256** ” in “ **Privacy algorithm** ”.  
If the Auth algorithm is “ **NONE** ” , NO privacy algorithm can be selected.

**Step 19.** Input the “ **Privacy password** ”

**Step 20.** If you want to receive trap message, select “ **Enable** ” in **SNMP trap**

**Step 21.** Input the “ **Trap Station IP** ” & “ **Trap port** ”


**Step 22.** Repeat step 12 to 20 for User 2 & 3

**Step 23.** Click “ **Apply** ” to finish the SNMP v3 settings.

## < 1.11 > SNMP Setup

### ( III ). SNMP Traps Setting

After enable SNMP, you can click “ SNMP Traps ” to go to the “ SNMP Traps Setting ” page



Below is the default setting for each PDU SNMP trap.

You can set the SNMP trap option and Click “ Apply ” to finish the settings.

### SNMP Traps Setting

pduConnectionLost :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
pduConnectionRecovered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
circuitLoadEventTriggered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
circuitLoadEventCleared :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
circuitBreakerTripped :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
circuitBreakerRecovered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
sensorConnectionLost :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
sensorConnectionRecovered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
tempSensorEventTriggered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
tempSensorEventCleared :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
humiSensorEventTriggered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
humiSensorEventCleared :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
rcmSensorConnectionLost :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
rcmSensorConnectionRecovered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
rcmSensorEventTriggered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
rcmSensorEventCleared :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
smokeSensorEventTriggered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
smokeSensorEventCleared :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	
doorSensorEventTriggered :	<input type="radio"/> Disable	<input checked="" type="radio"/> Once	<input type="radio"/> Cyclic
doorSensorEventCleared :	<input type="radio"/> Disable	<input checked="" type="radio"/> Enable	

## < 1.12 > Notification

In < **Notification** > , you can configure the alarm email server & max. 5 email recipients to receive alarm notifications from the IP dongle.

Default is “ **Disable** ”.

**Step 1.** “ **Enable** ” alarm email

**Step 2.** Enter “ **SMTP server** ” and “ **SMTP port** ”. Default is “ **Port 25** ”

**Step 3.** “ **Enable** ” or “ **Disable** ” the “ **SMTP authentication** “. Default is “ **Disable** ”

**Step 4.** Enter “ **User name** ” and “ **Password** ” when SMTP authentication is enabled

**Step 5.** Select the “ **secure connection** ” ( None, SSL / TLS & STARTTLS ). Default is “ **None** ”

**Step 6.** Enter the “ **Sender Name** ” and “ **Sender Email** ”

**Step 7.** Enter the “ **Alarm Interval** ”. ( Min. 10, Max. 60 mins )

**Step 8.** Enter the alarm recipient email account in “ **Recipient 01** ”

**Step 9.** Repeat step 8 for other recipients

**Step 10.** Click “ **Apply** ” to finish the alarm email server setting

**Email Notification**

Alarm email : ☒ Enable ☐ Disable

SMTP server : smtp.austin-hughes.com

SMTP port : 25 ( Default: 25 )

Authentication : Enable ▾

User name : sender@mail.com

Password : \*\*\*\*\*

Secure connection : None ▾

Sender name : Email alarm

Sender email : sender@mail.com

Interval (minutes) : 10 (Min. 10, Max. 60)

Recipient 01 : recipient-01@mail.com

Recipient 02 :

Recipient 03 :

Recipient 04 :

Recipient 05 :

Apply Cancel



## < 1.13 > Syslog

In < **Syslog** > , you can view the latest 2000 device and system log

Syslog			
#	Type	Date & Time	Event
1	Device	2020-09-07 11:55:39	Door alarm (open) - PDU level 24 - Door sensor 1(sensor_location )
2	Device	2020-09-07 11:55:38	Sensor reconnection - PDU level 24 - door sensor 1(sensor_location )
3	Device	2020-09-07 11:55:28	Sensor reconnection - PDU level 23 - T sensor 1(TH_Sensor_01 )
4	WebUI	2020-09-07 11:52:11	[Email Notification] has been Updated
5	Device	2020-09-07 11:50:11	Activate(1) T sensor - PDU level 25 - sensor 2 (sensor_location )
6	Device	2020-09-07 11:49:50	Deactivate(0) T sensor - PDU level 25 - sensor 1 (sensor_location )
7	Device	2020-09-07 11:48:37	Sensor disconnection - PDU level 25 - T sensor 2(sensor_location )
8	Device	2020-09-07 11:48:27	Activate(1) T sensor - PDU level 25 - sensor 2 (sensor_location )
9	Device	2020-09-07 11:48:08	Deactivate(0) T sensor - PDU level 25 - sensor 1 (sensor_location )
10	WebUI	2020-09-07 11:47:31	[Email Notification] has been Updated
11	WebUI	2020-09-07 11:47:16	[Email Notification] has been Updated
12	Device	2020-09-07 11:34:06	Sensor disconnection - PDU level 25 - T sensor 1(sensor_location )
13	Device	2020-09-07 11:33:55	Activate(1) T sensor - PDU level 25 - sensor 1 (sensor_location )
14	WebUI	2020-09-07 11:33:37	[Email Notification] has been Updated
15	Device	2020-09-07 10:43:29	Activate(1) T sensor - PDU level 24 - sensor 2 (sensor_location )
16	Device	2020-09-07 10:43:20	Sensor disconnection - PDU level 24 - door sensor 1(sensor_location )

## < 1.14 > IP Dongle Firmware Upgrade

### < Firmware Upgrade >

For function enhancement of IP dongle WEBUI, please take the following steps to remotely upgrade the IP Dongle firmware :

**Step 1.** Click the following link to go to the mangement software download page :

<http://www.austin-hughes.com/resources/infrapower/software>

**Step 2.** Select the appropriate IP Dongle firmware file of the PDU series

**Step 3.** Connect the IP Dongle to the computer. ( Please refer to < 1.4 > IP dongle configuration )

**Step 4.** Open the MS Edge

**Step 5.** Enter the configured IP Dongle address into the Address bar.

Default IP address of LAN 1 is “ **192.168.11.1** ”

Default IP address of LAN 2 is “ **192.168.0.1** ”

**Step 6.** Enter “ **Login name** ” & “ **Password** ”.



Login name

Password

- Default login name: 00000000
- Password: the one you set in Step 7 of < 1.4 > IP Dongle Configuration.

**Step 7.** Select the Firmware from the left navigation pane



## < 1.14 > IP Dongle Firmware Upgrade

**Step 8.** The firmware upgrade window appears as below :

**Firmware**

**Device information**

Device name : IP Dongle PPS-03s

Firmware version : IPD-03-FW-v1

Hardware revision : 2.0

---

**LAN 1 information**

IPv4 address : 192.168.1.62

IPv6 address : 2001:0:1:a2::ec11/64

MAC address : 20:0A:0D:FF:FF:02

---

**LAN 2 information**

IPv4 address : 192.168.0.2

IPv6 address : 2001:0:1:a2::ec01/64

MAC address : 20:0A:0D:FF:FF:01

---

**Upgrade firmware**

File path :

**Warning :** Upgrading firmware may take a few minutes,  
please don't turn off the power or press the reset button.

**Step 9.** Click “ **Browse** ” and select the firmware file ( xxx.zip for firmware version IPD-03-FW-v1 / xxx.enc for firmware version IPD-03-FW-V1.1 or above ) from the specific path in the pop up window and Click “ **Open** ”


**Step 10.** Click “ **Upgrade** ” to start the upgrade process. It takes a few minutes to complete.

**Step 11.** Once complete, UI will return to the login page.

## < 1.15 > Bulk Firmware Upgrade

### < Bulk Firmware Upgrade via DHCP/TFTP >

If a TFTP server is available, you can use it to perform firmware upgrade for a huge number of IP dongles ( IPD-03-S ) in the same network.

-  • The feature of bulk firmware upgrade via DHCP/TFTP only works on IPD-03-S directly connected to the network.
- The bulk firmware upgrade can ONLY be performed via IPv4 network.
- Do NOT perform the firmware upgrade via a wireless network connection.

### < Procedure for Bulk Firmware Upgrade >

The bulk firmware upgrade feature only available for IP Dongle ( IPD-03-S ) firmware version v3.0 or above. Ensure the IP Dongle ( IPD-03-S ) firmware is v3.0 or above before you want to perform the upgrade.

### Steps of using DHCP/TFTP for bulk firmware upgrade

**Step 1.** Prepare some or all of the following files:

- Fwupdate.cfg ( always required )
- Devices.csv
- IP Dongle firmware file in .enc format

**Step 2.** Configure your TFTP server properly. See ***TFTP Requirements***

**Step 3.** Put ALL required files into a folder and COPY the folder to the TFTP root directory

**Step 4.** Properly configure your DHCP server so that it refers to the file “ **fwupdate.cfg** ” on the TFTP server for your IP Dongle. See ***DHCP IPv4 Configuration in Windows***

**Step 5.** Make sure all of the IP Dongles use DHCP as the IP configuration method and have been directly connected to the network.



The default IP configuration of IP Dongle is “ **STATIC** ”

## < 1.15 > Bulk Firmware Upgrade

**Step 6.** Reboot the IP Dongles. The DHCP server will execute the commands in the “ **fwupdate.cfg** ” file on the TFTP server to upgrade those IP Dongles supporting DHCP in the same network. You can Click “ **Reboot IP Dongle** ” in “ System ” of IP Dongle.

The screenshot shows the 'IP Dongle' configuration page. On the left is a sidebar menu with categories: Device (Status, Details, Sensor), Setting (System, Network, Login, Local User, Domain/LDAP, SNMP, Notification, Syslog, Firmware). The 'System' setting is selected. The main content area has sections: 'Name' (default\_ipd\_name), 'Location' (default\_ipd\_loc), 'Temperature unit' (checked for °C, unchecked for °F), 'Date & Time' (2023-02-07 15:21:59, Time zone: GMT+08:00, Time setting: Manually, Date: 2023-02-07, Time: 15:21:59), and 'Web Access' (Protocol: HTTPS, Port: 443, SSL Certificate: Use default certificate). At the bottom are four buttons: 'Apply', 'Cancel', 'Reset to Factory Default', and 'Reboot IP Dongle' (which is circled in red).



You must enable firmware upgrade via DHCP in SSH ( default is ENABLED ) and input the username and password for bulk firmware upgrade in the “ **fwupdate.cfg** ” file. You can change the username and password for bulk firmware upgrade via SSH. **See Configuration of username / password for bulk firmware upgrade.**

## < 1.15 > Bulk Firmware Upgrade

### Configuration of username / password for bulk firmware upgrade

**Step 1.** Access the SSH using putty

**Step 2.** Input the login name and password to login the CLI.

```
login as: 00000000
00000000@192.168.1.234's password:

*****
*                               *
*          System Status        *
*                               *
*****
* Firmware                      *
*   -FirmwareID   : IPD-03-FW-v3.0 *
*   -Build_info   : 20230131      *
*                               *
* Device              *
*   -Model         : IP Dongle PPS-03s *
*   -Name          : default_ipd_name *
*   -Location      : default_ipd_loc. *
*   -Temp. unit    : C              *
*                               *
* Network settings *
*   -Auto failover: Disable *
*   [ LAN 1 (1000) ] *
*   -LAN 1 link    : down *
*   -DHCP          : Disable *
*   -MAC address   : 20:0A:0D:FF:BE:9A *
*   -IPv6 address  : ::ffff:192.168.11.1/120 *
```

**Step 3.** Select “ (U) Firmware upgrade ” and “ Enter ”

```
*   -IPM-04 support : Yes *
*   -SNMP agent     : Disable *
*   -WebUI HTTPS    : Enable TLSv1/1.2/1.3 *
*   -FTP server     : Disable *
*   -UDP discovery  : Enable *
*   -Telnet         : Enable *
*   -SSH console    : Enable *
*   -Service account : Disable *
*   -Firmware upgrade: Enable DHCP onBoot *
*****
*****
*                               *
*          Menu (Ver. 20.06.19) *
*                               *
*****
* (0) Show system status *
* (1) Change System settings *
* (2) Change Login settings *
* (5) Reboot *
* (U) Firmware upgrade *
* (F) Reset to factory default and reboot *
* (?) This menu *
* (Q) Exit *
*****
Input menu item number(? for help):
```

## < 1.15 > Bulk Firmware Upgrade

**Step 4.** Select “ (5) Change firmware upgrade authentication ” and “ Enter ”

```
*          Menu (Ver. 20.06.19)          *
*****
*  (0) Show system status                *
*  (1) Change System settings            *
*  (2) Change Login settings             *
*  (5) Reboot                           *
*  (U) Firmware upgrade                 *
*  (F) Reset to factory default and reboot *
*  (?) This menu                         *
*  (Q) Exit                             *
*****
Input menu item number(? for help):U

*****
*          Menu (Ver. 20.06.19)          *
*****
*  (0) Show system status                *
*  (1) Enable/Disable firmware upgrade via DHCP *
*  (5) Change firmware upgrade authentication *
*  (R) Reboot                           *
*  (?) This menu                         *
*  (Q) Exit                             *
*****
Input menu item number(? for help):
```

**Step 5.** Select “ (1) Change authentication name ” or “ (2) Change authentication password ” to change the username or password for bulk firmware upgrade purpose.

```
Input menu item number(? for help):U

*****
*          Menu (Ver. 20.06.19)          *
*****
*  (0) Show system status                *
*  (1) Enable/Disable firmware upgrade via DHCP *
*  (5) Change firmware upgrade authentication *
*  (R) Reboot                           *
*  (?) This menu                         *
*  (Q) Exit                             *
*****
Input menu item number(? for help):5

*****
*  Firmware upgrade authentication        *
*****
*  (0) Show system status                *
*  (1) Change authentication name         *
*  (2) Change authentication password     *
*  (?) This menu                         *
*  (Q) Exit                             *
*****
Input menu item number(? for help):
```

## < 1.15 > Bulk Firmware Upgrade

### < TFTP Requirements >

To perform bulk firmware upgrade successfully, your TFTP server must meet the following requirements :


- Able to work with IPv4
- A folder containing all required files is available in the TFTP root directory. The folder name **MUST** be the same as the String value of the Magic code. Details please refer to DHCP IPv4 Configuration in Winodws
- The TFTP server supports the write operation including file creation and upload.

### < DHCP IPv4 Configuration in Windows >


Please follow the procedures below to configure your DHCP server. The illustration below is based on Microsoft Windows Server 2019

**Step 1.** Add a new vendor class for Austin Hughes IP Dongle.

- Right Click the IPv4 node in DHCP to select Define Vendor Classes ( under server manager, select tools > DHCP
- Click “ **Add** ” to add a new vendor class.



- Specify a unique name for this vendor class and type the binary codes of “ **InfraPower** ” in the New Class dialog. The vendor class is named “ **InfraPower** ” in this illustration.






## < 1.15 > Bulk Firmware Upgrade

### Step 2. Define one DHCP standard option – Vendor Class Identifier

- Right Click the IPv4 node in DHCP to select Set Predefined Options.
- Select “ **DHCP Standard Options** ” in the “ **Option class** ” field, and “ **Vendor Class Identifier** ” in the “ **Option name** ” field. Leave the String field blank.



Predefined Options and Values

Option class: DHCP Standard Options

Option name: 060 Vendor Class Identifier

Add... Edit... Delete

Description:


Value

String:

OK Cancel

### Step 3. Add four options to the new vendor class “ **InfraPower** ” in the same dialog. The fourth option is an optional item if the UDP port you set for the TFTP server is NOT 69.

- Select “ **InfraPower** ” in the “ **Option class** ” field.



Predefined Options and Values

Option class: InfraPower

Option name: DHCP Standard Options  
Microsoft Windows 2000 Options  
Microsoft Windows 98 Options  
Microsoft Options  
Raritan PDU  
vInfraBox  
InfraPower


Description:

Value

OK Cancel


## < 1.15 > Bulk Firmware Upgrade

- Click “ **Add** ” to add the first option. Type “ **update-server** ” in the Name field, select String as the data type, and type 1 in the Code field and Click “ **OK** ”.




The dialog box titled "Option Type" has a close button (X) and a help button (?). It contains the following fields: "Class" is set to "InfraPower"; "Name" is "update-server"; "Data type" is a dropdown menu set to "String" with an "Array" checkbox to its right; "Code" is a text box containing the number "1"; and "Description" is an empty text box. At the bottom right, the "OK" button is circled in red, next to a "Cancel" button.

- Click “ **Add** ” to add the second option. Type “ **update-control-file** ” in the Name field, select String as the data type, and type 2 in the Code field and Click “ **OK** ”.



The dialog box titled "Option Type" has a close button (X) and a help button (?). It contains the following fields: "Class" is set to "InfraPower"; "Name" is "update-control-file"; "Data type" is a dropdown menu set to "String" with an "Array" checkbox to its right; "Code" is a text box containing the number "2"; and "Description" is an empty text box. At the bottom right, the "OK" button is circled in red, next to a "Cancel" button.


- Click “ **Add** ” to add the third option. Type “ **update-magic** ” in the Name field, select String as the data type, and type 3 in the Code field and Click “ **OK** ”.



The dialog box titled "Option Type" has a close button (X) and a help button (?). It contains the following fields: "Class" is set to "InfraPower"; "Name" is "update-magic"; "Data type" is a dropdown menu set to "String" with an "Array" checkbox to its right; "Code" is a text box containing the number "3"; and "Description" is an empty text box. At the bottom right, the "OK" button is circled in red, next to a "Cancel" button.

## < 1.15 > Bulk Firmware Upgrade


- Click “ **Add** ” to add the fourth option. Type “ **update-port** ” in the Name field, select String as the data type, and type 4 in the Code field and Click “ **OK** ”.



The 'Option Type' dialog box is shown. It has a title bar with a question mark and a close button. The 'Class' is set to 'InfraPower'. The 'Name' field contains 'update-port'. The 'Data type' is set to 'String' with a dropdown arrow, and there is an unchecked 'Array' checkbox. The 'Code' field contains '4'. The 'Description' field is empty. At the bottom, the 'OK' button is circled in red, and the 'Cancel' button is to its right.


**Step 4.** Create a new policy associated with the “ **InfraPower** ” vendor class.

- Right Click the Policies node under IPv4 to select New Policy.
- Specify a policy name and click “ **Next** ”. The policy is named “ **InfraPower** ” in this illustration.



The 'DHCP Policy Configuration Wizard' is shown. It has a title bar and a subtitle 'Policy based IP Address and Option Assignment'. Below this, there is explanatory text about distributing settings. The 'Policy Name' field contains 'InfraPower' and the 'Description' field is empty. At the bottom, the 'Next >' button is circled in red, with '< Back' and 'Cancel' buttons to its left and right respectively.

- Click “ **Add** ” to add a new condition
- Select the vendor class “ **InfraPower** ” in the Value field, click “ **Add** ” and then “ **OK** ”.



The 'Add/Edit Condition' dialog box is shown. It has a title bar with a question mark and a close button. The 'Criteria' is set to 'Vendor Class' and the 'Operator' is set to 'Equals'. Under 'Value(s)', the 'Value' field contains 'InfraPower'. There are 'Add' and 'Remove' buttons next to the 'Value' field. Below the 'Value' field, there are checkboxes for 'Prefix wildcard(\*)' and 'Append wildcard(\*)', both of which are unchecked. At the bottom, the 'Ok' button is circled in red, and the 'Cancel' button is to its right.

## < 1.15 > Bulk Firmware Upgrade

- Click “ **Next** ”.
- Select “ **DHCP Standard Options** ” in the “ **Vendor class** ” field, select “ **060 Vendor Class Identifier** ” from the Available Options list, and type “ **InfraPower** ” in the “ **String value** ” field.

The screenshot shows the 'DHCP Policy Configuration Wizard' window. At the top, it says 'Configure settings for the policy' and 'If the conditions specified in the policy match a client request, the settings will be applied.' Below this, the 'Vendor class' dropdown is set to 'DHCP Standard Options'. Under 'Available Options', the '060 Vendor Class Identifier' is selected with a checkmark. The 'Data entry' section has a 'String value' field containing 'InfraPower'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

Available Options	Description
<input checked="" type="checkbox"/> 060 Vendor Class Identifier	
<input type="checkbox"/> 064 NIS+ Domain Name	The name of the client's NIS+
<input type="checkbox"/> 065 NIS+ Servers	A list of IP addresses indicatinc

- Select the “ **InfraPower** ” in the “ **Vendor class** ” field, select “ **001 update-server** ” from the Available Options list, and type your TFTP server’s IPv4 address in the “ **String value** ” field.

The screenshot shows the 'DHCP Policy Configuration Wizard' window. At the top, it says 'Configure settings for the policy' and 'If the conditions specified in the policy match a client request, the settings will be applied.' Below this, the 'Vendor class' dropdown is set to 'InfraPower'. Under 'Available Options', the '001 update-server' is selected with a checkmark. The 'Data entry' section has a 'String value' field containing '192.168.0.1'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

Available Options	Description
<input checked="" type="checkbox"/> 001 update-server	
<input type="checkbox"/> 002 update-control-file	
<input type="checkbox"/> 003 update-magic	
<input type="checkbox"/> 004 vendorclass	vendorclass

## < 1.15 > Bulk Firmware Upgrade

- Select “ **002 update-control-file** ” from the Available Options list, and type the filename “ **fwupdate.cfg** ” in the “ **String value** ” field.

DHCP Policy Configuration Wizard

**Configure settings for the policy**  
If the conditions specified in the policy match a client request, the settings will be applied.

Vendor class: InfraPower

Available Options	Description
<input checked="" type="checkbox"/> 001 update-server	
<input checked="" type="checkbox"/> 002 update-control-file	
<input type="checkbox"/> 003 update-magic	
<input type="checkbox"/> 004 vendorclass	vendorclass

Data entry

String value:  
fwupdate.cfg

< Back Next > Cancel

- Select “ **003 update-magic** ” from the Available Options list, and type folder name of the files you stored in the root directory of the TFTP server in the “ **String value** ” field. This String value is the magic code to prevent the fwupdate.cfg commands from being executed repeatedly.

DHCP Policy Configuration Wizard

**Configure settings for the policy**  
If the conditions specified in the policy match a client request, the settings will be applied.

Vendor class: InfraPower

Available Options	Description
<input checked="" type="checkbox"/> 001 update-server	
<input checked="" type="checkbox"/> 002 update-control-file	
<input checked="" type="checkbox"/> 003 update-magic	
<input type="checkbox"/> 004 vendorclass	vendorclass

Data entry

String value:  
IPD-03-FW-3.0-2020207


< Back Next > Cancel



The magic code is transmitted to and stored in IP Dongle at the time of executing the “ **fwupdate.cfg** ” commands. The DHCP/TFTP operation is triggered **ONLY** when there is a mismatch between the magic code in DHCP and the one stored in the IP Dongle. Therefore, you must modify the magic code’s value in DHCP when intending to execute the “ **fwupdate.cfg** ” commands next time.

## < 1.15 > Bulk Firmware Upgrade

- Select “ **004 update-port** ” from the Available Options list, and type UDP port number you set for the TFTP server in the “ **String value** ” field. Port number 69 is used in this illustration.



The screenshot shows the 'DHCP Policy Configuration Wizard' window. At the top, it says 'Configure settings for the policy' and 'If the conditions specified in the policy match a client request, the settings will be applied.' Below this, the 'Vendor class' is set to 'InfraPower'. A table of 'Available Options' is shown with four checked items: '001 update-server', '002 update-control-file', '003 update-magic', and '004 update-port'. Below the table, the 'Data entry' section has a 'String value' field containing '69'. At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'. The 'Next >' button is circled in red.

Available Options	Description
<input checked="" type="checkbox"/> 001 update-server	
<input checked="" type="checkbox"/> 002 update-control-file	
<input checked="" type="checkbox"/> 003 update-magic	
<input checked="" type="checkbox"/> 004 update-port	

Data entry

String value:

69

< Back   **Next >**   Cancel

- Click “ **Next** ” and “ **Finish** ” to complete the setup.

## < 1.15 > Bulk Firmware Upgrade

### Description of Devices.csv


	A	B	C	D	E
1	1	1	20:0A:0D:FF:CA:BF	192.168.0.123	192.168.0.1
2	1	1	20:0A:0D:FF:3C:E6	192.168.0.122	192.168.0.1
3	#--keep this be the last line of this file--				
4					
5					

Column A & B is reserved for future use

Column C is the MAC address of the network interface of the IP Dongle. As the IP Dongle comes with two network interface, we highly recommend to do the bulk firmware upgrade via either one of the network interface.

Column D & E is the IP address of the network interface of the IP Dongle and the TFTP server respectively.

### Description of fwupdate.cfg



```
[UPFWCFG]
user=admin
password=123abc???
logfile=log.txt
device_list=devices.csv
allow_downgrade=yes
force_update=yes
firmware=IPD_03_FW_v3_0.enc
match=mac:3
```

First and second row is the user and password for authentication of bulk firmware upgrade which can be configured via SSH. Details refer to Section “**Configuration of username / password for bulk firmware upgrade**”.

Fourth row tells the TFTP server to generate a log file after bulk firmware upgrade is performed. It is stored at the same location of the fwupdate.cfg and the filename is the same as the MAC address of the IP Dongle.

Fifth row lets IP Dongle to check if its’ MAC address exists in the column 3 of devices.csv to execute the firmware upgrade.

Eighth row is the firmware version you want to upgrade, it MUST be the same as the filename of the firmware stored in the folder under the root directory of the TFTP server.



## < 1.16 > DHCP Setting

**Step 1.** Connect the IP dongle to the computer ( Please refer to < 1.4 > IP dongle configuration )


**Step 2.** Open the MS Edge

**Step 3.** Enter the configured IP Dongle address into the address bar.

Default IP address of LAN 1 is “ **192.168.11.1** ”


Default IP address of LAN 2 is “ **192.168.0.1** ”

**Step 4.** Enter the “ **Login name** ” & “ **Password** ” .

A login dialog box with two input fields: "Login name" and "Password". Below the fields are two buttons: "Login" and "Cancel".


- Default login name: 00000000
- Password: the one you set in Step 7 of < 1.4 > IP Dongle Configuration.

**Step 5.** Select “ **Network** ” from the left navigation pane.




**Step 6.** Dual Lan Mode: Select “ **ON** ” from “ **DHCP** ” of LAN 1 & LAN 2.

Click “ **Apply** ” to save the settings.

A screenshot of the Network settings page. The "Network" title is at the top. Below it are two columns: "LAN 1 settings" and "LAN 2 settings". In the "LAN 1 settings" column, the "DHCP" dropdown is set to "ON" (circled in red). In the "LAN 2 settings" column, the "DHCP" dropdown is also set to "ON" (circled in red). Below these columns is a checkbox for "Enable automatic failover" which is unchecked. Under the "DNS" section, "Manually configure DNS server" is checked. The "Primary DNS" is set to "8.8.8.8" and the "Secondary DNS" is set to "0.0.0.0". At the bottom, the "Apply" button is circled in red, along with a "Cancel" button.

## < 1.16 > DHCP Setting

**Step 7.** Select “ **Firmware** ” from the left navigation pane.



**Step 8.** Record the “ **MAC address** ” of LAN 1 & LAN 2.

The screenshot displays the 'Firmware' configuration page. It is divided into several sections: 'Device information' with fields for Device name (IP Dongle PPS-03s), Firmware version (IPD-03-FW-v1), and Hardware revision (2.0); 'LAN 1 information' with IPv4 address (192.168.1.62), IPv6 address (2001:0:1:a2::ec11/64), and MAC address (20:0A:0D:FF:FF:02, circled in red); 'LAN 2 information' with IPv4 address (192.168.0.2), IPv6 address (2001:0:1:a2::ec01/64), and MAC address (20:0A:0D:FF:FF:01, circled in red); and an 'Upgrade firmware' section with a 'File path' input field and a 'Browse' button. A warning message states: 'Warning : Upgrading firmware may take a few minutes, please don't turn off the power or press the reset button.' At the bottom are 'Upgrade' and 'Cancel' buttons.

**Step 9.** Assign an IP address of LAN 1 & LAN 2 of to the IP Dongle from your DHCP server.

## < 1.16 > DHCP Setting

**Step 10.** Failover Mode: Select “ **ON** ” from “ **DHCP** ” & Click “ **Apply** ” to save the settings.

**Network**

**LAN settings**

DHCP : **ON** ▼

IPv4 address : 192.168.0.1

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Enable automatic failover : ☒

**DNS**

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

**Apply** **Cancel**

**Step 11.** Select “ **Firmware** ” from the left navigation pane.

**Step 12.** Record the “ **MAC address** ”.

### Firmware

#### Device information

Device name : IP Dongle PPS-03s

Firmware version : IPD-03-FW-v1

Hardware revision : 2.0

#### LAN information

IPv4 address : 192.168.1.62

IPv6 address : ::ffff:c0a8:1/120

MAC address : 20:0A:0D:FF:FF:01

#### Upgrade firmware

File path :  **Browse**

**Warning :** Upgrading firmware may take a few minutes,  
please don't turn off the power or press the reset button.

**Upgrade** **Cancel**

**Step 13.** Assign an IP address to the IP Dongle from your DHCP server.

..... **Complete**

## User Guide of 802.1X Authentication

802.1X is an authentication protocol which provides protected authentication for secure network access with the use of a Radius server. It opens ports for network access when an organization authenticates a user's identity and authorizes them for access to the network. The user's identity is determined based on their credentials or certificate, which is confirmed by the RADIUS server.

802.1X authentication function ONLY available at IP Dongle firmware version v3.0 or above.

Before configure the 802.1X authentication, ensure the system clock of the IP Dongle is set up properly. Otherwise, the authentication will fail while the RADIUS server verifies the validity of the certificate. You can go the System of IP Dongle to set up the date and time of the IP Dongle.

Device

Status

• Details

Sensor

Setting

System

Network

Login

• Local User

• Domain/LDAP

SNMP

Notification

Syslog

Firmware

IP Dongle

Name : default\_ipd\_name

Location : default\_ipd\_loc.

Temperature unit : ☒ °C ☐ °F

Date & Time2023-02-09 14:26:26

Time zone : GMT+08:00 ▾

Time setting : Manually ▾

Date (YYYY-MM-DD) : 2023-02-09

Time : 14 ▾ : 26 ▾ : 26 ▾

Web Access

Protocol : HTTPS ▾

Port : 443 ( Default: 443 )

SSL Certificate : ☒ Use default certificate ☐ Use custom certificate

ApplyCancelReset to Factory DefaultReboot IP Dongle

## < 1.17 > 802.1X authentication

Please follow the procedures below to setup the 802.1X authentication in IP Dongle.

### < 802.1X authentication for Wired network >

**Step 1.** Login the IP Dongle WEBUI and go the Network.

**Network**

**LAN 1 settings**

DHCP : OFF ▾

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:b01/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

Authentication : None ▾

Enable automatic failover : ☐

**DNS**

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

Apply Cancel

**LAN 2 settings**

DHCP : OFF ▾

IPv4 address : 192.168.0.1

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Authentication : None ▾

**Step 2.** Click the Authentication pull down menu and you will see the authentication method.

**Network**

**LAN 1 settings**

DHCP : OFF ▾

IPv4 address : 192.168.11.1

IPv6 address : ::ffff:c0a8:b01/120

Subnet mask : 255.255.255.0

Gateway : 192.168.11.254

Authentication : None ▾

Enable automatic failover : ☐

**DNS**

Manually configure DNS server : ☒

Primary DNS : 8.8.8.8

Secondary DNS : 0.0.0.0

Apply Cancel

**LAN 2 settings**

DHCP : OFF ▾

IPv4 address : 192.168.0.110

IPv6 address : ::ffff:c0a8:1/120

Subnet mask : 255.255.255.0

Gateway : 192.168.0.254

Authentication : 

None ▾  
None  
PEAP  
TLS

## < 1.17 > 802.1X authentication

**Step 3.** To use PEAP as authentication method, select PEAP. Then input the “ **Identity** ”, “ **Password** ” and “ **CA certificate** ” in PEM format. You can uncheck “ **Enable CA certificate** ” to bypass the authentication using CA certificate.

Click “ **Apply** ” to save the configuration.

The screenshot shows the 'Network' configuration page. On the left is a sidebar with 'Device' (Status, Details, Sensor) and 'Setting' (System, Network, Login, Local User, Domain/LDAP, SNMP, Notification, Syslog, Firmware). The 'Network' section is active. Under 'LAN 1 settings', DHCP is OFF, and IP settings are 192.168.11.1, ::ffff:c0a8:b01/120, 255.255.255.0, and 192.168.11.254. Under 'LAN 2 settings', DHCP is OFF, IP settings are 192.168.0.110, ::ffff:c0a8:1/120, 255.255.255.0, and 192.168.0.254. Authentication is set to PEAP. Identity and Password fields are empty with red error messages 'Identity is required.' and 'Password is required.'. CA certificate is empty with 'CA cert is required.' and 'Enable CA certificate' is checked. DNS settings show 'Manually configure DNS server' checked with 8.8.8.8 and 0.0.0.0. The 'Apply' button is circled in red.

**Step 4.** To use TLS as authentication method, select TLS. Then input the “ **Identity** ”, “ **Certificate** ”, “ **Private key** ”, “ **Private key password** ” and “ **CA certificate** ”. ( Certificate, private key and CA certificate are in PEM format )

Click “ **Apply** ” to save the configuration.

The screenshot shows the 'Network' configuration page with 'LAN 2 settings' for TLS authentication. DHCP is ON. IP settings are 192.168.0.122, not available, 255.255.255.0, and not available. Authentication is set to TLS. Identity, Certificate, Private key, and Private key password fields are empty with red error messages 'Identity is required.', 'Certificate is required.', 'Private key is required.', and 'Private key password is required.'. CA certificate is empty with 'CA cert is required.' and 'Enable CA certificate' is unchecked. DNS settings are the same as in Step 3. The 'Apply' button is circled in red.

## < 1.17 > 802.1X authentication

### < 802.1X authentication for Wireless network >

**Step 1.** Login the IP Dongle WEBUI and go to Network. Click the Authentication pull down menu and you will see the authentication method

The screenshot displays the 'Network' configuration page of the IP Dongle WEBUI. On the left is a sidebar menu with options: Device, Status, Details, Sensor, Setting (selected), System, Network (selected), Login, Local User, Domain/LDAP, SNMP, Notification, Syslog, and Firmware. The main content area is titled 'Network' and contains several sections:

- LAN 1 settings:** DHCP is set to OFF. IPv4 address is 192.168.11.1, IPv6 address is ::ffff:c0a8:b01/120, Subnet mask is 255.255.255.0, Gateway is 192.168.11.254, and Authentication is set to None.
- LAN 2 settings:** DHCP is set to ON. IPv4 address is 192.168.0.122, IPv6 address is not available, Subnet mask is 255.255.255.0, Gateway is not available, and Authentication is set to None.
- WiFi settings:** ESSID is Austin-Hughes User, Authentication is set to None (with a dropdown menu open showing options: None, PSK, PEAP, TLS), DHCP is set to None, IPv4 address is not available, IPv6 address is not available, Subnet mask is 255.255.255.0, and Gateway is 192.168.1.1. There is a 'Scan Wifi' button.
- DNS:** Manually configure DNS server is checked. Primary DNS is 8.8.8.8 and Secondary DNS is 0.0.0.0.

At the bottom of the page are 'Apply' and 'Cancel' buttons.



## < 1.17 > 802.1X authentication

**Step 2.** To use PEAP as authentication method, select PEAP. Select the Wireless network from “ESSID”, input the “Identity”, “Password” and “CA certificate” in PEM format. You can uncheck “Enable CA certificate” to bypass the authentication using CA certificate.

If you have the DHCP server to assign the IP address to the Wireless network, select “ON” from DHCP.

If you select “OFF” from DHCP, please input the “IPv4 address”, “Subnet mask” and “Gateway”.

Click “Apply” to save the configuration.

The screenshot displays the 'Network' configuration page. On the left is a sidebar with a menu containing 'Device', 'Status', 'Sensor', 'Setting', 'System', 'Network', 'Login', 'Local User', 'Domain/LDAP', 'SNMP', 'Notification', 'Syslog', and 'Firmware'. The 'Network' section is active. The main area is divided into several sections: 'LAN 1 settings' and 'LAN 2 settings' both have DHCP set to 'OFF' and show static IP, subnet mask, and gateway configurations. The 'WiFi settings' section shows 'ESSID' as 'Austin-Hughes User', 'Authentication' as 'PEAP', and a red error message 'Identity is required.' below the 'Identity' field. The 'DNS' section has 'Manually configure DNS server' checked, with 'Primary DNS' as '8.8.8.8' and 'Secondary DNS' as '0.0.0.0'. At the bottom, the 'Apply' button is circled in red, next to a 'Cancel' button.

Section	Parameter	Value
LAN 1 settings	DHCP	OFF
	IPv4 address	192.168.11.1
	IPv6 address	::ffff:c0a8:b01/120
	Subnet mask	255.255.255.0
	Gateway	192.168.11.254
	Authentication	None
LAN 2 settings	DHCP	OFF
	IPv4 address	192.168.0.110
	IPv6 address	::ffff:c0a8:1/120
	Subnet mask	255.255.255.0
	Gateway	192.168.0.254
	Authentication	None
WiFi settings	ESSID	Austin-Hughes User
	Authentication	PEAP
	Identity	(Redacted)
	Identity is required.	(Error message)
	Password	(Redacted)
	CA certificate	(Redacted)
DNS	Manually configure DNS server	Checked
	Primary DNS	8.8.8.8
	Secondary DNS	0.0.0.0
	DHCP	ON
	IPv4 address	not available
	IPv6 address	not available

**Step 3.** To use TLS as authentication method, select TLS. Select the Wireless network from “ESSID”, input the “Identity”, “Certificate”, “Private key”, “Private key password” and “CA certificate”. ( Certificate, private key and CA certificate are in PEM format )

If you have the DHCP server to assign the IP address to the Wireless network, select “ON” from DHCP.

If you select “OFF” from DHCP, please input the “IPv4 address”, “Subnet mask” and “Gateway”.

Click “Apply” to save the configuration.

The screenshot displays the 'Network' configuration page. On the left is a sidebar with a 'Setting' menu containing 'System', 'Network' (selected), 'Login', 'Local User', 'Domain/LDAP', 'SNMP', 'Notification', 'Syslog', and 'Firmware'. The main content area is titled 'Network' and contains several sections:

- LAN 1 settings:** DHCP is set to 'OFF'. Fields for IPv4 address (192.168.11.1), IPv6 address (::ffff:c0a8:b01/120), Subnet mask (255.255.255.0), and Gateway (192.168.11.254) are present. Authentication is set to 'None'. There is an unchecked checkbox for 'Enable automatic failover'.
- LAN 2 settings:** Similar to LAN 1, with DHCP set to 'OFF' and various IP and gateway fields.
- WiFi settings:** ESSID is 'Austin-Hughes User'. Authentication is set to 'TLS'. Fields for Identity, Certificate, Private key, Private key password, and CA certificate are present, each with a red error message 'Identity is required.', 'Certificate is required.', 'Private key is required.', and 'CA certificate is required.' respectively. There are 'Browse' buttons for Certificate, Private key, and CA certificate. An unchecked checkbox for 'Enable CA certificate' is also present.
- DNS:** 'Manually configure DNS server' is checked. Fields for Primary DNS (8.8.8.8) and Secondary DNS (0.0.0.0) are present.

At the bottom, there are 'Apply' and 'Cancel' buttons. The 'Apply' button is circled in red.

## < 1.18 > Command Line Interface ( CLI ) Access

Command Line Interface ( CLI ) allows you access the IP dongle via Telnet or Secure Shell ( SSH ) to configure the system settings and login settings. If the IP dongle is in factory default setting or password is " 00000000 ", you MUST change the password during the login. After you change the password, you can configure the system and login settings of the IP dongle.

By default, CLI access via SSH is enabled and Telnet is disabled whereas the Telnet can be enabled.

CLI and IP dongle WEBUI shares the same login name & password. The CLI session will be terminated automatically if three unsuccessful login attempts.

You can change the following settings via CLI access :

- i. System settings
  - Change temperature display unit : change the temp unit to be displayed in the WEBUI
  - Change system RTC date time : set the system time of the IP Dongle
  - Change network settings : change the IP settings of the IP Dongle
  - Change features & services
    - a. Enable / disable management software support
    - b. Enable / disable SNMP agent
    - c. Enable / disable FTP server
    - d. Enable / disable WEBUI
    - e. Enable / disable UDP ( When disabled, IP dongle CANNOT be found by IP setup utilities )
    - f. Enable / disable Telnet
    - g. Enable / disable maintenance ( service ) account
- ii. Login settings
  - Change login name
  - Change login password
  - Reset to default login name & password

< 1.19 > Optional Accessories - Wifi Kit

Part I. Package and Technical Specification



WIFI Kit ( IPD-WIFI )

- Antenna x 1
- USB wireless adapter x 1
- Magnetic stand with 1M antenna wire x 1

Unpacking

The equipment comes with the standard parts shown on the package contents. Check and make sure they are included and in good condition. If anything is missing, or damage, contact the supplier immediately.

IPD-WIFI Wireless Specification	
IEEE Standards	IEEE 802.11a / b / g / n / ac
Operating Frequencies	2.4GHz~2.4835GHz / 5.15GHz~5.85GHz
Modulation	<ul style="list-style-type: none"><li>• 802.11b : CCK, DQPSK, DBPSK</li><li>• 802.11a/g : 64-QAM, 16-QAM, QPSK, BPSKz</li><li>• 802.11n : 64-QAM, 16-QAM, QPSK, BPSK</li><li>• 802.11ac : 256-QAM, 64-QAM, 16-QAM, QPSK, BPSK BT, 8DPSK, π/4DQPSK, GFSK</li></ul>
Wireless Date Rate	<ul style="list-style-type: none"><li>• 802.11b : 1, 2, 5.5, 11 Mbps</li><li>• 802.11a/g : 6, 9, 12, 18, 24, 36, 48, 54 Mbps</li><li>• 802.11n : HT20 reach up to 72.2Mbps, HT40 reach up to 150Mbps</li><li>• 802.11ac : VHT20 reach up to 86.7Mbps, VHT40 reach up to 200Mbps, VHT80 reach up to 433.3Mbps</li></ul>
Security	<ul style="list-style-type: none"><li>• WPA2 - Personal</li><li>• WPA2 - Enterprise</li></ul>

## < 1.19 > Optional Accessories - Wifi Kit

### Part II. Hardware Connection

#### Antenna + USB Wireless Adaptor


##### Step < 1 >

- Inset and screw the antenna to the USB wireless adaptor. Fix the antenna in place & lift it up.



##### Step < 2 >

- Take out the membrane from the PDU dongle, and the WIFI USB port will be found.



##### Step < 3 >

- Connect the USB wireless adaptor (with antenna) to PDU dongle




## < 1.19 > Optional Accessories - Wifi Kit

### Antenna + USB Wireless Adaptor + Magnetic Stand with Antenna Wire

#### Step < 1 >

- Inset and screw the antenna to the magnetic stand, and fix the antenna in place.
- Inset and screw the 1M antenna wire to USB wireless adaptor, and fix the adaptor in place.



#### Step < 2 >

- Take out the membrane from the PDU dongle, and the WIFI USB port will be found.



#### Step < 3 >

- Connect USB wireless adaptor to PDU dongle.
- Affix the magnetic stand (with antenna) to the desirable area of rack.



Intentionally  
Left  
Blank



Intentionally  
Left  
Blank

Intentionally  
Left  
Blank

The company reserves the right to modify product specifications without prior notice and assumes no responsibility for any error which may appear in this publication.

All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2023 Austin Hughes Electronics Ltd. All rights reserved.