

# COMMAND LINE INTERFACE USER GUIDE IP Dongle ( IPD-03-S )



**( Version 1.0 )**

**(1<sup>st</sup> April, 2026 )**

## Content

### < Part 1 > Command Line Interface ( CLI )

|     |                   |     |
|-----|-------------------|-----|
| 1.1 | Introduction      | P.1 |
| 1.2 | Logging in to CLI | P.1 |
| 1.3 | Syntax            | P.1 |

### < Part 2 > System

|     |            |     |
|-----|------------|-----|
| 2.1 | Get system | P.2 |
| 2.2 | Set system | P.3 |

### < Part 3 > Network

|     |             |     |
|-----|-------------|-----|
| 3.1 | Get network | P.4 |
|-----|-------------|-----|

### < Part 4 > Device

|     |              |      |
|-----|--------------|------|
| 4.1 | Get PDUs     | P.5  |
| 4.2 | Set PDUs     | P.6  |
| 4.3 | Get Circuits | P.6  |
| 4.4 | Set Circuits | P.8  |
| 4.5 | Get Outlets  | P.8  |
| 4.6 | Set Outlets  | P.10 |
| 4.7 | Get Sensors  | P.11 |
| 4.8 | Set Sensors  | P.13 |

### < Part 5 > Outlet Notation P.14

## < Part 1 > Command Line Interface

### < 1.1 > Introduction

Command Line Interface ( CLI ) allows you to administer the PDUs connected to the IP Dongle via the network interface using Telnet or Secure Shell ( SSH ). If the IP Dongle is in factory default setting or password is “ 00000000 ”, you MUST change the password during the login. After you change the password, you can login the CLI to perform the setting, monitoring and control.

By default, CLI access via SSH is enabled and Telnet is disabled whereas the Telnet can be enabled.

The CLI can be used to :

- Reset
- Configure the device settings
- Display the device and network information such as device name, firmware version, IP setting and so on.

### < 1.2 > Logging in to CLI

You can login the CLI via the network interface using SSH or Telnet. Please follow the steps below to login the CLI.

1. Launch SSH or Telnet via PuTTY.
2. Input the IP address of IP Dongle.
3. Input the login and password in the login prompt. CLI shares the same login name and password as the WEBUI.
4. A main menu will be shown for functions selection and configuration.
5. Select “ (6) Command Line Interface ” to enter to CLI prompt

### < 1.3 > Syntax

The CLI uses a SET and GET command structure to save and retrieve setup parameters.

The CLI syntax is as follows :

- Colon ( : ) MUST be followed by a parameter
- All names are case sensitive
- get help to retrieve the get commands and options
- set help to retrieve the set commands and options

## < Part 2 > System

### < 2.1 > Get system

| Command                | Default value      | Remarks   |
|------------------------|--------------------|---|
| get system help        | N/A                | To show the list of system option can be retrieved.   |
| get system model       | IP Dongle PPS-03-S | The model name of the IP Dongle   |
| get system firmware    | IPD-03-FW-v3.26    | The firmware version of the IP Dongle   |
| get system build       | yyyymmdd           | The build date of the IP Dongle firmware  |
| get system name        | Default_z4m_name   | To retrieve the system name   |
| get system location    | Default_z4m_loc.   | To retrieve the system location   |
| get system tempunit    | C                  | C = Celsius F = Fahrenheit  |
| get system date        | 2007-01-01         | The format is yyyy-mm-dd  |
| get system time        | 00:08:51           | The format is hh:mm:ss  |
| get system timezone    | GMT+00:00          | The time zone setting of the system   |
| get system ntp         | time.google.com    | If returns "none", the system date / time is set manually not synchronize by time server  |
| get system https       | Yes                | If the value returned is " No ", web service is via http.   |
| get system port        | 443                | Port no. use by https / http  |
| get system timesync    | Disable            | Disable = time sync is disabled. Enable = time sync is enabled.   |
| get system sslcert     | Default            | If you load your own certificate in the WEBUI, it will return " Custom ".   |
| get system opcpop      | xxxx               | N/A   |
| get syslog xxxx - xxxx | A list of syslog   | To retrieve the syslog of the system. xxxx : 1 to 1600. If <b>NOT</b> input xxxx – xxxx. The first 100 events will be displayed by default. |

## < 2.2 > Set system

| Command                            | Return value | Remarks  |
|------------------------------------|--------------|--|
| set system help                    | N/A          | To show the list of system option can be set.  |
| set system name:xxxx               | OK           | Set the system name to “ xxxx ”. Valid input : 0~9, A~Z, a~z, underscore, dash & full-stop up to 16 characters.  |
| set system location:xxxx           | OK           | Set the system location to “ xxxx ”. Valid input : 0~9, A~Z, a~z, underscore, dash & full-stop up to 16 characters.  |
| set system tempunit:C              | OK           | Set the temperature unit to “ C ”  |
| set system date:2025-09-18         | OK           | Set the system date to 2025-09-18. If ntp server is enabled, cannot set system date  |
| set system time:15:20:30           | OK           | Set the system time to 15:20:30. If ntp server is enabled, cannot set system time.   |
| set system timezone:GMT+08:00      | OK           | Set the time zone of the system  |
| set system ntp:none / xxxxx / sync | OK           | None: set the date / time setting to manual.<br>xxxxxx : set the date / time synchronization by NTP server.<br>sync : synchronize date / time from NTP server. |
| set system opcpop:xxxx             | OK           | N/A  |

## < Part 3 > Network

### < 3.1 > Get network

| Command                 | Default value                              | Remarks  |
|-------------------------|--|--|
| get network help        | N/A  | To show the list of network option can be retrieved.                                 |
| get network:xx mode     | dual / lan1                                | dual : device has 2 network interfaces.<br>lan1 : device has one network interface.  |
| get network:xx failover | Disable / Enable                           | To view to the network interface operates in failover mode or not.                   |
| get network:xx dns      | xxx.xxx.xxx.xxx / xxx.xxx.xxx.xxx          | To retrieve the IP address of primary and secondary DNS server.                      |
| get network:xx mac      | xx:xx:xx:xx:xx:xx                          | To retrieve the Mac address of the network interface.                                |
| get network:xx link     | Up / Down                                  | To retrieve the link state of the network interface.                                 |
| get network:xx speed    | 100 / 1000 / 65535                         | To retrieve the connection speed of the network interface. 65535 means not connected |
| Get network:xx dhcp     | Disable / Enable                           | To retrieve the DHCP setting of the network interface.                               |
| get network:xx ipv4     | xxx.xxx.xxx.xxx                            | To retrieve the IPv4 address of the network interface.                               |
| get network:xx smv4     | xxx.xxx.xxx.xxx                            | To retrieve the IPv4 address of the network interface's subnet.                      |
| get network:xx gwv4     | xxx.xxx.xxx.xxx                            | To retrieve the IPv4 address of the network interface's gateway.                     |
| get network:xx ipv6     | xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx/xx | To retrieve the IPv6 address of the network interface.                               |

## < Part 4 > Device

### < 4.1 > Get PDUs

| Command                      | Default value                                    | Remarks  |
|------------------------------|--|--|
| get pdu help                 | N/A  | To show the list of pdu option can be retrieved  |
| get pdu:xx model             | The pdu model name                               | To retrieve the model name of the pdu  |
| get pdu:xx name              | The name of the specified pdu level              | To retrieve the name of the pdu  |
| get pdu:xx location          | The location of the specified pdu level          | To retrieve the location of the pdu  |
| get pdu:xx firmware          | The firmware version of the specified pdu level  | To retrieve the firmware version of the pdu  |
| get pdu:xx uid               | The unique ID of the specified pdu level         | To retrieve the unique ID of the pdu   |
| get pdu:xx real-time-clock   | The rea-time clock of the specified pdu level    | To retrieve the real-time clock of the pdu.<br>Format :<br>yymmddhhmmssw. w means weekday. |
| get pdu:xx serial-no         | The serial no. of the specified pdu level        | To retrieve the serial no of the pdu.  |
| get pdu:xx cumulative-energy | The cumulative energy of the specified pdu level | To retrieve the cumulative energy of the pdu in thousandth of kWh.                         |
| get pdu:xx apparent-power    | The apparent power of the specified pdu level    | To retrieve the apparent power of the pdu in thousandth of kVA.                            |
| get pdu:xx active-power      | The active power of the specified pdu level      | To retrieve the active power of the pdu in thousandth of kW.                               |
| get pdu:xx current           | The current loading of the specified pdu level   | To retrieve the current loading of the pdu in A.   |
| get pdu:xx power-factor      | The power factor of the specified pdu level      | To retrieve the power factor of the pdu Valid value : 0.0 ~ 1.0                            |
| get pdu:xx frequency         | The frequency of the specified pdu level         | To retrieve the frequency of the pdu in Hz.  |
| get pdu:xx voltage           | The voltage of the specified pdu level           | To retrieve the voltage of the pdu in V.   |

## < 4.2 > Set PDUs

| Command                     | Default value                                       | Remarks   |
|-----------------------------|---|---|
| set pdu help                | N/A   | To show the list of pdu option can be set.  |
| set pdu:xx<br>name:xxxx     | To set the pdu name of the specified pdu level.     | Length of name : 1 ~ 63. Valid input : 0~9, A~Z, a~z, underscore, dash & full-stop.     |
| set pdu:xx<br>location:xxxx | To set the pdu location of the specified pdu level. | Length of location : 1 ~ 63. Valid input : 0~9, A~Z, a~z, underscore, dash & full-stop. |

## < 4.3 > Get Circuits

| Command                                 | Default value   | Remarks   |
|---|---|---|
| get circuit help                        | N/A   | To show the list of circuit option can be retrieved   |
| get circuit:xx level:yy<br>name         | The circuit name  | To retrieve the name of the circuit   |
| get circuit:xx level:yy<br>rated-amp    | The rated amp. of the specified circuit                     | To retrieve the rated amp of the circuit in A.  |
| get circuit:xx level:yy<br>rated-volt   | The rated voltage. of the specified circuit                 | To retrieve the rated voltage of the circuit in V.  |
| get circuit:xx level:yy<br>alarm        | The amp. alarm threshold of the specified circuit           | To retrieve the amp. Alarm threshold of the circuit in A.   |
| get circuit:xx<br>level:yy rising-alert | The amp. rising alert threshold of the specified circuit    | To retrieve the amp. rising alert threshold of the circuit in A.  |
| get circuit:xx level:yy<br>low-alert    | The amp. low alert threshold of the specified circuit       | To retrieve the amp. low alert threshold of the circuit in A.   |
| get circuit:xx level:yy<br>amp state    | The alarm state of current loading of the specified circuit | To retrieve the alarm state of the circuit.<br>Value : Normal, L. Alert ( low alert ), R.Alert ( rising alert ) & Alarm |
| get circuit:xx level:yy<br>voltage      | The voltage of the specified circuit                        | To retrieve the voltage of the circuit in V.  |
| get circuit:xx level:yy<br>current      | The current loading of the specified circuit                | To retrieve the current loading of the circuit in A.  |
| get circuit:xx level:yy<br>power-factor | The power factor of the specified circuit                   | To retrieve the power factor of the circuit Valid value : 0.0 ~ 1.0   |
| get circuit:xx level:yy<br>active-power | The active power of the specified circuit                   | To retrieve the active power of the circuit in thousandth of kW.  |

| Command                                      | Default value   | Remarks  |
|--|---|--|
| get circuit:xx level:yy<br>apparent-power    | The apparent power of the specified circuit                     | To retrieve the apparent power of the circuit in thousandth of kVA.  |
| get circuit:xx level:yy<br>peak              | The peak current loading of the specified circuit               | To retrieve the peak current loading of the circuit in A.  |
| get circuit:xx level:yy<br>peak-timestamp    | The time stamp of peak current loading of the specified circuit | To retrieve the time stamp of peak current loading of the circuit being recorded in A.<br>Time stamp format :<br>yymmddhhmmss              |
| get circuit:xx level:yy<br>cumulative-energy | The cumulative energy of the specified circuit                  | To retrieve the cumulative energy of the circuit in thousandth of kWh.   |
| get circuit:xx level:yy<br>cum-timestamp     | The time stamp of cumulative energy of the specified circuit    | To retrieve the time stamp of cumulative energy of the circuit being recorded in thousandth of kWh.<br>Time stamp format :<br>yymmddhhmmss |
| get circuit:xx level:yy<br>protection-state  | The circuit state of the specified circuit.                     | Value: Normal , Tripped  |

## < 4.4 > Set Circuits

| Command  | Default value  | Remarks   |
|--|--|---|
| set circuit help                                   | N/A  | To show the list of circuit option can be set.  |
| set circuit:xx level:yy<br>alarm:zz                | Set the amp. alarm threshold of the specified circuit to zz        | To set the amp. Alarm threshold of the circuit in A up to 3 decimal places. Alarm threshold must be greater than rising alert threshold. Rising alert threshold must be greater than low alert threshold. |
| set circuit:xx level:yy<br>rising-alert:zz         | Set the amp. rising alert threshold of the specified circuit to zz | To set the amp. rising alert threshold of the circuit in A up to 3 decimal places. Rising alert threshold equals to 0.000 means disable.  |
| set circuit:xx level:yy<br>low-alert:zz            | Set the amp. low alert threshold of the specified circuit to zz    | To set the amp. low alert threshold of the circuit in A up to 3 decimal places. Low alert threshold equals to 0.000 means disable.  |
| set circuit:xx level:yy<br>peak:reset              | Reset the peak current loading of the specified circuit to zero    | To reset the peak current loading of the circuit to zero with timestamp updated.  |
| set circuit:xx level:yy<br>cumulative-energy:reset | Reset the cumulative energy of the specified circuit to zero       | To reset the cumulative energy of the circuit to zero with timestamp updated.   |

## < 4.5 > Get Outlets

| Command                                   | Default value                                    | Remarks  |
|---|--|--|
| get outlet help                           | N/A  | To show the list of outlet option can be retrieved                                 |
| get outlet:xx level:yy<br>binding-circuit | The circuit which the outlet belongs to          | Binding circuit value: 01 to 12. It depends on the no. of circuit of the PDU have. |
| get outlet:xx level:yy<br>type            | The outlet type of the specified outlet          | To retrieve the outlet type of the outlet.   |
| get outlet:xx level:yy<br>name            | The outlet name of the specified outlet          | To retrieve the outlet name of the outlet.   |
| get outlet:xx level:yy<br>rated-volt      | The rated voltage of the specified outlet        | To retrieve the rated voltage of the outlet in V.                                  |
| get outlet:xx level:yy<br>rated-amp       | The rated ampere of the specified outlet         | To retrieve the rated ampere of the outlet in A.                                   |
| get outlet:xx level:yy<br>alarm           | The amp. alarm threshold of the specified outlet | To retrieve the amp. Alarm threshold of the outlet in A.                           |

| Command  | Default value  | Remarks  |
|--|--|--|
| get outlet:xx level:yy rising-alert            | The amp. rising alert threshold of the specified outlet        | To retrieve the amp. rising alert threshold of the outlet in A.  |
| get outlet:xx level:yy low-alert               | The amp. low alert threshold of the specified outlet           | To retrieve the amp. low alert threshold of the outlet in A.   |
| get outlet:xx level:yy power-up-sequence-delay | The power up sequence delay of the specified outlet.           | To retrieve the power up sequence delay of the outlet in second. Value : 1 to 10.  |
| get outlet:xx level:yy relay-state             | The power state of the specified outlet                        | To retrieve the power state of the outlet. Value : On / Off  |
| get outlet:xx level:yy amp-state               | The apparent power of the specified outlet                     | To retrieve the alarm state of the outlet.<br>Value : Normal, L. Alert ( low alert ), R.Alert ( rising alert ) & Alarm                 |
| get outlet:xx level:yy voltage                 | The voltage of the specified outlet                            | To retrieve the voltage of the outlet in V.  |
| get outlet:xx level:yy current                 | The current loading of the specified outlet                    | To retrieve the current loading of the outlet in A.  |
| get outlet:xx level:yy power-factor            | The frequency of the specified outlet                          | To retrieve the power factor of the outlet Valid value : 0.0 ~ 1.0   |
| get outlet:xx level:yy active-power            | The active power of the specified outlet                       | To retrieve the active power of the outlet in thousandth of kW.  |
| get outlet:xx level:yy apparent-power          | The apparent power of the specified outlet                     | To retrieve the apparent power of the outlet in thousandth of kVA.   |
| get outlet:xx level:yy peak                    | The peak current loading of the specified outlet               | To retrieve the peak current loading of the outlet in A.   |
| get outlet:xx level:yy peak-timestamp          | The time stamp of peak current loading of the specified outlet | To retrieve the time stamp of peak current loading of the outlet being recorded in A.<br>Time stamp format : yymmddhhmmss              |
| get outlet:xx level:yy cumulative-energy       | The cumulative energy of the specified outlet                  | To retrieve the cumulative energy of the outlet in thousandth of kWh.  |
| get outlet:xx level:yy cum-timestamp           | The time stamp of cumulative energy of the specified outlet    | To retrieve the time stamp of cumulative energy of the outlet being recorded in thousandth of kWh.<br>Time stamp format : yymmddhhmmss |

## < 4.6 > Set Outlets

| Command  | Default value   | Remarks  |
|--|---|--|
| set outlet help  | N/A   | To show the list of outlet option can be set.  |
| set outlet:xx level:yy<br>name:zz                        | Set the outlet name of the specified outlet to zz                 | Length of name : 1 ~ 16. Valid input : 0~9, A~Z, a~z, underscore, dash & full-stop.  |
| set outlet:xx level:yy<br>alarm:zz                       | Set the amp. alarm threshold of the specified outlet to zz        | To set the amp. Alarm threshold of the outlet in A up to 3 decimal places. Alarm threshold must be greater than rising alert threshold. Rising alert threshold must be greater than low alert threshold. |
| set outlet:xx level:yy<br>rising-alert:zz                | Set the amp. rising alert threshold of the specified outlet to zz | To set the amp. rising alert threshold of the outlet in A up to 3 decimal places. Rising alert threshold equals to 0.000 means disable.  |
| set outlet:xx level:yy low-<br>alert:zz                  | Set the amp. low alert threshold of the specified outlet to zz    | To set the amp. low alert threshold of the outlet in A up to 3 decimal places. Low alert threshold equals to 0.000 means disable.  |
| set outlet:xx level:yy<br>power-up-sequence-<br>delay:zz | Set the power up sequence delay of the specified outlet to zz     | To set the power up sequence delay of the outlet in second. Value: 1 to 10s.   |
| set outlet:xx level:yy<br>relay-state:zz                 | Set the relay-state of the specified outlet to zz                 | To set the relay-state of the outlet. Value: On, Off, Power-cycle  |
| set outlet:xx level:yy<br>peak:reset                     | Reset the peak current loading of the specified outlet to zero    | To reset the peak current loading of the outlet to zero with timestamp updated.  |
| set outlet:xx level:yy<br>cumulative-energy:reset        | Reset the cumulative energy of the specified outlet to zero       | To reset the cumulative energy of the outlet to zero with timestamp updated.   |

## < 4.7 > Get Sensors

| Command                                     | Default value  | Remarks   |
|---|--|---|
| get sensor help                             | N/A  | To show the list of sensor option can be retrieved  |
| get sensor:xx<br>level:yy name              | The sensor name of the specified sensor                  | To retrieve the sensor name of the sensor.  |
| get sensor:xx<br>level:yy location          | The sensor location of the specified sensor              | To retrieve the sensor location of the sensor.  |
| get sensor:xx<br>level:yy activation        | The activation state of the specified sensor             | To retrieve the activation state of the sensor.<br>1=activated , 0=deactivated  |
| get sensor:xx<br>level:yy type              | The sensor type of the specified sensor                  | To retrieve the sensor type of the sensor. 2=Temp/TH, 3=Door, 5=Smoke   |
| get sensor:xx<br>level:yy connect-state     | The connect state of the specified sensor                | To retrieve the connect state of the sensor. 1=connected, 2=disconnect  |
| get sensor:xx<br>level:yy alarm-state       | The alarm state of the specified sensor                  | To retrieve the alarm state of the sensor.<br>Temp /TH<br>sensor :00=normal,<br>10=temp sensor alarm,<br>01=humid sensor alarm,<br>20=temp sensor rising alert,<br>02=humid sensor rising alert<br>Door sensor : 10=open ,<br>00=close<br>Smoke sensor : 10=alarm,<br>00=normal |
| get sensor:xx<br>level:yy temp-measurement  | The temp. reading of the specified sensor                | To retrieve the temp. reading of the sensor in degree C or F depends on the temp unit setting of system   |
| get sensor:xx<br>level:yy temp-state        | The temp. alarm state of the specified sensor            | To retrieve the temp. alarm state of the sensor.<br>Value: Normal, Alarm,R.Alert  |
| get sensor:xx<br>level:yy temp-alarm        | The temp. alarm threshold of the specified sensor        | To retrieve the temp. Alarm threshold of the sensor in degree C or F depends on the temp unit setting of system   |
| get sensor:xx<br>level:yy temp-rising-alert | The temp. rising alert threshold of the specified sensor | To retrieve the temp. rising alert threshold of the sensor in degree C or F depends on the temp unit setting of system  |

| <b>Command</b>                                   | <b>Default value</b>   | <b>Remarks</b>  |
|--|--|---|
| get sensor:xx<br>level:yy humid-<br>measurement  | The humidity reading of the<br>specified sensor              | To retrieve the humidity<br>reading of the sensor in %.                                 |
| get sensor:xx<br>level:yy humid-state            | The humid. alarm state of the<br>specified sensor            | To retrieve the humid. alarm<br>state of the sensor.<br>Value: Normal,<br>Alarm,R.Alert |
| get sensor:xx<br>level:yy humid-alarm            | The humid. alarm threshold of<br>the specified sensor        | To retrieve the humid. Alarm<br>threshold of the sensor in %.                           |
| get sensor:xx<br>level:yy humid-rising-<br>alert | The humid. rising alert threshold<br>of the specified sensor | To retrieve the humid. rising<br>alert threshold of the sensor<br>in %.                 |

## < 4.8 > Set Sensors

| Command   | Default value  | Remarks   |
|---|--|---|
| set sensor help                                     | N/A  | To show the list of sensor option can be set  |
| set sensor:xx<br>level:yy location                  | To set the location of the specified sensor.                     | Length of location : 1 ~ 16. Valid input : 0~9, A~Z, a~z, underscore, dash & full-stop.   |
| set sensor:xx<br>level:yy activation:zz             | To set the activation state of the specified sensor              | To set the activation state of the sensor. 1=activate , 0=deactivate  |
| set sensor:xx<br>level:yy type:zz                   | To set the sensor type of the specified sensor                   | To set the sensor type of the sensor. 2=TH / Temp, 3=Door, 5=Smoke  |
| set sensor:xx<br>level:yy temp-<br>alarm:zz         | To set the temp. alarm threshold of the specified sensor         | To set the temp. Alarm threshold of the sensor in degree C or F depends on the temp unit setting of system. Temp alarm threshold must be greater than temp. rising alert threshold. |
| set sensor:xx<br>level:yy temp-rising-<br>alert:zz  | To set the temp. rising alert threshold of the specified sensor  | To set the temp. rising alert threshold of the sensor in degree C or F depends on the temp unit setting of system. Temp. rising alert threshold equals to 0.0 means disable.        |
| set sensor:xx<br>level:yy humid-<br>alarm:zz        | To set the humid. alarm threshold of the specified sensor        | To set the humid. Alarm threshold of the sensor in %.   |
| set sensor:xx<br>level:yy humid-rising-<br>alert:zz | To set the humid. rising alert threshold of the specified sensor | To set the humid. rising alert threshold of the sensor in %. Temp. rising alert threshold equals to 0.0 means disable.  |

## < Part 5 > Outlet Notation

| Outlet Type                     | Notation       |
|---------------------------------|----------------|
| IEC C13                         | 1              |
| IEC C19                         | 2              |
| BS-1363                         | 3              |
| US NEMA                         | 4              |
| Schuko ( CEE 7/4 )              | 5              |
| AS 3112                         | 6              |
| French ( CEE 7/5 )              | 7              |
| L13 ( IEC C13 with slide lock ) | Z              |
| L19 ( IEC C19 with slide lock ) | [              |
| X19                             | \              |
| CX13                            | ^              |
| CX19                            | _ (underscore) |
| South Africa ( Type M )         | R              |
| International                   | S              |

**INTENTIONALLY  
BLANK**

The company reserves the right to modify product specifications without prior notice and assumes no responsibility for any error which may appear in this publication.

All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2026 Austin Hughes Electronics Ltd. All rights reserved.